







Preface

Thank you for purchasing the AC drive developed by Our company.

AC drives are general type inverters with vector control based on BD330.High quality, multiple functions and low noise, developed independently by ourselves. It can realize open loop and close loop control of different mode, and also signal detection of PT100/PT1000 motor temperature.It support speed sensorless vector control, sensor vector control and V/F control.Performance of motor control has beed improved obviously.Easy operation, perfect self-learning of motor static and dynamic state.

AC drives are compact structure, easy installation, and reasonable heat dissipation design ,that ensure reliability of product. Various of expansion cards are available for your choice.

We provide information of model selection, installation, parameter setting, field debugging, fault diagnosis and daily maintenance for users in this manual.

First-time Use

For the users who use this product for the first time, read the manual carefully. If in doubt concerning some functions or performances, contact the technical support personnel of Our company to ensure correct use.

ATTENTIONS

- > Please power off when wiring.
- Electronic components inside AC drive are especially sensitive to static electricity, do not put anything into internal of AC drive. And do not touch main circuit board.
- After power cut, if indicator is still lamp, it still have high voltage in AC drive. It is very dangerous, please do not touch internal circuit and components.
- > Please ensure the grounding terminals of AC drive is grounded correctly.
- > Never connect input power supply with output terminal U,V,W of AC drive.



Contents

Chapter 1 Safety and Attentions	
1.1 Safety Matters	6
1.2 Use Considerations	9
Chapter 2 Product Brief Introduction	
2.1 Position and content of nameplate	12
2.2 Nameplate model description and rated parameters	12
2.3 Specifications and models of AC drives	13
2.4 Technical Features	15
2.5 All components schematic diagram of AC drive	17
2.6 Dimensions	18

Chapter 3 Installation

3.1	Mechanical installation	.22
3.2	Electrical Installation	.23
3.3	Basic wiring diagram	.26
3.4	Jumper function declaration of main board	.27
3.5	Main circuit terminals and connection	.27
3.6	Control circuit terminal and wirin	.29
3.7	Treatment of EMC problem	.32

Chapter 4 Operation and Display

4.1	Keypad description	.36
4.2	Function code examining and modifying methods explanation	.38
4.3	How to view status parameters	.40
4.4	Password setting	.40
4.5	Self-learning of motor parameters (when vector control function)	.41

Chapter 5 Function & Parameter Table

5.1	How to read the parameter list44	1
5.2	Functional group4	5



Chapter 6 Description of Function Codes

F00	Standard Function Parameters	86
F01	Standard Function Parameters	
F02	Motor 1 Parameters	104
F03	Vector Control Parameters	108
F04	V/F Control Parameters	114
F05	Fault and Protection	120
F06	Input Terminals	131
F07	Output Terminals	146
F08	Keypad And Display	152
F09	Auxiliary Functions	157
F10	Process Control PID Function	172
F11	Swing Frequency, Fixed Length and Count	
F12	Simple PLC Function And Multi-speed control	
F13	Communication Parameters	
F15	Motor 2 Parameters	190

Chapter 7 Fault Diagnosis and Trouble Shooting

7.1	Faults and Solutions	
7.2	Common Faults and Solutions	

Chapter 8 Appendix

Appendix A: Serial Communications	202
Appendix B: Accessories Selection	212
Appendix C: Mini Series introduction	216
Appendix D: Single Phase Output Series	219
Appendix E: 220V Input, 380V Output Series	221
Appendix F: Elevator & Lift Series	223
Appendix G: Off Grid Solar Series	229

Warranty

Warranty Card

Certificate of quality

Peaco Support FC280 Series VFD User Manual





Peaco Support FC280 Series VFD User Manual



Safety and Attentions

1.1	Safe	ty Matters6	3
1.2	Use	Considerations)



Chapter 1 Safety and Attentions

Users are requested to read this chapter carefully when installing, commissioning and repairing this product and perform the operation according to safety precautions as set forth in this chapter without fail. Our company will bear no responsibility for any injury and loss as a result of any violation operation.

Safety signs in this manual		
	Dangers caused by operations beyond requirements may lead to serious injury,and even death.	
	angers caused by operations beyond requirements may lead to moderate damages or minor injuries, as well equ-ipment damages.	

1.1 Safety Matters

Use Stage	Safety Grade	Precautions	
Before Installation		 Do not install the product if the package is with water, or component is missing or broken; Do not install the product if the label on the package is not identical to that on the inverter. 	
		 Be careful of carrying or transportation. Risk of devices damage; Do not use damaged product or the inverters missing component .Risk of injury; Do not touch the parts of control system with bare hands. Risk of ESD hazard. 	
Installation	Anger	 ◇ Installation base shall be metal or other non-flammable material. Risk of fire; ◇ Do not install inverter in an environment containing explosive gases, otherwise there is danger of explosion; ◇ Do not unscrew the fixing bolts, especially the bolts with red mark. 	
		 Do not leave cable strips or screws in the inverter. Risk of inverter damage; Install the product at the place with less vibration and no direct sunlight; 	



Chapter 1 Safety and Attentions

Use Stage	Safety Grade	Precautions	
Installation		Consider the installation space for cooling purpose when two or more inverters are placed in the same cabinet.	
		Wiring must be performed by authorized and qualified personnel. Risk of danger;	
		Circuit-breaker should be installed between inverter and the mains. Risk of fire;	
		♦ Make sure the input power supply has been completely disconnected before wiring. Failure to comply may result in personnel injury and/or equipment damage;	
Wiring	Anger	☆ Since overall leakage current of this equipment may be bigger than 3.5mA, for safety's sake, this equipment and its associated motor must be well grounded so as to avoid risk of electric shock;	
		Never connect the power cables to the output terminals (U,V,W) of the AC drive. Pay attention to the marks of the wiring terminals and ensure correct wiring. Failure to comply will result in damage to the AC drive;	
		♦ Install braking resistors at terminals (P+)and (P- or PB) only. Failure to comply may result in equipment damage.	
		♦ If motor cables are longer than 100m, it is recommend- ed output AC reactor be used. Failure to comply may result in faults.	
Before		Inverter shall be power-on only after the front cover is assembled. Risk of electrical hazard.	
Power-on		Verify that the input voltage is identical to the rated voltage of product, correct wiring of input terminals R,	



Chapter 1 Safety and Attentions

Use Stage	Safety Grade	Precautions
Before Power-on		S, T or L1, L2 and output terminals U, V, and W, wiring of inverter and its peripheral circuits, and all wires should be in good connection. Risk of inverter damage.
After Power-on		 ◇ Do not open the cover after power. Rick of electrical hazard; ◇ Do not touches any input/output terminals of inverter with bare hands. Rick of electrical hazard.
		 ◇ If auto tuning is required, be careful of personal injury when motor is running. Risk of accident; ◇ Do not change the defaults of parameters. Risk of devices damage.
During Operation	Anger	 Non-professionals shall not detect signals during operation. Risk of personal injury or device damage; Do not touch the fan or the discharging resistor to check the temperature. Failure to comply will result in personal burnt.
		 Prevent any foreign items from being left in the devices during operation. Risk of device damage; Do not control start/stop of inverter by ON/OFF of contactor. Risk of device damage.
Main- tenance	in- nce A danger	Please do not make repair and maintenance over equ- ipment in a charged state, or it will give rise to electric shock hazard!
		AC drive can be put into maintenance and repair only you confirm the AC drive charge light out, or the rema- ining electric charge of capacitance will cause damages to people!
		Any people who are not trained professionally cannot make repair and maintenance, or it will cause personal injuries or equipment troubles!

-8-



1.2 Use Considerations

1.2.1 Motor Insulation Inspection

When the motor is used for the first time or when the motor is reused after being kept, or when periodical inspection is performed, insulation inspection shall be conducted with motor so as to avoid damaging the inverter because of the insulation failure of the motor windings. The motor wires must be disconnected from the inverter during the insulation inspection. It is recommended to use the 500V mega meter, and the insulating resistance measured shall be 5M Ω at least.

1.2.2 Motor Thermal Protection

If the motor rating does not match that of the inverter, especially when the rated power of the inverter is higher than that of the motor, adjust motor protection parameters in the inverter or install thermal relay to protect motor.

1.2.3 Operating with the Frequency Higher than Grid Power Frequency

Output frequency of is 0.00Hz~500Hz. If product is required to operate above 50.00Hz, please take the endurance of mechanical devices into consideration.

1.2.4 Mechanical Vibrations

Inverter may encounter mechanical resonance point of the load device at certain output frequencies which can be avoided by setting the skip frequency parameters of the inverter.

1.2.5 Motor Heat and Noise

Since output voltage of inverter is PWM wave and contains a certain amount of harmonics, so that the temperature, noise and vibration of the motor will be higher than those when the inverter runs at grid power frequency.

1.2.6 Voltage-sensitive device or capacitor on output side of the AC drive

Do not install the capacitor for improving power factor or lightning protection voltage-sensitive resistor on the output side of the AC drive because the output of the AC drive is PWM wave. Otherwise, the AC drive may suffer transient overcurrent or even be damaged.

1.2.7 Contactor at the I/O terminal of the AC drive

When a contactor is installed between the input side of the AC drive and the power supply, the AC drive must not be started or stopped by switching the contactor on or off. If the AC drive has to be operated by the contactor, ensure that the time interval between switching is at least one hour since frequent charge and discharge will shorten the service life of the capacitor inside the AC drive;

-9-



When a contactor is installed between the output side of the AC drive and the motor, do not turn off the contactor when the AC drive is active. Otherwise, modules inside the AC drive may be damaged.

1.2.8 Applied with the Rated Voltage

Apply product with the rated voltage. Failure to comply will damage inverter. If required, take a transformer to boost or step-down voltage.

1.2.9 Do Not Apply a 3-Phase Input Inverter to 2-Phase Input Applications

Do not apply a 3-phase input FR inverter to 2-phase input applications. Otherwise, it will result in faults or damage inverter.

1.2.10 Lightning Protection

The product has integrated lightning over-current protection device which has certain self-protection capacity against the lightning. Additional protection devices have to be installed between inverter and power supply in the area where lightning occurs frequently.

1.2.11 Altitude De-rating

In places where the altitude is above 1000 m and the cooling effect reduces due to thin air, it is necessary to de-rate the AC drive. Contact Our company for technical support.

1.2.12 Adaptable Motor

Standard adaptive motor is quadrupole squirrel- cage asynchronous induction motor. If it is not above- mentioned motor, please select AC drive upon rated current of moter. If you need to drive permanent magnet synchronous motor, please consult our company;

The cooling fan of non variable frequency motor and rotor spindle are coaxially connected. While despinning, the fan cooling effect also declines at the same time. Hence, for overheated occasion of moter, you shall install strong exhaust fan or change variable frequency motor;

AC drives have built- in adaptive motor standard parameters. It is necessary to make motor parameter identification or amend default values to accord with actual values, or it will influence operation effects and protective values;

As short circuit existing inside cable or motor will cause inverter alarming, enen explosion. Therefore, please make insulation short- circuit test of initial installed motor and cable first. And the test also is necessary in routine maintenance.

-10-



Peaco Support FC280 Series VFD User Manual



Product Brief Introduction

2.1	Position and content of nameplate	12
2.2	Nameplate model description and rated parameters	12
2.3	Specifications and models of AC drives	13
2.4	Technical Features	15
2.5	All components schematic diagram of AC drive	17
2.6	Dimensions	18



Chapter 2 Product Brief Introduction

2.1 Position and content of nameplate



2.2 Nameplate model description and rated parameters



Code	No.	Content		
Voltage level	1	2 : 220V 4 : 380V		
Voltage Classification	2	S : Single-phase T : Three phase		
Adapted motor powe	3	0.75KW~630KW		
Model	4	Heavy-duty		
Accessory type	5	Brake unit		



2.3 Specifications and models of AC drives

Models	Rated power (KW)	Rated input current (A)	Rated output current(A)	Adaptive motor (KW)
	Input 1PH 220V	±15% 47Hz~6	3Hz	
2S-0.5G-B	0.55	5.4	4.0	0.55
2S-0.7G-B	0.75	8.2	5.0	0.75
2S-1.5G-B	1.5	14.0	7.0	1.5
2S-2.2G-B	2.2	23	10.0	2.2
	Input 3PH 220V	±15% 47Hz~6	3Hz	
2T-0.5G-B	0.55	3.8	3.2	1.5
2T-0.75G-B	0.75	4.9	4.1	0.75
2T-1.5G-B	1.5	8.4	7.0	1.5
2T-2.2G-B	2.2	11.5	10.0	2.2
2T-3.7G-B	3.7	18	15	3.7
2T-5.5G-B	5.5	24	23	5.5
2T-7.5G-B	7.5	37	31	7.5
2T-11G-B	11	52	45	11
2T-15G-B	15	68	58	15
2T-18.5G-B	18.5	84	71	18.5
2T-22G-B	22	94	85	22
2T-30G	30	120	115	30
2T-37G	37	160	145	37
2T-45G	45	198	180	45
2T-55G	55	237	215	55
2T-75G	75	317	283	75
\sim	Input 3PH 380V	±15% 47Hz~6	3Hz	
4T-0.75G/1.5P	0.75/1.5	3.4/5.0	2.5/3.7	0.75/1.5
4T-1.5G/2.2P	1.5/2.2	5.0/5.8	3.7/5.0	1.5/2.2
4T-2.2G/3.7P	2.2/3.7	5.8/10.5	5.0/8.5	2.2/3.7
4T-3.7G/5.5P	3.7/5.5	10.5/14.6	8.5/13	3.7/5.5
4T-5.5G/7.5P	5.5/7.5	14.6/20.5	13/18	5.5/7.5
4T-7.5G/11P	7.5/11	20.5/26	18/24	7.5/11



Chapter 2 Product Brief Introduction

Models	Rated power (KW)	Rated input current (A)	Rated output current(A)	Adaptive motor (KW)
	Input 3PH 380V	±15% 47Hz~6	3Hz	
4T-11G/15P	11/15	26/35	24/30	11/15
4T-15G/18.5P	15/18.5	35/38.5	30/37	15/18.5
4T-18.5G/22P	18.5/22	38.5/46.5	37/46	18.5/22
4T-22G/30P	22/30	46.5/62	46/58	22/30
4T-30G/37P	30/37	62/76	58/75	30/37
4T-37G/45P	37/45	76/92	75/90	37/45
4T-45G/55P	45/55	92/113	90/110	45/55
4T-55G/75P	55/75	113/157	110/150	55/75
4T-75G/93P	75/93	157/180	150/170	75/93
4T-93G/110P	93/110	180/214	170/210	93/110
4T-110G/132P	110/132	214/256	210/250	110/132
4T-132G/160P	132/160	256/307	250/300	132/160
4T-160G/200P	160/200	307/385	300/380	160/200
4T-200G/220P	200/220	385/430	380/430	200/220
4T-220G/250P	220/250	430/468	430/465	220/250
4T-250G/280P	250/280	468/525	465/520	250/280
4T-280G/315P	280/315	525/590	520/585	280/315
4T-315G/350P	315/350	590/665	585/650	315/350
4T-350G/400P	350/400	665/785	650/754	350/400
4T-400G/500P	400/500	785/965	754/930	400/500
4T-500G/630P	500/630	965/1210	930/1180	500/630
4T-630G/710P	630/710	1210/1465	1180/1430	630/710



2.4 Technical Features

P	Technical Features	Description				
oweri	Input voltage range	1AC 220V±15%, 3AC 220V±15%,3AC 380V±15%, 3AC 660V±10%, 3AC 1140V±15%				
npu	Input frequency range	47~63Hz				
7	Power factor	≥95%				
	Control mode	V/F control, non-PG vector control(SVC), PG vector control (FVC)				
	V/F control	Line, multiple point , square V/F curve, V/F separation				
0	Operation command mode	Keypad control, Terminal control, Serial communic-ation control				
	Frequency Reference Source	Digital,analog,pulse frequency,serial communication, multi- step speed,simple PLC and PID The combinaton of multi- modes and the different modes can be switched.				
	Overload capacity	G type: 150% rated current 60s,180% rated current 3s P type: 120% rated current 60s, 150% rated current 3s				
	Start torque	G type: 0.5Hz/150%(SVC), 0Hz/180%(FVC) P type: 0.5Hz/100%				
ont	Speed adjusting range	1:100(SVC) 1:1000(FVC)				
rol pe	Speed control accuracy	±0.5%(SVC) ±0.02%(FVC)				
rform	Carrier frequency	0.5 to 16.0kHz;automatically adjust carrier frequency according to the load characteristics				
ance	Frequency resolution	Digital setting:0.01Hz. Anolog setting:maximum frequency x 0.025%				
	Torque boost	Automatic torque boost; manual torque boost 0.1~30%				
	Acceleration and deceleration mode	Line or S-curve, 4 types of acceleration/deceleration time with the range of 0.0~6500.0 s $$				
	DC brake	Supports starting and stopping DC brake;				
	Jogging Control	Jog frequency range:0.0Hz~50.00Hz; Jog Acc/Dec time:0~6500.0s				
	Simple PLC & multi step speed operation	Built-in PLC or control terminal,16 steps speed can be set				
	Built-in PID	Built-in PID control to easily realize the close loop control for the process parameters (such aspressure, temperature, flow, etc.)				



Chapter 2 Product Brief Introduction

Technical Features		Description
Con	Automatic voltage regulation(AVR)	Automatically maintain a constant output voltage when the voltage of electricity grid changes
trol perform	Common DC bus	Common DC bus function: multiple inverters can use a common DC bus
	Traverse control	Traverse control function:multiple triangular pulse frequency control
anc	Fixed length control	Setting length control
e	Timing control	Setting time range: 0~6500min
Main control	Input terminals	6 programmable digital inputs,it can be extended to 4 digital inputs,one of which supports high speed pulse input; 1 analog volatge input 0~10VDC; 2 volatge input 0~10VDC or current input 0~20mA.
	Output terminals	1 open collector output ,it can be extende to 1 high speed pulse output ; 2 relay outputs ; 2 analog output: volatge output 0~10VDC or current output 0~20mA.
Human machine interface	LED Display	Can display setting frequency, output frequency, output voltage, output current, etc.
	Protection class	IP20
En & Pro	Humidity & temperature	90%RH or less (no-condensation),- $10^{\circ}C \sim +40^{\circ}C$.Inverter will be derated if ambien temperature exceeds $40^{\circ}C$
vioi tecti	Vibration	Under 20Hz 9.8m/s(1G),Over 20Hz5.88m/s(0.6G)
ion c	Store environment	≤1000M,indoor(no corrosive gas and liquid)
nt :lass	Store temperature	- 20°℃~ 60°℃
	Cooling Mode	Forced air-cooling

-16-



2.5 All components schematic diagram of AC drive

The following picture is all components and names of below 22KW plastic shell AC drive.



No.	Name	Description			
0	Cabinet-cover	Protect the internal components.			
2	Keypad	Refer to chapter4 "Keypad operating procedures."			
3	Lower-cover	Protect the internal components.			
4	Fan-cover	Protection fan.			
6	Lower House	Including Fan and heat sink			
6	Middle House	Including Power Boards			
0	Dust prevention	To Prevent Dust			
8	Bottom Board	Inverter protection			
9	Apron	Convenient input and output wiring.			
0	Series Label	Refer to 2.3 "Naming Rules".			
0	Screw Hole	To make VFD firm with screw			

-17-



Chapter 2 Product Brief Introduction

2.6 Dimensions



AC Drive Model	Rated Power (KW)	A (mm)	H (mm)	D (mm)	W (mm)	B (mm)	d (mm)
Input 1PH 220V±15% 47Hz~63Hz							
2S-0.5G-B	0.55						
2S-0.7G-B	0.75	118	185	157	106	175	4.5
2S-1.5G-B	1.5						
2S-2.2G-B	2.2						
2S-3.7G-B	3.7	160	247	177	148	235	5.5
2S-5.5G-B	5.5						

-18-



Peaco Support FC280 Series VFD User Manual Chapter 2 Product Brief Introduction

AC Drive Model	Rated Power (KW)	A (mm)	H (mm)	D (mm)	W (mm)	B (mm)	d (mm)
	Input 3PH	H 380V±1	5% 471	Iz∼63Hz			
4T-0.7G/1.5P-B	0.75/1.5						
4T-1.5G/2.2P-B	1.5/2.2	110	105	457	100	175	4.5
4T-2.2G/4.0P-B	2.2/3.7	110	160	157	106	175	4.5
4T-4.0G/5.5P-B	3.7/5.5						
4T-5.5G/7.5P-B	5.5/7.5						
4T-7.5G/11P-B	7.5/11	160	247	177	148	235	5.5
4T-11G/15P-B	11/15						
4T-15G/18.5P-B	15/18.5						
4T-18.5G/22P-B	22/30	220	321	198	205	305	5.5
4T-22G/30P-B	30/37						
4T-30G/37P	37/45	220	220 411	238	160	395	7
4T-37G/45P	45/55	220					
4T-45G/55P	55/75	255	453	237	190	440	7
4T-55G/75P	75/93	290	500	205	200	560	0
4T-75G/90P	93/110	280	282	295	200	503	9
4T-90G/110P	110/132	300	605	222	200	667	11
4T-110G/132P	132/160		000	323	200	007	11
4T-132G/160P	160/200	360	690	330	260	660	11
4T-160G/185P	200/220	400	040	224	150*	015	44
4T-185G/200P	220/250	420	840	334	150	815	11
4T-200G/220P	250/280						
4T-220G/250P	280/315	540	934	390	200* 200	893	13
4T-250G/280P	315/350				200		
4T-280G/315P	350/400	640	1005	200	250*	1000	11
4T-315G/350P	400/500	640	1035	390	250	1003	11
4T-350G/400P	500/630	000	1000	400	350*	1104	45
4T-400G/450P	630/710	800	1200	400	350	1164	15



Peaco Support FC280 Series VFD User Manual



Installation

3.1	Mechanical installation	.22
3.2	Electrical Installation	.23
3.3	Basic wiring diagram	.26
3.4	Jumper function declaration of main board	27
3.5	Main circuit terminals and connection	.27
3.6	Control circuit terminal and wirin	.29
3.7	Treatment of EMC problem	32



3.1 Mechanical Installation

3.1.1 Installation Environment

- Environment temperature: Surrounding environment temperature has a great impact on lifetime of AC drive, and the operation environment temperature of AC drive shall not exceed allowable temperature range (- 10°C ~ 40°C).
- While AC drive is installed on the surface of inflaming retardants, and enough space around is necessary for heat dissipation. When AC drive works, it will produce plenty of heats. And make vertical installation onto supporting holder with screw.
- Please install it in some places that are not easy to vibrate. And the vibration shall not be larger than 0. 6G. Especially pay attention to keep away from punching machine and other equipments.
- Avoid to be installed where there are direct sunlights, moist surroundings and water drops.
- Avoid to be installed where there are corrosivity, inflammability and explosive gas.
- > Avoid to be installed where there are oil contamination, dirts and metal dusts.

3.1.2 Reminder of installation site



Air flow diverting

Explanation: When power of AC drive≤ 22kw it means taking no account of size A is permissible. When the power > 22KW, A shall be larger than 50mm. **Explanation:** When AC drive is installed upside and underside, please install thermal insulation guide plate as picture shows.





3.2 Electrical Installation

3.2.1 Model Selection of Main Circuit Peripheral Devices

Models	MCCB (A)	Contactor (A)	Cable of Input Side Main Circuit (mm²)	Cable of Output Side Main Circuit (mm²)	Cable of Control Circuit (mm ²)
	In	put 1PH 22	20V±15% 47Hz~	~63Hz	
2S-0.5G-B	16	10	2.5	2.5	1.0
2S-0.7G-B	16	10	2.5	2.5	1.0
2S-1.5G-B	20	16	4.0	2.5	1.0
2S-2.2G-B	32	20	6.0	4.0	1.0
	In	put 3PH 22	20V±15% 47Hz-	~63Hz	
2T-0.5G-B	10	10	2.5	2.5	1.0
2T-0.75G-B	16	10	2.5	2.5	1.0
2T-1.5G-B	16	10	2.5	2.5	1.0
2T-2.2G-B	25	16	4.0	4.0	1.0
2T-3.7G-B	32	25	4.0	4.0	1.0
2T-5.5G-B	63	40	4.0	4.0	1.0
2T-7.5G-B	63	40	6.0	6.0	1.0
2T-11G-B	100	63	10	10	1.0
2T-15G-B	125	100	16	10	1.0
2T-18.5G-B	160	100	16	16	1.0
2T-22G-B	200	125	25	25	1.0
2T-30G	200	125	35	25	1.0
2T-37G	250	160	50	35	1.0
2T-45G	250	160	70	35	1.0
2T-55G	350	350	120	120	1.0
2T-75G	500	400	185	185	1.0
	In	put 3PH 38	30V±15% 47Hz-	~63Hz	
4T-0.75G/1.5P	10	10	2.5	2.5	1.0
4T-1.5G/2.2P	16	10	2.5	2.5	1.0
4T-2.2G/3.7P	16	10	2.5	2.5	1.0
4T-3.7G/5.5P	25	16	4.0	4.0	1.0
4T-5.5G/7.5P	32	25	4.0	4.0	1.0
4T-7.5G/11P	40	32	4.0	4.0	1.0
4T-11G/15P	63	40	4.0	4.0	1.0
4T-15G/18.5P	63	40	6.0	6.0	1.0



Chapter 3 Installation

Models	MCCB (A)	Contactor (A)	Cable of Input Side Main Circuit (mm²)	Cable of Output Side Main Circuit (mm²)	Cable of Control Circuit (mm²)
	In	put 3PH 38	30V±15% 47Hz~	~63Hz	
4T-18.5G/22P	100	63	6	6	1.0
4T-22G/30P	100	63	10	10	1.0
4T-30G/37P	125	100	16	10	1.0
4T-37G/45P	160	100	16	16	1.0
4T-45G/55P	200	125	25	25	1.0
4T-55G/75P	250	125	35	25	1.0
4T-75G/93P	250	160	50	35	1.0
4T-15G/18.5P	350	160	70	35	1.0
4T-93G/110P	350	350	120	120	1.0
4T-110G/132P	400	400	150	150	1.0
4T-132G/160P	500	400	185	185	1.0
4T-160G/200P	500	400	185	185	1.0
4T-200G/220P	630	600	150*2	150*2	1.0
4T-220G/250P	630	600	150*2	150*2	1.0
4T-250G/280P	800	600	150*2	150*2	1.0
4T-280G/315P	800	800	150*2	150*2	1.0
4T-315G/350P	1000	800	150*3	150*3	1.0
4T-350G/400P	1000	800	150*4	150*4	1.0
4T-400G/500P	1200	1000	150*4	150*4	1.0
4T-500G/630P	1200	1000	150*4	150*4	1.0
4T-630G/710P	1200	1000	150*4	150*4	1.0



3.2.2 Peripheral device wiring diagram



Figure 3-2 Peripheral device wiring diagram

-25-



Chapter 3 Installation

3.3 Basic wiring diagram



Figure 3-3 Basic Wiring Diagram

Note:

- ➤ The general type AC drives ≤22kw have built- in brake unit,brake resistance (+) and PB terminal;(+) and(-) terminals are the plus or minus terminals of inverter's DC bus.
- ➢ Reserved direct current reactor connection terminals ≥30kw,⊕1⊕2,⊕2 and Θterminals are used to connect energy feedback unit or brake unit.
- > When brake unit is used in high- power AC drives, you shall connect positive pole of brake unit to output terminal⊕2 of direct current reactor. If it is connected to⊕1 terminal, it will damage brake unit.

-26-



3.4 Jumper function declaration of main board

Item	Meaning
AI1	Analogue input 1 voltage/ current signal conversion
Al2	Analogue input 2 voltage/ current signal conversion
V	0-10VDC voltage signal input
I	0-20mA analog current signal input
AO1	Analog output 1 voltage/ current signal conversion
AO2	Analog output 2 voltage/ current signal conversion
V	0-10VDC voltage signal input
I	0-20mA analog current signal input

3.5 Main circuit terminals and connection



- Confirm power switch stays in the state of OFF and then start wiring operation or it will give rise to electric shock hazard!
- Wiring personnel must be those professional trainees or it will cause equipment damages and personal injuries!
- Reliable ground connection is necessary or it will give rise to electric shock or fire alarm!
- Confirm the input power is in accordance with the rated value of AC drive, or it will cause damages to AC drive!
- Confirm motor is adaptive with AC drive or it will cause damages to motor or cause AC drive protection!
- Power supply shall not be connected to the terminals of U, V and W, or it will cause damages to AC drive!
- ➢ Brake resistance shall not be connected directly to DC bus ⊕2,⊙ or it will cause damages to AC drive!



Chapter 3 Installation

3.5.1 Main circuit terminal description

Main circuit wiring terminal ≤22kw					
Terminal	Name	Function description			
R、S、T(L、N)	Main circuit power input terminal	Connect three- phase (one- phase) power supply			
U, V, W	Output terminal of AC drive	Connect three phase motor			
(+)、PB	Braking terminal	Connect external brake resistance			
(+)、(-)	DC bus terminal	2 sets or more inverters use a common DC bus			
	Grounding terminal	Safty grounding			

Main circuit wiring terminal >22kw					
Terminal	Name	Function description			
R, S, T(L, N)	Main circuit power input terminal	Connect three- phase (one- phase) power supply			
U, V, W	Output terminal of AC drive	Connect three phase motor			
⊕2, ⊙	DC bus terminal	Use for connect brake unit,energy feedback, 2 sets or more AC drive use a common DC bus			
⊕1、⊕2	External reactor terminal	Connect external DC reactor			
	Grounding terminal	Safty grounding			

3.5.2 Attentions of wiring

A.Input power L, N or R, S and T:

The connection of inverter input side has no phase sequence requirements.

B.DC bus (+)2, (-)terminals:

At the moment of power failure, DC bus 12, O terminals still have residual voltage, you just can touch it after internal"charge" power light is off confirming the voltage is less than 36V, it may cause electric shock.

When you select external brake unit for AC drive \geq 30KW, the polarity of \oplus 2 and \bigcirc cannot be connected inversely or it will cause damages to ACdrive, or even fire hazard.



The wiring length of brake unit shall not be more than 10m, and only twisted pair or tight double-line is available in parallel.

Brake resistance cannot be connected onto DC bus directly, or it may cause damages to AC drive, or even fire hazard.

C.Brake resistance connection terminal (+) and PB:

AC drive ≤22KW and built- in brake unit.

The recommended value of brake resistance model selection reference and wiring distance shall be less than 5m, or it may cause damages to AC drive.

D.AC drive output side U, V and W:

AC drive output side shall not be connected to capacitor or surge absorber, or it will frequent protection of AC drive, or even damages.

When the cable of motor is overlong, the effects of distributed capacitance will generate electric resonance easily, and give rise to dielectric breakdown of motor.

The generated large leakage current makes AC drive suffer overcurrent protection. If cable length is more than 100m, alternating current output reactor shall be installed.

E.Grounding terminal (

Terminals must have been reliable ground connection, and resistance value of ground wire shall be less than 4Ω , or it will cause abnormal work of equipment, and even damages.

Grounding terminal and null line N terminal of power supply cannot be shared.

3.6 Control circuit terminal and wiring

3.6.1 Schematic diagram of control circuit wiring terminal



Figure 3-4 Schematic diagram of main control board wiring terminal

-29-



Chapter 3 Installation

3.6.2 Control circuit terminal description

Terminal	Terminal function description		
S1-DCM	Multifunctional input terminal 1	Function setting: F06.00 ~ F06.05	
S2-DCM	Multifunctional input terminal 2		
S3-DCM	Multifunctional input terminal 3		
S4-DCM	Multifunctional input terminal 4		
S5-DCM	Multifunctional input terminal 5		
S6-DCM	Multifunctional input terminal 6		
P24-DCM	Auxiliary power supply 24VDC 200mA		
10V-ACM	Input auxiliary power supply 10VDC 20mA		
AI1-ACM	Analog current input port 1: 0-10V or 0-20mA	Function setting:	
AI2-ACM	Analog current input port 2: 0-10V or 0-20mA		
AI3-ACM	Analog current input port 3 : -10~10V	100.10 100.20	
AO1-ACM	Analog current output port 1: output 0-10V or 0- 20mA	Function setting:	
AO2-ACM	Analog current output port 2: output 0-10V or 0- 20mA	F07.13~F07.20	
SG+ SG-	Rs485 communication port	F013.00~F13.07	
RA-RB-RC	Multifunctional connection point output, factory default is failure output		
TA-TB-TC	Multifunctional connection point output, factory default is output in operating	Function setting: F07.02 ~ F07.04	
MO1-DCM	Multifunctional collector output port of open circuit		

3.6.3 Control circuit terminal wiring explanation

A. Analog input terminal:

As the weak analog voltage signal will suffer external disturbance easily, generally shield cable is required, and the wiring distance shall be kept as short as possible, and no more than 20m will be better, as follows:





Figure 3-5 Schematic diagram of analog input terminal wiring

At some occasion where analog signal suffers severe interference, filter condenser or ferrite core shall be installed at the side of analog signal source, as Figure 3-6shows:



Figure 3-6 Analog input terminal with filter devices

B. Digital input terminal:

AC drive receives figure signal upon its judging of these terminals'states. So the external contactors shall be those connection points with high reliability over weak signals. If the applied open collector output to digital input terminal of AC drive provides 0N/0FF signal, you shall consider the false operation caused from the power crosstalk. We advise to adopt contactor control mode.

C. Digital output terminal:

When driving relay is required for digital output terminals, absorber diode shall be installed at both sides of relay coil, or it will cause damages to DC 24V power supply.

Attention: The polarity of absorber diode must be installed correctly, as following picture shows. Or when digital output terminals are outputted, it will cause DC 24Vpower supply damaged.

-31-



Chapter 3 Installation





3.7 Treatment of EMC problem

3.7.1 Effects of harmonic wave

- Higher harmonic wave of power supply will cause damages to inverter. So in some places with bad power grid quality, we advise to install AC input reactor.
- As higher harmonic wave exists at the output side of AC drive, the application of capacitor to improve power factor and surge suppressor at output side may lead to electric shock, or even damages to equipment, so capacitor or surge suppression device cannot be installed at output side.

3.7.2 Electromagnetic interference and treatment

- Electromagnetic interference has two categories: One is peripheral electromagnetic noise's interference on AC drive, which will give rise to false operations of inverter itself. But the effects of such interference usually are small, because AC drive has been processed internally in design about this interference, and it has a strong antiinterference capability. The other one is AC drive-'s effects on peripheral equipments.
 - > AC drive and other electrical products should ground well, and the ground resistance shall not more than 4Ω .
 - It will be better if power line of AC drive won't be placed in parallel with circuit of control line. If condition permission, please arrange power lines vertically.
 - At those occasions with a high anti- interference requirement, shield cable shall be used between AC drive and power line of motor, and reliable ground connection also is necessary for shielding layer.



- Handling methods of interference from peripheral electromagnetic equipment on AC drive.Electromagnetic effects on inverter generally result from the installation of many relays, contactors or electromagnetic contactors near AC drive. When AC drive has false operation from the interference, please try to solve it with following methods:
 - > Install surge suppressor on the devices that make interference;
 - Install filter at signal input terminal of AC drive;
 - The leading wire of AC drive's control signal line and detection circuit shall be shield cable, and reliable ground connection also is necessary for shielding layer.
- The handling methods of interference on peripheral equipments from the noises of AC drive:

This part of noise can be divided into two categories: One is the radiation of AC drive itself, and the other one is the radiation of the leading wire from inverterto motor.

These two kinds of radiations make the leading wires surface of peripheral electrical equipments suffer electromagnetic and electrostatic induction, which will lead to false operations of equipments. About these several different disturbed conditions, please refer to following methods to resolve them:

- Instrument, receiver, sensor and other equipment for measurement,generally have a weaker signal. If they are placed near AC drive or in a same control cabinet, they will suffer interference and operate falsely. So we advise to take following methods: Keep away from interference source; Signal line shall not be placed with power line in parallel, especially shall not be tied up together in parallel, and please adopt shield cable signal line and power line;Install linear filter or radio noise filter at the input and output sides of AC drive.
- When interrupted equipments and AC drive share a same power supply, if above methods still cannot help to eliminate interference, you shall install linear filter or radio noise filter between AC drive and power supply.



Separated ground connection for peripheral equipments can help to eliminate the interference from ground wires'leakage current of AC drive while common grounding.

3.7.3 Leakage current and treatment

Leakage current has two categories when inverter is in service: One is leakage current over the ground: and the other is leakage current between lines.

• The factors of influencing leakage current over the ground and solutions:

Distributed capacitances exist between wire and ground. The larger distributed capacitances are, the larger the leakage current will be: Effectively decreasing the distance between AC drive and motor can reduce distributed capacitances. The larger carrier frequency is, the larger the leakage current will be. Reducing carrier frequency can decrease leakage current effectively. But reducing carrier frequency will result in the increase of motor noise, so please note this. Installing electric reactor also is an effective method to solve leakage current.

Leakage current will increase with enlargement of loop current, so when the power of motor is large, the relevant leakage current also will be large.

2 The factors of influencing electric current between lines and solutions:

Distributed capacitances exit between output wires of AC drive. If the electric current passing the circuit contains higher harmonic, it may give rise to resonance and leakage current. If you use thermal relay, it may cause false operation at this time.

The solution is to decrease carrier frequency or install output reactor. We advise not to install thermal relay before you use the motor of AC drive, but apply the electronic overcurrent protection function of AC drive.



Peaco Support FC280 Series VFD User Manual



Operation and Display

4.1	Keypad description	.36
4.2	Function code examining and modifying methods explanation	.38
4.3	How to view status parameters	.40
4.4	Password setting	.40
4.5	Self-learning of motor parameters (when vector control function)	.41


Chapter 4 Operation and Display

4.1 Keypad description

4.1.1 Keypad explanation and function

Keypad locates above AC drive, and can be divided into two parts: display area and control area. Display area shows parameter setting mode and different run state. Control area is communication interface for users and AC drive.



Figure 4-1 Schematic diagram of operation panel

Name			Function Description
	编程PRGM ESC题出	PRGM/ESC	Enter first level menu or exit parameter group
Keypad button zone	わ施FUNG DATD设定	FUNCTION/ DATA	In the mode of normal operation, press this key to display all items of status and information of AC drive, such as frequency command,output freque-ncy and output current; In the mode of program, press this key to display parameters, and press again to write modified data into the internal storage.
	正转FMD REV反转	FORWARD/ REVERSE	Press the key of forward/reverse turning to slow down the motor to 0Hz, and acceleration in negativ-e direction to the setting frequency command.
	<u>煮动J0G</u> ≫移位	JGO / 》	Press this key to execute jog frequency command; In the mode of parameter operation, work as the left shift key.



Name		Function Description			
Keypad button zone	RUN 运行	RUN	Used to start AC drive operation.(This key has no effect when the drive is set to terminal run.)		
	停止STOP RST复位	STOP/RST	Used to stop the AC drive operation. If the AC drive has stopped due to a fault, press this key to reset the drive.		
		UP/DOWN	Used to select parameter item and modify parameter.		

4.1.2 Digital display item and description

• operating state (display item selection refer to parameter F08.03,F08.04)

Display Code	Item Fescription	Operation
Н	Setting frequency	Press (DATORIZE key
ρ	Operation frequency	Press (BATDIRGE key
E	Output current	Press (MRFunc key
d	Output voltage	Press (DATORIZE key
n	Operation speed	Press (MILEFUNC INTOINE key
E	Output torque	Press (DATORIZE key
ŀ	Output power	Press (MIRFUNC INTOINE key
U	Bus voltage	Press (DATORIZE key
8	PID setting value	Press
Ь	PID feedback value	Press (MINEFUNC INTOXAL key
1	Input terminal state	Press
ο	Output terminal state	Press (MINEFUNC INTOIRE key
U	Analog Al1 value	Press (MINEFUNC INTOXAL key
С	Analog Al2 value	Press (MINEFUND key
r	Analog AI3 value	Press (MIRFUNC key
П	Timing value	Press (MIRFUNC INTOINE key
L	Length value	Press they



1

Chapter 4 Operation and Display

ົ	In halted state (Refer to more	details of d	isplav items	selection in	E08 05)
9	in nancu state		uctans or u	ispiay norms	3010011111	1 00.00).

Display Code	Item Fescription	Operation
Н	Setting frequency	Press there key
U	Bus voltage	Press the key
1	Input terminal state	Press there key
ο	Output terminal state	Press there key
Я	PID setting value	Press there key
U	Analog Al1 value	Press the key
C	Analog Al2 value	Press the key
r	Analog AI3 value	Press there key
Ĥ	Timing value	Press (MILEFUNC INTOIRE key
L	Length value	Press there key

4.2 Function code examining and modifying methods explanation

AC drives adopts three-level menu structure for parameter setting and other operations. The three-level menus respectively are: functional parameter group(firstlevel menu)-function code (second- level menu)-function code setting value (third-level menu). Operational process is shown in Figure 4-2:



Figure 4-2 Operation flow chart of three-level menu



Explanation:

In third-level menu operation, press PRGM or DATA to return to second-level menu. The difference between them: Press DATA to store the setting parameters into control panel, return to second-level menu, and automatically shift to next function code; Press PRGM to return to second-level menu directly without saving parameters, and then return to function code.

For example:

Change the function code F2.02 from 10.00Hz to 15.00Hz.(Bold means flash bit):



Figure 4-3 Example for parameter changing

In third-menu state, if parameter can not flicker, it means this code can not be changed, and the reason may be:

- This parameter of function code cannot be changed, such as actually detected parameter, and running record parameter.
- In running status, this function code cannot be changed. And it can be changed only when inverter is stoped.

-39-



Chapter 4 Operation and Display

4.3 How to view status parameters

In stop or running status, LED nixie tube can be used to display the multiple state parameters of AC drive. The function code F08.03(operating parameter1) and F08.05(stop parameter) can be used to select whether this state parameter shall be displayed.Please refer to the function code F08. 03~F08.05 for more explanations. DATA is available for circular switchover to display the state parameter of halting state or running state.

In stop status, total 13 stop status parameters are available for selection to be displayed or not, and respectively are: setting frequency, bus voltage, input terminal status, output terminal status, PID setting, analog Al1 value, analog Al2 value, analog Al3 value, timing value, length value, PLC state, load speed, input pulse frequency(kHz).Positionally select whether display function F08. 05, and switch to display the selected parameters upon the sequence of FUNC/DATA.

In running status, total 32 status parameters are available for selection to be displayed or not, and respectively are: setting frequency, running frequency, output current, output voltage, running speed, output torque, output torque, bus voltage, PID setting value, PID feedback value,

input terminal status, output terminal status, analog Al1 value, analog Al2 value, analog Al3 value, timing value, length vaule. Positionally select whether display function F08. 03/F08.04, and switch to display the selected parameters upon the sequence of FUNC/ DATA.

If AC drive was power cut and then power on again, parameters is display the selected parameter before power cut.

4.4 Password setting

AC drives provide user password defensive function. When F08. 00 is set to non-0, it is user password. While quit function code editing state, password protection will take effect. Press PRGM/ESC again to enter function code editing state, it will display"0. 0. 0. 0. 0. ". User must enter password correctly, or he cannot get access.

If cancel password protection function, set F08.00 to 0.

-40-



4.5 Self-learning of motor parameters (when vector control function)

When you select vector control mode without PG, before inverter is running, you must input nameplate parameters of motors correctly. AC drives will match standard motor parameters upon the nameplate parameters. Vector control mode has a strong dependency on motor parameters. To obtain a good control performance, you shall get the exact parameters of controlled motors.

The operating steps of motor parameters self-learning as below:

First select operation instruction channel (F00. 01) as keypad instruction channel. Then input following parameters according to motor's actual parameters:

F02. 01: Asynchronous motor 1 rated power; F02. 02: Asynchronous motor 1 rated frequency; F02. 03: Asynchronous motor 1 rated speed; F02. 04: Asynchronous motor 1 rated voltage; F02. 05: Asynchronous motor 1 rated current.

If motors can be separated with loads totally, please select 2 in F02. 37(dynamic self- learning), and then press"RUN" on control panel, AC drives will calculate parameter automatically:

F02. 06: Asynchronous motor 1 stator resistance; F02. 07: Asynchronous motor 1 rotor resistance;

F02. 08: Asynchronous motor 1 stator and rotor leakage inductance; F02. 09: Asynchronous motor 1 stator and rotor mutual inductance;

F02. 10: Asynchronous motor 1 no-load current;

If motors cannot be separated with loads totally, please select 1 in F02. 37(static self-learning), and then press "RUN" on control panel.

AC drives will measure these three parameters: stator resistance, rotor resistance and leakage inductive reactance in sequence, don't measure excluding mutual inductive reactance and no-load current of motors. Users can calculate these two parameters according to motor nameplate : rated voltage U, rated current I, rated frequency f and power factor η .

The computing methods of motor no-load current and motor mutual inductance are described as below, thereinto, L_s is motor leakage inductive reactance.

-41-

Chapter ²



Chapter 4 Operation and Display

No-load current: $I_0 = I \cdot \sqrt{1 - \eta^2}$

Mutual inductance calculation: $L_m = \frac{U}{2[\sqrt{3} \pi f \cdot I_n} - L_s$

10 is no-load current, $L_{\scriptscriptstyle m}$ is mutual inductive reactance, and $L_{\scriptscriptstyle S}$ is leakage inductive reactance.



Peaco Support FC280 Series VFD User Manual



Function & Parameter Table

5.1	How to read the parameter list	44
5.2	Functional group	45



5.1 How to read the parameter list

The functional parameters of AC drives are grouping by function, total 16 groups from F00~F15. Each functional group includes several function codes. Function codes adopt three-level menu, for example, "F06. 08" means 8th function code of the functions in group F06.

For convenience of setting function codes, while operating with operation panel, function group number corresponding first- level menu, function code number corresponding second-level menu, and function cade parameters corresponding third-level menu.

- Contents note of function table is described as below:
- First column "function code": Functional parameter set and parametric number;
- Second column "name": Full name of functional parameters;
- > Third column "setting range": Valid set value range of functional parameters;
- Fourth column "factory default": Original factory default of functional parameters;
- Fifth column"modify": Alteration property of functional parameters(whether or not it is permitted to modify and modification conditions) and the explanations are described as below:

lcons	Content
*	It means the setting value of this parameter can be modified when AC drive is in stop or running state;
•	It means the setting value of this parameter cannot be modified when AC drive is in running state;
**	It means the numerical value of this parameter is practical detection record value, and cannot be modified;
##	It means the numerical value of this parameter is "factory para- meter", and is limited to be set by manufacturers. Users are prohibited about such operation.

(AC drives have already made automatic inspection constraint about the modification property of all parameters, which can help users to avoid faults in modification.)

 "Factory default" refers to the numerical value after function code parameters are renovated when you take factory reset operation; but the actually detective para-meter values or recorded values won't be renovated.



- To make more effective parameter protection, AC drives provide password protection for function codes. After users set password (the parameter of user password, F08. 00 set to non-0), and press PRGM/ ESC to enter into user parameter editingstate, the system will enter into user password authorization state, and display "0. 0. 0. 0. 0.". The manipulator must input user password correctly, or he cannot get access to it. In the unlocked state of password protection, user assword can be altered at any time, and user password will be confirmed as the last input numerical value. When F08.00 is set to 0, user password can be canceled; while power on, F08.00 set to non-0, then parameters are protected by password.
- While function code parameters are altered with serial communications, any functions of user password still keep to above regulations.

5.2 Functional group

Function code	Name	Description (setting range)	Factory Default	Change
	Group F00:	Standard Function Parameters		
F00.00	Speed control mode	0: non-PG vector control (SVC) 1: PG vector control (FVC) 2: V/F control	2	•
F00.01	Command source selection	0:keypad control 1:terminal control 2:RS 485 communication control	0	*
F00.02	Run command source of communication	0: Modbus communication card	0	*
F00.03	Max.output frequency	50.00Hz ~ 600.00Hz	50.00Hz	•
F00.04	Run frequency upper limit	F00.05 ~ F00.03(max.frequency)	50.00Hz	*
F00.05	Run frequency lower limit	0.00Hz ~ F00.04(run frequency upper limit)	00.00Hz	*
F00.06	Frequency A command selection	0:keypad, no retentive upon power failure 1:keypad, retentive upon power failure 2:analog Al1 3:analog Al2 4:analog Al3	0	•



Function code	Name	Description (setting range)	Factory Default	Change
F00.06	Frequency A command selection	5:pulse(HDI) 6:multi-speed running 7:simple PLC 8:PID control 9:RS485 Communication 10:potentiometer	0	·
F00.07	Frequency B command selection	Same as F00.06	0	•
F00.08	Range of frequency B command selection	0: relative to maximum frequency 1: relative to frequency A command	0	*
F00.09	Frequency source combination mode	0: frequency A command 1: frequency B command 2:switchover between frequency A command and frequency B command 3: A+B 4: A-B 5:MAX (A and B) 6: MIN (Aand B	0	*
F00.10	Keypad setting frequency	0.00Hz~F00.03(max. frequency)	50.00Hz	*
F00.11	Frequency refer- ence resolution	1:0.1Hz 2:0.01Hz	2	•
F00.12	Acceleration time 1	0.00s~6500.0s	Model dependent	*
F00.13	Deceleration time 1	0.00s~6500.0s	Model dependent	*
F00.14	Acceleration/Decele ration time unit	0: 1s 1: 0.1s 2: 0.01s	1	•
F00.15	Acceleration/Decele ration time base frequency	0:max.frequency(F00.03) 1:setting frequency 2:100Hz	0	•
F00.16	Rotation direction	0: same direction 1: reverse direction	0	*



Function code	Name	Description (setting range)	Factory Default	Change
F00.17	Carrier frequency	0.5kHz ~ 16.0kHz	Model dependent	*
F00.18	Carrier frequency adjustment with temperature	0: No 1: Yes	1	*
F00.19	Source of frequency upper limit	0: set by F00.04 1: analog Al1 2:analog Al2 3:analog Al3 4:pulse (HDI) 5:RS485 comminication	0	•
F00.20	Frequency upper limit offset	0.00Hz~max.frequency (F00.03)	00.00Hz	*
F00.21	Base frequency for UP/DOWN modification during running	0: running frequency 1: set frequency	0	•
F00.22	Binding command source to frequency source	Unit digit: (Binding keypad command to frequency source) 0: no binding 1: keypad setting 2: analog Ai1 3: analog Ai2 4: analog Ai3 5:pulse setting (HDI) 6: multi- speed run setting 7: Simple PLC 8: PID control 9: RS485 communication Ten's digit (Binding terminal command to frequency source) Hundred's digit (Binding comm- unication command to frequency source) Thousands digit:(Binding autoop- eration command to frequency source)	0000	*



Function code	Name	Description (setting range)	Factory Default	Change
F00.23	Range of frequency B source during superposition	0% ~ 150%	100%	*
F00.25	Frequency offset of frequency B source during superposition	0.00Hz ~ max.frequency F00.03	00.00Hz	•
F00.26	Retentive of keypad setting frequency upon power failure	0: no retentive 1: retentive	0	•
F00.27	Motor model selection	1: G type (constant torque load) 2: P type (variable torque load)	0	*
F00.28	Function parameter restore	0:no operation 1: restore factory defaults,not include motor parameter 2: clear fault file	0	•
F00.29	Reserved			_
F00.30	Reserved			_
F00.31	Reserved			_
F00.32	Parameter macro	0~6000	0	•
	Group F01: S	tandard Function Parameters		
F01.00	Start mode	0:direct start 1: rotational speed tracking restart 2: pre-excited start	0	*
F01.01	Startup frequency	0.00Hz ~ 10.00Hz	0.00Hz	*
F01.02	Startup frequency holding time	0.0s ~ 100.0s	0.0s	•
F01.03	Startup DC braking current/ Pre-excited current	0%~100%	0%	•
F01.04	Startup DC braking time/ Pre-excited time	0.0s ~ 100.0s	0.0s	•
F01.05	Acceleration/ deceleration mode	0: line Acc/Dec time 1: S curve Acc/Dec A 2: S curve Acc/Dec B	0	•



Function code	Name	Description (setting range)	Factory Default	Change
F01.06	Time proportion of S- curve start segment	0.0%~ (100.0%-F01.07)	30.0%	•
F01.07	Time proportion of S- curve end segment	0.0%~ (100.0%- F01.06)	30.0%	*
F01.08	Stop mode	0: Deceleration to stop 1: Stop freely	0	•
F01.09	Initial frequency of stop DC braking	0.00Hz ~ F00.03(max. frequency)	0.00Hz	•
F01.10	Waiting time of stop DC braking	0.0s~100.0s	0.0s	*
F01.11	Stop DC braking current	0%~100%	0.0%	•
F01.12	Stop DC braking time	0.0s~100.0s	0.0s	-
F01.13	Rotational speed tracking mode	0: start from frequency at stop1: start from zero speed2: start from max. frequency	0	_
F01.14	Rotational speed tracking speed	1~100	20	*
F01.15	Brake usage rate	0% ~ 100%	100%	*
	Group I	F02: Motor 1 Parameters		
F02.00	Motor type selection	0:common asynchronous motor 1:variable frequency asynchro- nous motor	0	•
F02.01	Rated power of asynchronous motor 1	0.1kW ~ 1000.0kW	Model dependent	•
F02.02	Rated frequency of asynchronous motor 1	0.01Hz ~ F00.03(max. frequency)	Model dependent	•
F02.03	Rated speed of asynchronous motor 1	1rpm ~ 65535rpm	Model dependent	•
F02.04	Rated voltage of asynchronous motor 1	1V~2000V	Model dependent	•
F02.05	Rated current of asynchronous motor 1	0.01A ~ 655.35A (AC drive power<= 55kW) 0.1A ~ 6553.5A (AC drive power> 55kW)	Model dependent	•

Function code	Name	Description (setting range)	Factory Default	Change
F02.06	Stator resistance of asynchronous motor 1	0.001Ω ~ 65.535Ω (inverter power<= 55kW) 0.0001Ω ~ 6.5535Ω (AC drive power> 55kW)	Model dependent	•
F02.07	Rotor resistance of asynchronous motor 1	0.001Ω ~ 65.535Ω (AC drive power<= 55kW) 0.0001Ω ~ 6.5535Ω (AC drive power> 55kW)	Model dependent	•
F02.08	Leakage inductive reactance of asynchronous motor 1	0.01mH ~ 655.35mH (AC drive power<= 55kW) 0.001mH ~ 65.535mH (AC drive power> 55kW)	Model dependent	•
F02.09	Mutual inductive reactance of asynchronous motor 1	0.1mH ~ 6553.5mH (inverter power<= 55kW) 0.01mH ~ 655.35mH (AC drive power> 55kW)	Model dependent	•
F02.10	No-load current of asynchronous motor 1	0.01A ~ F02.05 (inverter power<= 55kW) 0.1A ~ F02.05 (AC drive power> 55kW)	Model dependent	•
F02.27	Encoder type	0:ABZ incremental encoder 1:UVW incremental encoder	0	•
F02.28	Selection of PG card	0:QEP1	0	•
F02.29	Encoder pulses per revolution	1~65535	2500	•
F02.30	AB phase sequence of ABZ incremental encoder	0: forward 1: reverse	0	•
F02.31	Encoder installation angle	0.0 ~ 359.9°	0.0°	•
F02.32	UVW phase sequence of UVW encoder	0: forward 1: reverse	0	•
F02.33	UVW encoder angle offset	0.0 ~ 359.9°	0.0°	•



Function code	Name	Description (setting range)	Factory Default	Change
F02.36	Encoder wire-break fault detection time	0.0s: No action 0.1–10.0s	0.0	•
F02.37	Self-learning of motor parameter	0: no self-learning 1: dynamic self- learning of asynchronous motor 2: static self- learning of asynchronous motor	0	•
	Group F03:	Vector Control Parameters		
F03.00	Proportional gain 1 of speed loop	1~100	30	*
F03.01	Integral time 1 of speed loop	0.01s~10.00s	0.50s	*
F03.02	Switchover low point frequency	0.00Hz ~ F03.05	5.00Hz	*
F03.03	Proportional gain 2 of speed loop	1~100	20	*
F03.04	Integral time 2 of speed loop	0.01s~10.00s	1.00s	*
F03.05	Switchover high point frequency	F03.02 ~ F00.03(max. frequency)	10.00Hz	*
F03.06	Vector control slip gain	50% ~ 200%	100%	*
F03.07	Speed loop output filter	0.000s~0.100s	0.000s	*
F03.08	Vector control over excitation gain	0~200	64	*
F03.09	Torque upper limit source in speed control mode	0:F03.10 1:analog Al1 2:analog Al2 3:analog Al3 4:Pulse (HDI) 5:RS485 Communication 6:MIN(Al1,Al2) 7:MAX(Al1,Al2) (corresponding to F03.10 digital setting)	0	*

Function code	Name	Description (setting range)	Factory Default	Change
F03.10	Digital setting of torque upper limit in speed control mode	0.0% ~ 200.0%	150.0%	*
F03.13	Excitation adjustment proportional gain	0~60000	2000	*
F03.14	Excitation adjustment integral gain	0~60000	1300	*
F03.15	Torque adjustment proportion gain	0~60000	2000	*
F03.16	Torque adjustment integral gain	0~60000	1300	*
F03.17	Speed loop integral property	Units' digit: integral separation 0: invalid 1: valid	0	*
F03.18	Synchronous machine field weakening mode	0: Field weakening is invalid1: Direct calculation mode2: Automatic adjustment mode	0	*
F03.19	Synchronous machine field weakening depth	50% ~ 500%	100%	*
F03.20	Maximum field weakening current	1% ~ 300%	50%	*
F03.21	Field weakening automatic adjustment gain	10% ~ 500%	100%	*
F03.22	Field weakening integral multiple	2~10	2	*
F03.23	Speed/torque control mode selection	0: speed control 1: torque control	0	*
F03.24	Torque setting mode selection	0: digital setting (F03.26) 1:analog Al1 2:analog Al2 3:analog Al3 4:PULSE (HDI) 5:RS485 Communication 6:MIN(Al1,Al2)	0	*



Function code	Name	Description (setting range)	Factory Default	Change
F03.24	Torque setting mode selection	7:MAX(AI1,AI2) (corresponding to F03.26 digital setting)	0	*
F03.26	Torque setting by keypad	-200.0% ~ 200.0%	105%	*
F03.28	Upper frequency limit of forward when torque control	0.00Hz ~ F00. 03(max. frequency)	50.00Hz	*
F03.29	Upper frequency limit of reverse when torque control	0.00Hz ~ F00. 03(max. frequency)	50.00Hz	*
F03.30	Torque control acceleration time	0.00s~650.00s	0.00s	*
F03.31	Torque control deceleration time	0.00s~650.00s	0.00s	*
	Group F04:	V/F Control Parameters		
F04.00	Motor1 V/F curve setting	0: linear V/F 1: multi-point V/F 2: square V/F 3: V/F complete seperation 4: V/F half seperation 5:1.2 square V/F 6: 1.4 square V/F 7: 1.6 square V/F 8: 1.8 square V/F	0	*
F04.01	Motor 1 torque boost	0.0%:(auto torque boost) 0.1% ~ 30.0%	Model dependent	•
F04.02	Cut-off frequency of motor 1 torque boost	0.00Hz ~ F00.03 (max.frequency)	50.00Hz	•
F04.03	Motor1 V/F frequency point 1	0.00Hz~F04.05	0.00Hz	•
F04.04	Motor1 V/F voltage point 1	0.0% ~ 100.0%	0.0%	•
F04.05	Motor1 V/F frequency point 2	F04.03 ~ F04.07	0.00Hz	•



Function code	Name	Description (setting range)	Factory Default	Change
F04.06	Motor1 V/F voltage point 2	0.0% ~ 100.0%	0.0%	•
F04.07	Motor1 V/F frequency point 3	F04.05 ~ F02.02 (motor rated frequency	0.00Hz	•
F04.08	Motor1 V/F voltage point 3	0.0% ~ 100.0%	0.0%	•
F04.09	Motor1 V/F slip compensation gain	0.0% ~ 200.0%	0.0%	*
F04.10	V/F over-excitation gain	0~200	64	*
F04.11	V/F oscillation suppression gain	0~100	Model dependent	*
F04.13	Voltage source for V/F separation	0: digital setting (F04.14) 1: analog Al1 2: analog Al2 3: analog Al3 4: pulse (HDI) 5: multi-speed operation 6: simple PLC 7: PID control 8: RS485 Communication (corresponding F02.04 digital setting)	0	*
F04.14	Digital setting V/F separation of voltage	0V ~ F02.04(motor rated voltage)	0V	*
F04.15	Voltage digital setting for V/F separation	0.0s ~ 1000.0s note: time from 0V to motor rated voltage (F02.04)	0.0s	*
	Group F05:	Fault and Protection		
F05.00	Input phase loss protection	0: disabled 1: enabled	1	*
F05.01	Output phase loss protectio	0: disabled 1: enabled	1	*
F05.02	Action selection at instantaneous power failure	0: Invalid 1: Decelerate 2: Decelerate to stop	0	*



Function code	Name	Description (setting range)	Factory Default	Change
F05.03	Voltage rally judging time a instantaneous power failure	0.00s~100.00s	0.50s	*
F05.04	Action judging voltage at instantaneous power failure	60.0% ~ 100.0%(standard bus voltage)	80.0%	*
F05.05	Overvoltage stall gain	0~100	0	*
F05.06	Overvoltage stall protective voltage	120% ~ 150%	130%	*
F05.07	Overcurrent stall gain	0~100	20	*
F05.08	Overcurrent stall protective current	100% ~ 200%	150%	*
F05.09	Motor overload warning selection	0: disabled 1: enabled	1	*
F05.10	Motor overload pre-alarm warning detection levels	0.20~10.00	1.00	*
F05.11	Motor overload pre-alarm warning detection time	50% ~ 100%	80%	*
F05.12	Protection upon load becoming 0	0: disabled 1: enabled	0	*
F05.13	Detection level of load becoming 0	0.0 ~ 100.0% (rated motor current)	10.0%	*
F05.14	Detection time of load becoming 0	0.0~60.0s	1.0s	*
F05.15	Over-speed detection value	0.0% ~ 50.0%(F00.03(max. frequency))	20.0%	*
F05.16	Over-speed detection time	0.0~60.0s	1.0s	*
F05.17	Detection value of too large speed deviation	0.0% ~ 50.0%(F00.03(max. frequency))	20.0%	*
F05.18	Detection time of too large speed deviation	0.0s~60.0s	5.0s	*
F05.19	Fault auto reset times	0~20	0	*
F05.20	Time interval of fault auto reset	0.1s~100.0s	1.0s	*



Function code	Name	Description (setting range)	Factory Default	Change
F05.21	Fault protection action selection 1	Unit's digit:motor overload (E007) 0:coast to stop 1:stop according to the stop mode 2:continue to run Ten's digit :power input phase loss (E012) Hundred's digit:power output phase loss (E013) Thousand's digit:external equipment fault(E00d) Ten thousand's digit:communication fault(E018)	00000	*
F05.22	Fault protection action selection 2	Unit's digit:encoder/PG card fault(E026) 0:coast to stop Ten's digit:EEPROM read-write fault(E021) 0:coast to stop 1:stop according to the stop mode Hundred's digit: reserved Thousand's digit: motor overheat(E036) Ten thousand's digit (Accumulative running time reached)(E020)	00000	*
F05.23	Fault protection action selection 3	Unit's digit: reserved Ten's digit: reserved Hundred's digit (Accumulative power-on time reached(E029) 0: coast to stop 1: stop according to the stop mode 2: continue to run Thousand's digit: off load(E030) 0: coast to stop 1: decelerate to stop 2: continue to run at 7% of rated motor frequency and resume to the set frequency if the load recovers	00000	*



Function code	Name	Description (setting range)	Factory Default	Change
F05.23	Fault protection action selection 3	Ten thousand's digit :PID feedback lost during running (E02E) 0:coast to stop 1:stop according to the stop mode 2:continue to run	00000	*
F05.24	Fault protection action selection 4	Unit's digit :too large speed deviation (E034) 0:coast to stop 1:stop according to the stop mode 2:continue to run Ten's digit:motor over-speed (E035) Hundred's digit :initial position fault (E037)	000	*
F05.26	Frequency selection for continuing to run upon fault	0:Current running frequency 1:Set frequency 2:Frequency upper limit 3:Frequency lower limit 4:Backup frequency upon abnormality	0	*
F05.27	Current fault type	 0: No fault 1: Overcurrent during acceleration (E004) 2: Overcurrent during deceleration (E005) 3: Overcurrent at constant speed 		•
F05.28	2nd fault type	 4: Overvoltage during acceleration (E002) 5: Overvoltage during deceleration (E00A) 6: Overvoltage at constant speed (E003) 7: Undervoltage (E001) 8: Motor overload (E007) 		•
F05.29	1st fault type	9: AC drive overload (E008) 10:Power input phase loss (E012) 11: Power output phase loss (E013) 12: Module overheat (E00E)		•



Function code	Name	Description (setting range)	Factory Default	Change
		13:Buffer resistance overload (E014)		
		14: Contactor fault (E017)		
		15: External equipment fault (E00d)		
		16: Communication fault(E018)		
		17: Current detection fault (E015)		
		18: Motor auto-tuning fault (E016)		
		19: Running time reached (E020)		
		20: EEPROM read-write fault		
		(E00F)		
		21: Short circuit to ground (E023)		
		22: PID feedback lost during running (E02E)		
		23: Encoder/PG card fault(E026)	_	•
		24: AC drive hardware fault (E033)		
		25: Power-on time reached (E029)		
		26: Load becoming 0 (E030)		
		27: With-wave current limit fault (E032)		
		28: Too large speed deviation (E034)		
		29: Motor switchover fault during running (E038)		
		30: Motor over-speed (E035)		
		31: Motor overheat (E036)		
\bigcirc		32: Initial position fault (E037)		
F05.30	Frequency upon current fault		_	•
F05.31	Output current upon current fault			•
F05.32	Bus voltage upon current fault		_	•



Function code	Name	Description (setting range)	Factory Default	Change
F05.33	Input terminal status upon current fault	_	—	•
F05.34	Output terminal status upon current fault	_	_	•
F05.35	AC drive status upon current fault	_		•
F05.36	Power-on time status upon current fault	-		•
F05.37	Running time status upon current fault	-		•
F05.38	Frequency upon 2nd fault	-	_	•
F05.39	Output current upon 2nd fault	-<)	_	•
F05.40	Bus voltage upon 2nd fault		_	•
F05.41	Input terminal status upon 2nd fault	-		•
F05.42	Output terminal status upon 2nd fault	_	_	•
F05.43	AC drive status upon 2nd fault	—	_	•
F05.44	Power-on time upon 2nd fault	—	_	•
F05.45	Running time upon 2nd fault	—	_	•
F05.46	Frequency upon 1st fault	_	_	•
F05.47	Output current upon 1st fault	_	_	•
F05.48	Bus voltage upon 1st fault	_	_	•
F05.49	Input terminal status upon 1st fault	_	_	•
F05.50	Output terminal status upon 1st fault	_	_	•
F05.51	AC drive status upon 1st fault	_		•
F05.52	Power-on time upon 1st fault	_	_	•
F05.53	Running time upon 1st fault	_	_	•



Function code	Name	Description (setting range)	Factory Default	Change
F05.54	Short-circuit to ground upon power-on	0: Disabled 1: Enabled	1	•
F05.55	Output terminal action during fault auto reset	0: Not act 1: Act	0	•
F05.56	Backup frequency upon abnormality	0.0% ~ 100.0% (100.0% corresponding to maximum frequency)F00.03)	100.0%	•
F05.57	Type of motor temperature sensor	0: No temperature sensor 1: PT100 2: PT1000	0	•
F05.58	Motor overheat protection threshold	0°C ~ 200°C	100°C	•
F05.59	Motor overheat warning threshold	0°C ~ 200°C	90°C	•
F05.60	Action pause judging voltage at instantaneous power failure	F05.04 ~ 100.0%	90.0%	•
	Group	F06: Input Terminals		
F06.00	S1 terminal function selection	0: no function 1: forward run	1	•
F06.01	S2 terminal function selection	3: 3-wire operation control 4: forward jog	2	•
F06.02	S3 terminal function selection	5: reverse jog 6: coast to stop 7: fault_reset	4	•
F06.03	S4 terminal function selection	8: external fault normal open input	6	•
F06.04	S5 terminal function selection	9: UP command 10: DOWN command	12	•
F06.05	S6 terminal function selection	11: clear UP/ DOWN (terminal、keypad) 12: multi-speed terminal 1	13	•
F06.06	S7 terminal function selection	13: multi-speed terminal 2 14: multi-speed terminal 3	0	•



Function code	Name	Description (setting range)	Factory Default	Change
F06.07	S8 terminal function selection	 15: multi-speed terminal 4 16: Pause operation 17: Acc/Dec time selection 1 18: Acc/ Dec time selection 2 19: frequency source switch over 20: run command switch over terminal 21: Acceleration/Deceleration prohibited 22: PID pause 23: PLC status reset 24: swing pause 25: terminal count 26: counter reset 	0	
F06.08	S9 terminal function selection	 27: length count input 28: length reset 29: torque control prohibited 30: pulse input (enabled only for HDI) 31: reserved 32: immediate DC braking 33: Normally closed (NC) input of external fault 34: frequency modification forbidden 35: reverse PID action direction 36: external STOP terminal 1 37: command source switch over 	0	•
F06.09	HDI terminal function selection	terminal 2 38: PID integral pause 39: reserved 40: reserved 41: motor selection terminal 1 42: reserved 43: PID parameter switch over 44: reserved 45: reserved 46: speed/torque control switchover 47: emergency stop	0	•



Function code	Name	Description (setting range)	Factory Default	Change
		48: external stop terminal 249: deceleration DC braking50: clear the current runningtime		
F06.10	Input terminal valid mode selection 1	0: valid on high level 1: valid on low level units' digit: S1 tens' digit: S2 hundreds' digit: S3 thousands' digit: S4 ten thousands' digit: S5	00000	•
F06.11	Input terminal polarity selection 2	0: valid on high level 1: valid on low level units' digit: S6 tens' digit: S7 hundreds' digit: S8 thousands' digit: S9 ten thousands' digit: HDI	00000	•
F06.12	Filtering time of switch	0.000s ~ 1.000s	0.010s	*
F06.13	Terminal control operation mode	0: 2-wire control 1 1: 2-wire control 2 2: 3-wire control 1 3: 3-wire control 2	0	•
F06.14	Terminal UP/DOWN rate	0.001Hz/s ~ 65.535Hz/s	1.00Hz/s	*
F06.15	S1 delay time	0.0s~3600.0s	0.0s	•
F06.16	S2 delay time	0.0s~3600.0s	0.0s	•
F06.17	S3 delay time	0.0s~3600.0s	0.0s	•
F06.18	AI1 lower limit	0.00V ~ F06.20	0.00V	*
F06.19	Corresponding setting of AI1 lower limit	-100.0% ~ +100.0%	0.0%	*
F06.20	AI1 upper limit	F06.18~+10.00V	10.00V	*



Function code	Name	Description (setting range)	Factory Default	Change
F06.21	Corresponding setting of AI1 upper limit	-100.0% ~ +100.0%	100.0%	*
F06.22	AI1 input filter time	0.00s~10.00s	0.10s	*
F06.23	Al2 low limit	0.00V~F06.25	0.00V	*
F06.24	Corresponding setting of AI2 lower limit	-100.0% ~ + 100.0%	0.0%	*
F06.25	Ai2 upper limit	F06.23~+10.00V	10.00V	*
F06.26	Corresponding setting of Al2 upper limit	-100.0% ~ +100.0%	100.0%	*
F06.27	Ai2 input filter time	0.00s~10.00s	0.10s	*
F06.28	Ai3 lower limit	-10.00V~F06.30	0.10V	*
F06.29	Corresponding setting of AI3 lower limit	-100.0% ~ +100.0%	0	*
F06.30	Ai3 upper limit	F06.28~+10.00V	4.00V	*
F06.31	Corresponding setting of AI3 upper limit	-100.0% ~ +100.0%	100.0%	*
F06.32	Ai3 input filter time	0.00s~10.00s	0.10s	*
F06.33	HDI lower limit	0.00kHz~F06.35	0.00kHz	*
F06.34	Corresponding setting of HDI lower limit	-100.0% ~ +100.0%	0.0%	*
F06.35	HDI upper limit	F06.33~+100.00kHz	50.00kHz	*
F06.36	Corresponding setting of HDI upper limit	-100.0% ~ +100.0%	100.0%	*
F06.37	HDI frequency input filter time	0.00s~10.00s	0.10s	*
F06.38	AI curve selection	units'digit: AI curve selection 1: curve 1(2 point, see F06.18 ~ F06.21) 2: curve 2(2 point, see F06.23 ~ F06.26) 3: curve 3(2 point, see F06.28 ~ F06.31)	H.321	*



Function code	Name	Description (setting range)	Factory Default	Change
F06.38	AI curve selection	4: curve 4(4 point, see F06.40 ~ F06.47) 5: curve 5(4 point, see F06.48 ~ F06.55) tens'digit: Al2 curve selection hundreds'digit: Al3 curve selection	H.321	*
F06.39	Setting for AI less than minimum input	units'digit:(setting for AI1 less than minimum input) 0: corresponding to the minimum input set 1: 0.0% tens'digit:(setting for AI2 less than minimum input) setting selection hundreds'digit:(setting for AI3 less than minimum input)	H.000	*
F06.40	AI curve 4 lower limit	-10.00V~F06.42	0.00V	*
F06.41	AI curve 4 lower limit setting	-100.0% ~ +100.0%	0.0%	*
F06.42	Al curve 4 inflection point 1 input	F06.40 ~ F06.44	3.00V	*
F06.43	AI curve 4 inflection point 1 input setting	-100.0% ~ +100.0%	30.0%	*
F06.44	AI curve 4 inflection point 2 input	F06.42~F06.46	6.00V	*
F06.45	Al curve 4 inflection point 2 input setting	- 100.0% ~ +100.0%	60.0%	*
F06.46	Al curve 4 upper limit	F06.44~ + 10.00V	10.00V	*
F06.47	AI curve 4 upper limit setting	-100.0% ~ +100.0%	100.0%	*
F06.48	AI curve 5 lower limit	-10.00V ~ F06.50	- 10.00V	*
F06.49	AI curve 5 lower limit setting	-100.0% ~ +100.0%	- 100.0%	*



Function code	Name	Description (setting range)	Factory Default	Change
F06.50	AI curve 5 inflection point 1 input	F06.48 ~ F06.52	- 3.00V	*
F06.51	AI curve 5 inflection point 1 setting	-100.0% ~ +100.0%	- 30.0%	*
F06.52	Al curve 5 inflection point 2 input	F06.50 ~ F06.54	3.00V	*
F06.53	Al curve 5 inflection point 2 setting	-100.0% ~ +100.0%	30.0%	*
F06.54	AI curve 5 upper limit	F06.52~ +10.00V	10.00V	*
F06.55	AI curve 5 upper limit setting	-100.0% ~ +100.0%	100.0%	*
F06.64	AI1 jump point setting	-100.0% ~ 100.0%	0.0%	*
F06.65	AI1 jump point range setting	0.0% ~ 100.0%	0.5%	*
F06.66	AI2 jump point setting	-100.0% ~ 100.0%	0.0%	*
F06.67	Al2 jump point range setting	0.0% ~ 100.0%	0.5%	*
F06.68	AI3 jump point setting	-100.0% ~ 100.0%	0.0%	*
F06.69	AI3 jump point range setting	0.0% ~ 100.0%	0.5%	*
	Group F0	7: Output Terminals		
F07.00	HDO terminal output mode	0: Pulse output (HDOP) 1: Switch signal output(HDOR)	0	*
F07.01	HDOR output selection	0: no output 1: freuency reached	0	*
F07.02	Relay TA output selection(TA* TB* TC)	2: trequency-level detection FDT1 output 3: fault output (stop)	3	*
F07.03	Relay RA output selection(RA* RB* RC)	4: motor overload pre- warning	0	*
F07.04	Mo1 output selection	5: AC drive overload pre- warning	1	*



Function code	Name	Description (setting range)	Factory Default	Change
		6: zero-speed running (no output at stop)		
		7: zero-speed running 2(no output at stop)		
		8: frequency upper limit reached		
		9: frequency lower limit reached(no output		
		at stop)		
		10: set count value reached		
		11: designated count value reached		
		12: length reached		
		13: PLC cycle complete		
		14: accumulative running time reached		
		15: frequency limited		
		16: torque limited		
		17: ready for RUN		
		18: AC drive running		
		19: AI1>AI2		
		20: undervoltage state output	0	*
		22: reserved		
		23: reserved		
		24: accumulative power-on time reached		
		25: Frequency level detection FDT2 output		
		26: frequency 1 reached		
		27: frequency 2 reached		
		28: current 1 reached		
		29: current 2 reached		
		30: timing reached		
		31: AI1 input limit exceeded		
		32: load becoming 0		
		33: reverse running		
		34: zero current state		
		35: module temperature reached		
		36: output current limit exceeded		

Function code	Name	Description (setting range)	Factory Default	Change
		37: Frequency lower limitreached (having output at stop)38: Alarm output (keep running)39: motor overheat warning40: current running timereached	0	*
F07.06	Output terminal valid mode selection	0: Positive logic 1: Negative logic Unit's digit: HDO Ten's digit:TA Hundred's digit: RA Thousand's digit: MO1	0000	*
F07.07	HDO delay time	0.0s~3600.0s	0.0s	*
F07.08	TA delay time	0.0s~3600.0s	0.0s	*
F07.09	RA delay time	0.0s~3600.0s	0.0s	*
F07.10	Mo1 output delay time	0.0s~3600.0s	0.0s	*
F07.12	HDOP output selection	0: setting frequency 1: running frequency 2: output current 3: output voltage 4: output speed 5: output torque	0	*
F07.13	Ao1 output selection	6: output power 7: Pulse input (100% corresponding to 100.0kHz) 8: Al1 9: Al2 10: Al3	0	*
F07.14	Ao2 output selection	11: lenth 12: count value 13: RS485 communication 14: output current (100.0% corresponding to 1000.0A)	1	*

www.peacosupport.com sales@peacosupport.com Free Shipping Worldwide Reliable Supplier

Function code	Name	Description (setting range)	Factory Default	Change
		15: output voltage (100.0% corresponding to 1000.0V) 16: reserved		
F07.15	AO1 offset coefficient	-100.0% ~ 100.0%	0.0%	*
F07.16	AO1 gain	-10.00~+10.00	1.00	*
F07.17	AO2 offset coefficient	-100.0% ~ 100.0%	0.0%	*
F07.18	AO2 gain	-10.00 ~ +10.00	1.00	*
F07.19	AO1 output filter time	0~10.00	0	*
F07.20	AO2 output filter time	0~10.00	0	*
F07.21	HDO output filter time	0~10.00	0	*
F07.22	HDO output max.frequency	0.01kHz~100.00kHz	50.00kHz	*
	Group	F08: Keypad And Display		
F08.00	User password	0~65535	0	*
F08.02	STOP key function selection	0: STOP/RST key enabled only in keypad control 1: STOP/RST key enabled in any operation mode	1	*
F08.03	LED display running parameters 1	0000-FFFF Bit00: running frequency 1(Hz) Bit01: set frequency (Hz) Bit02: output current (A) Bit03: output voltage (V) Bit04: load speed display Bit05: output power (kW) Bit06: output torque (%) Bit07: bus voltage (V) Bit08: PID setting Bit09: PID feedback value Bit10: input terminal status Bit11: output terminal status Bit12: Al1 voltage (V)	H.008F	*

Factory

Default

H 0063

- 1.0000

₩

Ж

Change

₩

≫



Name

LED display

stop

parameters

Load speed

display

coefficient

F08.05

F08.06

Function

code

		Bit13: Al2 Voltage (V) Bit14: Al3 voltage (V) Bit15: count value		
F08.04	LED display running parameters 2	0000-FFFF Bit00: length value Bit01: PLC stage Bit02: pulse setting frequency(kHz) Bit03: running frequency 2 (Hz) Bit04: remaining running time Bit05: Al1 voltage before correction (V) Bit06: Al2 voltage before correction (V) Bit07: Al3 voltage before correction (V) Bit08: linear speed Bit09: current power-on time(Hour) Bit11: pulse setting frequency(Hz) Bit12: Rs485 communication setting value Bit13: encoder feedback speed(Hz) Bit14: main frequency A display(Hz) Bit15: auxiliary frequency B display (Hz)	Н.0000	
		0000-FFFF Bit00: set frequency (Hz) Bit01: bus voltage (V) Bit02: input terminal status Bit03: output terminal status Bit04: PID setting		

Bit05: Al1 voltage (V) Bit06: Al2 voltage (V)

Bit07: AI3 voltage (V)

Bit08: Count value Bit09: Length value Bit10: PLC stage Bit11: Load speed

0.0001 ~ 6.5000

Description

(setting range)

Bit12: Pulse setting frequency (kHz) Bit13: PID feedback value



Function code	Name	Description (setting range)	Factory Default	Change
F08.07	Auxiliary LED display selection	0: Operating frequency 1: Set frequency 2: Output current 3: Output voltage 4: Load speed display 5: Output power 6: Output torque 7: Bus voltage 8: PID setting 9: PID feedback 10: DI input status 11: DO output status 12: AI1 voltage 13: AI2 voltage 14: AI3 voltage 15: Count value 16: Length value	2	*
F08.08	Heatsink temperature of inverter module	0.0°C ~ 100.0°C	_	**
F08.09	Software version		—	**
F08.10	Accumulative running time	0h~65535h	_	**
F08.11	Product number	—	_	**
F08.12	Number of decimal places for load speed display	0: 0 decimal place1: 1 decimal place2: 2 decimal places3: 3 decimal places	1	*
F08.13	Accumulative power-on time	0h ~ 65535h	_	**
F08.14	Accumulative power consumption	0–65535 kWh	_	**
	Group F09: A	uxiliary Functions		
F09.00	Acceleration time 2	0.0s~6500.0s	Model dependent	*
F09.01	Deceleration time 2	0.0s~6500.0s	Model dependent	*
F09.02	Acceleration time 3	0.0s~6500.0s	Model dependent	*
F09.03	Deceleration time 3	0.0s~6500.0s	Model dependent	*
F09.04	Acceleration time 4	0.0s~6500.0s	Model dependent	*

-70-



Function code	Name	Description (setting range)	Factory Default	Change
F09.05	Deceleration time 4	0.0s~6500.0s	Model dependent	*
F09.06	JOG running frequency	0.00Hz ~ F00.03(max. frequency)	2.00Hz	*
F09.07	JOG acceleration time	0.0s~6500.0s	20.0s	*
F09.08	JOG deceleration time	0.0s~6500.0s	20.0s	*
F09.09	Jump frequency 1	0.00Hz ~ F00.03(max. frequency)	0.00Hz	*
F09.10	Jump frequency 2	0.00Hz ~ F00.03(max. frequency)	0.00Hz	*
F09.11	Frequency jump amplitude	0.00Hz ~ F00.03(max. frequency)	0.00Hz	*
F09.12	Forward/Reverse rotation dead-zone time	0.0s~3000.0s	0.0s	*
F09.13	Reverse control	0: enabled 1: disabled	0	*
F09.14	Running mode when set frequency lower than frequency lower limit	0:run at frequency lower limit 1: stop 2: run at zero speed	0	*
F09.15	Accumulative power-on time threshold	0.0s~6500.0s	0h	*
F09.16	Accumulative running time threshold	0.0s~6500.0s	0h	*
F09.17	Startup protection	0: No 1: Yes	0	*
F09.18	Droop control	0.00Hz ~ 10.00Hz	0.00Hz	*
F09.19	Motor switchover	0: Motor 1 1: Motor 2	0	•
F09.20	Frequency detection value(FDT1)	0.00Hz ~ F00.03(max. frequency)	50.00Hz	*
F09.21	Frequency detection hysteresis (FDT hysteresis 1)	0.0% ~ 100.0% (FDT1 level)	5.0%	*
F09.22	Frequency detection value(FDT2)	0.00Hz ~ F00.03(max. frequency)	50.00Hz	*
F09.23	Frequency detection hysteresis (FDT hysteresis 2)	0.0% ~ 100.0%(FDT2 level)	5.0%	*


Function code	Name	Description (setting range)	Factory Default	Change
F09.24	Detection range of frequency reached	0.0% ~ 100.0%(F00.03 (max. frequency))	0.0%	*
F09.25	Jump frequency during acceleration/deceleration	0: disabled 1: enabled	0	*
F09.28	Frequency switchover point between acceleration time 1 and acceleration time 2	0.00Hz~F00.03(max. frequency)	0.00Hz	*
F09.29	Frequency switchover point between deceleration time 1 and deceleration time 2	0.00Hz ~ F00.03(max. frequency)	0.00Hz	*
F09.30	Terminal JOG preferred	0: disabled 1: enabled	0	*
F09.31	Any frequency reaching detection value 1	0.00Hz~F00.03(max. frequency)	50.00Hz	*
F09.32	Any frequency reaching detection amplitude 1	0.0% ~ 100.0%(F00.03(max. frequency)	0.0%	*
F09.33	Any frequency reaching detection value 2	0.00Hz ~ F00.03(max. frequency)	50.00Hz	*
F09.34	Any frequency reaching detection amplitude 2	0.0% ~ 100.0%(F00.03(max. frequency)	0.0%	*
F09.35	Zero current detection level	0.0% ~ 300.0%(rated motor current)	5.0%	*
F09.36	Zero current detection delay time	0.01s~600.00s	0.10s	*
F09.37	Output overcurrent threshold	1.1% (no detection) 1.2%–300.0% (rated motor current)	200.0%	*
F09.38	Output overcurrent detectio delay time	0.00s~600.00s	0.00s	*
F09.39	Any current reaching 1	0.0% ~ 300.0% ((rated motor current)	100.0%	*
F09.40	Any current reaching 1 amplitude	0.0% ~ 300.0% (rated motor current)	0.0%	*
F09.41	Any current reaching 2	0.0% ~ 300.0% (rated motor current)	100.0%	*
F09.42	Any current reaching 2 amplitude	0.0% ~ 300.0% (rated motor current)	0.0%	*

-72-



Function code	Name	Description (setting range)	Factory Default	Change
F09.43	Timing function	0: Disabled 1: Enabled	0	*
F09.44	Timing duration source	0: F09.45 1: analog Al1 2: analog Al2 3: analog Al3 (Analog input range corresponds to F09.45)	0	*
F09.45	Timing duration	0.0Min ~ 6500.0Min	0.0Min	*
F09.46	Al1 input voltage lower limit	0.00V~F09.47	3.10V	*
F09.47	Al1 input voltage upper limit	F09.46~10.00V	6.80V	*
F09.48	Module temperature threshold	0°C ~ 100°C	75°C	*
F09.49	Cooling fan control	0: Fan working during running 1: Fan working continuously	0	*
F09.50	Wake up pressure	0.0~F10.04 (PID given feedback range)	0.0	*
F09.51	Wake up delay time	0.0s~6500.0s	0.0s	*
F09.52	Dormant frequency	0.0Hz~F00.3 (maximum frequency)	0.00Hz	*
F09.53	Dormant delay time	0.0s~6500.0s	0.0s	*
F09.54	Current running time reached	0.0Min ~ 6500.0Min	0.0Min	*
F09.55	DPWM switchover running frequency upper limit	0.00Hz ~ 15.00Hz	12.00Hz	*
F09.56	PWM modulation system	0: asynchronous modulation 1: synchronous modulation	0	*
F09.57	Dead zone compensation mode selection	0: no compensation 1: compensation mode 1 2: compensation mode 2	1	*



Function code	Name	Description (setting range)	Factory Default	Change
F09.58	Depth of PWM random	0: PWM random disabled 1 ~ 10: PWM carrier frequen-cy random depth	0	*
F09.59	Rapid current limit	0: Disabled 1: Enabled	1	*
F09.60	Current detection compensation	0~100	5	*
F09.61	Under-voltage point	60.0% ~ 140.0%	100.0%	*
F09.62	SVC optimize mode selection	0: no optimize 1: optimize mode 1 2: optimize mode 2	1	*
F09.63	Dead-zone time adjustment	100% ~ 200%	150%	*
F09.64	Over-voltage point	200.0V~2500.0V	Model dependent	*
	Group F10: F	Process Control PID Function		
F10.00	PID setting source	0: Keypad (F10.01) 1: Analog Al1 2: Analog Al2 3: Analog Al3 4: Pulse setting (HDI) 5: Rs485 communication setting 6: Multi-speed command 7:Panel potentiometer setting	0	*
F10.01	Keyboard preset PID given	0.0~F10.04 (PID given feedback range)	5.0	*
F10.02	PID feedback source	0: Al1 1: Al2 2: Al3 3: Al1–Al2 4: Pulse setting(HDI) 5: Rs485 communication setting 6: Al1 + Al2 7: MAX (Al1 , Al2) 8: MIN (Al1 , Al2)	0	*



Function code	Name	Description (setting range)	Factory Default	Change
F10.03	PID output characteristic selection	0: PID output is positive characteristic 1: PID output is negative characteristic	0	*
F10.04	PID setting feedback range	0.0 ~ 1000.0	10.0	*
F10.05	Proportional gain Kp1	0.0 ~ 100.0	20.0	*
F10.06	Integral time Ti1	0.01s~10.00s	2.00s	*
F10.07	Differential time Td1	0.000s~10.000s	0.000s	*
F10.08	Cut-off frequency of PID reverse rotation	0.00 ~ F00.03(maximum frequency)	0.00Hz	*
F10.09	PID deviation limit	0.0% ~ 100.0%	0.0%	*
F10.10	PID differential limit	0.00% ~ 100.00%	0.10%	*
F10.11	PID setting change time	0.00~650.00s	0.00s	*
F10.12	PID feedback filter time	0.00~60.00s	0.00s	*
F10.13	PID output filter time	0.00~60.00s	0.00s	*
F10.15	Proportional gain Kp2	0.0 ~ 100.0	20.0	*
F10.16	Integral time Ti2	0.01s~10.00s	2.00s	*
F10.17	Differential time Td2	0.000s~10.000s	0.000s	*
F10.18	PID parameter switchover condition	0: No switchover1: Switchover via input terminal2: Automatic switchover based on deviation	0	*
F10.19	PID parameter switchover deviation 1	0.0% ~ F10.20	20.0%	*
F10.20	PID parameter switchover deviation 2	F10.19~100.0%	80.0%	*
F10.21	PID initial value	0.0% ~ 100.0%	0.0%	*
F10.22	PID initial value holding time	0.00~650.00s	0.00s	*
F10.23	Maximum deviation between two PID outputs in forward direction	0.00% ~ 100.00%	1.00%	*



Function code	Name	Description (setting range)	Factory Default	Change
F10.24	Maximum deviation between two PID outputs in reverse direction	0.00% ~ 100.00%	1.00%	*
F10.25	PID integral property	Unit's digit :Integral separated 0: Invalid 1: Valid Ten's digit :Whether to stop integral operation when the output reaches the limit 0: Continue integral operation 1: Stop integral operation	00	*
F10.26	Detection value of PID feedback loss	0.0%: Not judging feedback loss 0.1%–100.0%	0.0%	*
F10.27	Detection time of PID feedback loss	0.0s~20.0s	0.0s	*
F10.28	PID operation at stop	0: No PID operation at stop 1: PID operation at stop	0	*
	Group F11: Swing Fre	quency, Fixed Length and	Count	
F11.00	Swing frequency setting mode	0: Relative to the central frequency 1: Relative to the maximum frequency	0	*
F11.01	Swing frequency amplitude	0.0% ~ 100.0%	0.0%	*
F11.02	Jump frequency amplitude	0.0% ~ 50.0%	0.0%	*
F11.03	Swing frequency cycle	0.1s~3000.0s	10.0s	*
F11.04	Triangular wave rising time coefficient	0.1% ~ 100.0%	50.0%	*
F11.05	Set length	0m ~ 65535m	1000m	*
F11.06	Actual length	0m~65535m	0m	*



Function code	Name	Description (setting range)	Factory Default	Change
F11.07	Number of pulses per meter	0.1~6553.5	100.0	*
F11.08	Set count value	1~65535	1000	*
F11.09	Designated count value	1~65535	1000	*
	Group F12: Simple PLC	Function And Multi-speed	control	
F12.00	Simple PLC running mode	0: Stop after the AC drive runs one cycle 1: Keep final values after the AC drive runs one cycle 2: Repeat after the AC drive runs one cycle	0	*
F12.01	Simple PLC retentive selection	Unit's digit: Retentive upon power failure 0: No 1: Yes Ten's digit: Retentive upon stop 0: No 1: Yes	00	*
F12.02	Multi-speed 0	-100.0% ~ 100.0%	0.0%	*
F12.03	Multi-speed 1	-100.0% ~ 100.0%	0.0%	*
F12.04	Multi-speed 2	-100.0% ~ 100.0%	0.0%	*
F12.05	Multi-speed 3	-100.0% ~ 100.0%	0.0%	*
F12.06	Multi-speed 4	-100.0% ~ 100.0%	0.0%	*
F12.07	Multi-speed 5	-100.0% ~ 100.0%	0.0%	*
F12.08	Multi-speed 6	-100.0% ~ 100.0%	0.0%	*
F12.09	Multi-speed 7	-100.0% ~ 100.0%	0.0%	*
F12.10	Multi-speed 8	-100.0% ~ 100.0%	0.0%	*
F12.11	Multi-speed 9	-100.0% ~ 100.0%	0.0%	*
F12.12	Multi-speed 10	-100.0% ~ 100.0%	0.0%	*
F12.13	Multi-speed 11	-100.0% ~ 100.0%	0.0%	*



Function code	Name	Description (setting range)	Factory Default	Change
F12.14	Multi-speed 12	-100.0% ~ 100.0%	0.0%	*
F12.15	Multi-speed 13	-100.0% ~ 100.0%	0.0%	*
F12.16	Multi-speed 14	-100.0% ~ 100.0%	0.0%	*
F12.17	Multi-speed 15	-100.0% ~ 100.0%	0.0%	*
F12.18	Running time of simple PLC multi-speed 0	0.0s(h) ~ 6500.0s(h)	0.0s(h)	*
F12.19	Acceleration/deceleration time of simple PLC multi- speed 0	0~3	0	*
F12.20	Running time of simple PLC multi-speed 1	0.0s(h) ~ 6500.0s(h)	0.0s(h)	*
F12.21	Acceleration/deceleration time of simple PLC multi- speed 1	0~3	0	*
F12.22	Running time of simple PLC multi-speed 2	0.0s(h) ~ 6500.0s(h)	0.0s(h)	*
F12.23	Acceleration/deceleration time of simple PLC multi- speed 2	0~3	0	*
F12.24	Running time of simple PLC multi-speed 3	0.0s(h) ~ 6500.0s(h)	0.0s(h)	*
F12.25	Acceleration/deceleration time of simple PLC multi- speed 3	0~3	0	*
F12.26	Running time of simple PLC multi-speed 4	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.27	Acceleration/deceleration time of simple PLC multi- speed 4	0~3	0	*
F12.28	Running time of simple PLC multi-speed 5	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.29	Acceleration/deceleration time of simple PLC multi- speed 5	0~3	0	*



Function code	Name	Description (setting range)	Factory Default	Change
F12.30	Running time of simple PLC multi-speed 6	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.31	Acceleration/deceleration time of simple PLC multi- speed 6	0~3	0	*
F12.32	Running time of simple PLC multi-speed 7	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.33	Acceleration/deceleration time of simple PLC multi- speed 7	0~3	0	*
F12.34	Running time of simple PLC multi-speed 8	0.0s(h) ~ 6500.0s(h)	0.0s(h)	*
F12.35	Acceleration/deceleration time of simple PLC multi- speed 8	0~3	0	*
F12.36	Running time of simple PLC multi-speed 9	0.0s(h) ~ 6500.0s(h)	0.0s(h)	*
F12.37	Acceleration/deceleration time of simple PLC multi- speed 9	0~3	0	*
F12.38	Running time of simple PLC multi-speed 10	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.39	Acceleration/deceleration time of simple PLC multi- speed 10	0~3	0	*
F12.40	Running time of simple PLC multi-speed 11	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.41	Acceleration/deceleration time of simple PLC multi- speed 11	0~3	0	*
F12.42	Running time of simple PLC multi-speed 12	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.43	Acceleration/deceleration time of simple PLC multi- speed 12	0~3	0	*



Function code	Name	Description (setting range)	Factory Default	Change
F12.44	Running time of simple PLC multi-speed 13	0.0s(h) ~ 6500.0s(h)	0.0s(h)	*
F12.45	Acceleration/deceleratio n time of simple PLC multi-speed 13	0~3	0	*
F12.46	Running time of simple PLC multi-speed 14	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.47	Acceleration/deceleratio n time of simple PLC multi-speed 14	0~3	0	*
F12.48	Running time of simple PLC multi-speed 15	0.0s(h) ~ 6500.0s(h)	0.0s(h)	*
F12.49	Acceleration/deceleratio n time of simple PLC multi-speed 15	0~3	0	*
F12.50	Time unit of multi-speed	0: s (second) 1:h (hour)	0	*
F12.51	Multi-speed 0 source	0: Set by F12.02 1: Al1 2: Al2 3: Al3 4: Pulse setting 5: PID 6: Set frequency via keypad(F00.10),modified UP/DOWN 7: Panel potentiometer setting	0	*
	Group F13: C	ommunication Parameters		
F13.00	Local communication address	1~247,0-bit broadcast address	1	*
F13.01	Data format	0: 300BPS 1: 600BPS 2: 1200BPS 3: 2400BPS 4: 4800BPS	5	*



Function code	Name	Description (setting range)	Factory Default	Change
	Data format	5: 9600BPS 6: 19200BPS 7: 38400BPS 8: 57600BPS 9: 115200BPS		
F13.02	Data format	0: No check, data format <8,N,2> 1: Even parity check, data format <8,E,1 2: Odd Parity check, data format <8,O,1> 3: Data format <8,N,1>	0	*
F13.03	Response delay	0ms ~ 20ms	20	*
F13.04	Communication timeout	0.0(invalid),0.1s~60.0s	0.0	*
F13.05	Modbus protocol selection	0: Non-standard Modbus protocol 1: Standard Modbus protocol	0	*
F13.06	Communication reading current resolution	0: 0.01A 1: 0.1A	0	*
	Group F1	5: Motor 2 Parameters		
F15.00	Motor type selection	0: Common asynchronous motor 1: Variable frequency asynchronous motor	0	•
F15.01	Rated motor power	0.1kW ~ 1000.0kW	Model dependent	•
F15.02	Rated motor frequency	0.01Hz ~ F00.03(maximum frequency)	Model dependent	•
F15.03	Rated motor rotational speed	1rpm ~ 65535rpm	Model dependent	•
F15.04	Rated motor voltage	1V~2000V	Model dependent	•
F15.05	Rated motor current	0.01A ~ 655.35A (AC drive power≤ 55kW) 0.1A ~ 6553.5A (AC drive power> 55kW)	Model dependent	•



Function code	Name	Description (setting range)	Factory Default	Change
F15.06	Stator resistance	0.001Ω ~ 65.535Ω (AC drive power≤ 55kW) 0.0001Ω ~ 6.5535Ω (AC drive power> 55kW)	Model dependent	•
F15.07	Rotor resistance	0.001Ω ~ 65.535Ω (AC drive power≤ 55kW) 0.0001Ω ~ 6.5535Ω (AC drive power> 55kW)	Model dependent	•
F15.08	Leakage inductive reactance	0.01mH ~ 655.35mH (AC drive power≤ 55kW) 0.001mH ~ 65.535mH (AC drive power> 55kW)	Model dependent	•
F15.09	Mutual inductive reactance	0.1mH ~ 6553.5mH (AC drive power≤ 55kW) 0.01mH ~ 655.35mH (AC drive power> 55kW)	Model dependent	•
F15.10	No-load current	0.01A ~ F15.05 (AC drive power≤ 55kW) 0.1A ~ F15.05 (AC drive power> 55kW)	Model dependent	•
F15.27	Encoder type	0: ABZ incremental encoder 1: UVW incremental encoder	0	•
F15.28	PG card selection	0: QEP1	0	•
F15.29	Encoder pulses per revolution	1 ~ 65535	2500	
F15.30	A, B phase sequence of ABZ incremental encoder	0: Forward 1: Reverse	0	•
F15.31	Encoder installation angle	0.0~359.9°	0.0°	•
F15.32	U, V, W phase sequence of UVW encoder	0: Forward 1: Reverse	0	•
F15.33	UVW encoder angle offset	0.0~359.9°	0.0°	•

-82-



Function code	Name	Description (setting range)	Factory Default	Change
F15.36	Speed feedback PG disc- onnection detection time	0.0: No action 0.1s ~ 10.0s	0.0	•
F15.37	Self-learning selection	0: No self-learning 1: Asynchronous motor static self-learning 2: Asynchronous motor dynamic self-learning	0	•
F15.38	Speed loop proportional gain 1	1~100	30	*
F15.39	Speed loop integral time 1	0.01s~10.00s	0.50s	*
F15.40	Switch low frequency	0.00 ~ F15.43	5.00Hz	*
F15.41	Speed loop proportional gain 2	1~100	20	*
F15.42	Speed loop integral time 2	0.01s~10.00s	1.00s	*
F15.43	Switch high frequency	F15.40 ~ F00.03(maxi- mum frequency)	10.00Hz	*
F15.44	Vector control slip gain	50%~200%	100%	*
F15.45	Time constant of speed loop filter	0.000s ~ 0.100s	0.000s	*
F15.46	Vector control overexcitation gain	0~200	64	*
F15.47	Torque upper limit source in speed control mode	0: F15.48 1: Al1 2: Al2 3: Al3 4: Pulse setting (HDI) 5: Rs485 communication 6: MIN(Al1,Al2) 7: MIN(Al1,Al2) (The full scale of options 1-7 corresponds to the digital setting of F15.48)	0	*
F15.48	Digital setting of torque upper limit in speed control mode	0.0% ~ 200.0%	150.0%	*



Function code	Name	Description (setting range)	Factory Default	Change
F15.51	Excitation adjustment proportional gain	0~60000	2000	*
F15.52	Excitation adjustment integral gain	0~60000	1300	*
F15.53	Torque adjustment proportional gain	0~60000	2000	*
F15.54	Torque adjustment integral gain	0~60000	1300	*
F15.55	Speed loop integral property	Unit's digit: Integral separated 0: Disabled 1: Enabled	0	*
F15.61	Motor 2 control mode	0: non- PG vector control 1:PG vector control 2: V/F control	0	•
F15.62	Motor 2 acceleration/ deceleration time	0: Same as motor 1 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	*
F15.63	Motor 2 torque boost	0.0%: Automatic torque boost 0.1%–30.0%	Model dependent	*
F15.55	Motor 2 oscillation suppression gain	0~100	Model dependent	*



Peaco Support FC280 Series VFD User Manual



Description of Function Codes

F00	Standard Function Parameters	
F01	Standard Function Parameters	98
F02	Motor 1 Parameters	104
F03	Vector Control Parameters	108
F04	V/F Control Parameters	114
F05	Fault and Protection	120
F06	Input Terminals	131
F07	Output Terminals	146
F08	Keypad And Display	152
F09	Auxiliary Functions	157
F10	Process Control PID Function	172
F11	Swing Frequency, Fixed Length and Count	
F12	Simple PLC Function And Multi-speed control	183
F13	Communication Parameters	188
F15	Motor 2 Parameters	190



Group F00: Standard Function Parameters

Function code	Name	Description (setting range)	Factory Default	Change
F00.00	Speed control mode	0: non-PG vector control (SVC) 1: PG vector control (FVC) 2: V/F control	2	•

0: non- PG vector control (SVC)

It indicates open-loop vector control, and is applicable to high-performance control applications without encoder such as machine tool, centrifuge, wire drawing machine and injection moulding machine. One AC drive can operate only one motor.

1: PG vector control (FVC)

It is applicable to high-accuracy speed control or torque control applications such as highspeed paper making machine, crane and elevator. One AC drive can operate only one motor. An encoder must be installed at the motor side, and a PG card matching the encoder must be installed at the AC drive side.

2: V/F control

It is applicable to applications with low load requirements or applications where one AC drive operates multiple motors, such as fan and pump.

Note: If vector control is used, motor self-learning must be performed because the advantages of vector control can only be utilized after correct motor parameters are obtained.Better performance can be achieved by adjusting speed regulator parameters in group F03 (or groups F15 for motor 2).

Function code	Name	Description (setting range)	Factory Default	Change
F00.01	Command source selection	0:keypad control 1:terminal control 2:RS 485 communication control	0	*

It is used to determine the input channel of the AC drive control commands, such as run, stop, forward rotation, reverse rotation and jog operation. You can input the commands in the following three channels:

0: keypad control

Commands are given by pressing keys RUN,STOP/RES on the keypad.

1: terminal control

Commands are given by means of multifunctional input terminals with functions such as FWD, REV, forward JOG, and reverse JOG.



2:RS485 communication control

Commands are given from host computer. Refer to Group F13: Communication Parameters for parameters.

Function code	Name	Description (setting range)	Factory Default	Change
F00.03	Max.output frequency	50.00Hz ~ 600.00Hz	50.00Hz	•

It is used to set the maximum output frequency of the inverter. It is the basis of the frequency setting, as well as the foundation of acceleration and deceleration speed. Please pay attention.

When analog input,pulse input(HDI),multiple command as frequency source of FC280, it 100% corresponding to F00.03.

Function code	Name	Description (setting range)	Factory Default	Change
F00.04	Run frequency upper limit	F00.05 ~ F00.03(max.frequency)	50.00Hz	*

Upper limit of the inverter's output frequency. The value should be less than or equal to the maximum output frequency.

Function code	Name	Description (setting range)	Factory Default	Change
F00.05	Run frequency lower limit	0.00Hz ~ F00.04(run frequency upper limit)	00.00Hz	*

Lower limit of the inverter's output frequency.

When the set frequency is lower than the lower limit frequency:When the starting set frequency cy is lower than the lower limit of frequency, it can not be started.When the set frequency entering the running frequency is lower than the lower limit frequency,AC drive can stop,run as frequency lower limit or zero speed via F09.14.

Function code	Name	Description (setting range)	Factory Default	Change
F00.06	Frequency A command selection	0:keypad, no retentive upon power failure 1:keypad, retentive upon power failure	0	•

Function code	Name	Description (setting range)	Factory Default	Change
F00.06	Frequency A command selection	2:analog Al1 3:analog Al2 4:analog Ai3 5:pulse(HDI) 6:multi-speed running 7:simple PLC 8:PID control 9:RS485 Communication 10:potentiometer	0	

It is used to select the setting channel of the main frequency. You can set the main frequency in the following 10 channels:

0: keypad, non-retentive at power failure

The initial value of the set frequency is the value of F00.10 (Preset frequency). You can change the set frequency by pressing \land and \lor on the operation panel (or using the UP/DOWN function of input terminals).

When the AC drive is powered on again after power failure, the set frequency reverts to the value of F00.10.

1: keypad, retentive at power failure

The initial value of the set frequency is the value of F00.10 (Preset frequency). You can change the set frequency by pressing keys \land and \lor on the operation panel (or using the UP/D-OWN function of input terminals).

When the AC drive is powered on again after power failure, the set frequency is the value memorized at the moment of the last power failure.

Note that F00.26 (Retentive of digital setting frequency upon power failure) determines whether the set frequency is memorized or cleared when the AC drive stops. It is related to stop rather than power failure.

2: Al1 (0–10 V voltage input or 0–20 mA current input, determined by jumper)

3: Al2 (0–10 V voltage input or 0–20 mA current input, determined by jumper)

4: AI3 (-10-10 V voltage input)

The frequency is set by analog input. The control board provides three analog input (AI) terminals (AI1, Ai2).

The provides five curves indicating the mapping relationship between the input voltage of Al1, Al2 and Al3 and the target frequency, three of which are linear (pointpoint)correspondence and two of which are four-point correspondence curves. You can set the curves by using function codes F06 and select curves for Al1, Al2 and Al3 in F06.38.



When AI is used as the frequency setting source, the corresponding value 100% of the voltage/current input corresponds to the value of F06.

5: Pulse setting (HDI)

The frequency given is given by the terminal pulse. Pulse given signal specifications: voltage range 9V~26V, frequency range 0kHz~100kHz. Pulse given can only be input from the multifunction input terminal HDI. The relationship between the input pulse frequency of the HDI terminal and the corresponding setting is set through F06.33~F06.36. The corresponding relationship is a straight line corresponding relationship between 2 points. The 100.0% set corresponding to the pulse input is relative to the maximum frequency F00.03 percent.

6: Multi-reference

In multi-reference mode, combinations of different input terminal states correspond to different set frequencies by setting F06 and F12. The supports a maximum of 16 speeds implemented by 16 state combinations of four terminals in Group F12.

The multiple references indicate percentages of the value of F00.03 (Maximum frequency).

If a S terminal is used for the multi-reference function, you need to perform related setting in group F06.

7: Simple PLC

When the simple programmable logic controller (PLC) mode is used as the frequency source, the running frequency of the AC drive can be switched over among the 16 frequency references. You can set the holding time and acceleration/deceleration time of the 16 frequency references. For details, refer to the descriptions of Group F12.

8: PID

The output of PID control is used as the running frequency. PID control is generally used in on-site closed-loop control, such as constant pressure closed-loop control and constant tension closed-loop control.

When applying PID as the frequency source, you need to set parameters of PID function in group F10.

9: Communication setting

The main frequency source is set by means of communication.For details,see the description of Appendix A Serial Communications.

10: Potentiometer

The frequency is set by potentiometer.

Function code	Name	Description (setting range)	Factory Default	Change
F00.07	Frequency B command selection	Same as F00.06	0	•



When used as an independent frequency input channel (frequency source switched over from A to B), the auxiliary frequency source B is used in the same way as the main frequency source A (refer to F00.06).

When the auxiliary frequency source is used for operation (frequency source is "A+B operation"), pay attention to the following aspects:

1) If the auxiliary frequency source B is keypad setting, the preset frequency (F00.10) does not take effect. You can directly adjust the set main frequency by pressing keys \land and \lor on the operation panel (or using the UP/DOWN function of input terminals).

2) If the auxiliary frequency source B is analog input (Al1, Al2 and Al3) or pulse setting, 100% of the input corresponds to the range of the auxiliary frequency B (set in F00.08 and F00.23).

3) If the auxiliary frequency source B is pulse setting, it is similar to analog input.

NOTE: The main frequency source A and auxiliary frequency source B must not use the same channel.That is, F00.06 and F00.07 cannot be set to the same value.

Function code	Name	Description (setting range)	Factory Default	Change
F00.08	Range of frequency B command	0: relative to maximum frequency 1: relative to frequency A	0	*
	selection	command		

You can set the auxiliary frequency to be relative to either maximum frequency or main frequency A. If relative to main frequency A, the setting range of the auxiliary frequency B varies according to the main frequency A.

Function code	Name	Description (setting range)	Factory Default	Change
F00.09	Frequency source combination mode	0: frequency A command 1: frequency B command 2:switchover between frequency A command and frequency B command 3: A+B 4: A-B 5:MAX (A and B) 6: MIN (Aand B	0	*



It is used o select the frequency setting channel. If the frequency source involves Aan d B operation, you can set the frequency offset in F00.25 for superposition to the A and B operation result, flexibly satisfying various requirements.

0: Frequency A command

Frequency A as target frequency.

1: Frequency B command

Frequency A as target frequency.

2: Switchover between frequency A command and frequency B command

If multi-function input terminal 18 is invalid, frequency A is target frequency; If multifunction input terminal 18 is valid, frequency B is target frequency.

3: A+B

It's frequency superposition that both A and B as target frequency.

4: A-B

Target frequency is difference value of A-B.

5: MAX (A and B)

Target frequency is Max.absolute value.

6: MIN (A and B)

Take the A frequency command and the B frequency command with the smallest absolute value as the target frequency. In addition, when the frequency source is the main and auxiliary operation, the offset frequency can be set through F00.25, and the offset frequency is superimposed on the main and auxiliary operation results to flexibly respond to various needs.

Function code	Name	Description (setting range)	Factory Default	Change
F00.10	Keypad setting	0.00Hz~F00.03 (max.	50 00Hz	*
	frequency	frequency)	50.00112	

If the frequency source is Keypad setting or terminal UP/DOWN, the value of this parameter is the initial frequency of the AC drive (digital setting).

Function code	Name	Description (setting range)	Factory Default	Change
F00.11	Frequency refer-	1:0.1Hz	2	
	ence resolution	2:0.01Hz	2	

It is used to set the resolution of all frequency-related parameters. If the resolution is 0.1Hz, the can output up to $600.0\,$ Hz.

If the resolution is 0.01 Hz,can output up to 300.0Hz.



Note: When modifying this function parameter, the decimal places of all frequency-related parameters will change, and the corresponding frequency value will also change. Special attention should be paid during use.

Function code	Name	Description (setting range)	Factory Default	Change
F00.12	Acceleration time 1	0.00s~6500.0s	Model dependent	*
F00.13	Deceleration time 1	0.00s~6500.0s	Model dependent	*

Acceleration time indicates the time required by the AC drive to accelerate from 0Hz to"Acceleration/Deceleration base frequency" (F00.15), that is, t1 in Figure 6-1.

Deceleration time indicates the time required by the AC drive to decelerate from"Accelertion/-Deceleration base frequency" (F00.15) to 0Hz, that is, t2 in Figure 6-1.



Fig.6-1 Acceleration/Deceleration time

When the set frequency is equal to the reference frequency of acceleration and deceleration, the actual acceleration and deceleration time is consistent with the set acceleration and deceleration time.

When the set frequency is less than the reference frequency of acceleration and deceleration, the actual acceleration time is less than the set acceleration and deceleration time.

Actual acceleration and deceleration time = set acceleration and deceleration time * (set frequency / acceleration and deceleration reference frequency)

The provides totally four groups of acceleration/deceleration time for selection. You can perform switchover by using a DI terminal.

Group 1: F00.12, F00.13	Group 2: F09.00,	F09.01
Group 3: F09.02, F09.03	Group 4: F09.04,	F09.05



Function code	Name	Description (setting range)		Factory Default	Change	
F00.14	Acceleration/Decele	0:1s;	1:0.1s;	2: 0.01s	1	•

To satisfy requirements of different applications, the provides three acceleration/ deceleration time units, 1s, 0.1s and 0.01s.

Function code	Name	Description (setting range)	Factory Default	Change
	Acceleration/Decele	0:max.frequency (F00.03)		
F00.15	ration time base	1:setting frequency	0	•
	frequency	2:100Hz		

The acceleration/deceleration time indicates the time for the AC drive to increase from 0Hz to the frequency set in F00.15. If this parameter is set to 1, the acceleration/deceleration time is related to the set frequency. If the set frequency changes frequently, the motor's acceleration/deceleration n/deceleration also changes.

Function code	Name	Description (setting range)	Factory Default	Change
F00.16	Rotation direction	0: run in the default direction	0	*
		1: run in the opposite direction		~

0: Run in the default direction. After the inverter is powered on, it runs in the actual direction.

1: Run in the opposite direction. By changing this function code, the rotation direction of the motor can be changed without changing any other parameters.

Note: The motor will resume running in the original direction after parameter initialization. Do not use this function in applications where changing the rotating direction of the motor is prohibited after system commissioning is complete.

Function code	ז י	lame		Description (setting range)		Factory Default	Change
F00.17	Carrie	r frequency	0.5kHz	~ 16.0kHz		Model dependent	*
fr	Carrier equency	Motor no	oise	Leakage current	A	C drive erature ris	e

frequency	Motor noise	Leakage current	temperature rise
0.5kHz	Large	Small	Low
10kHz	Ī	T T	T I
16kHz	Small	Large	High



Carrier frequency Model	Highest carrier frequency(kHz)	Lowest carrier frequency (kHz)	Default(kHz)
G model : 0.75kW ~ 11kW P model : 0.75kW ~ 15kW	16	0.5	6
G model : 15kW ~ 45kW P model : 18.5kW ~ 55kW	16	0.5	4
G model : 55kW P model : 75kW	16	0.5	3
G model : 75kW ~ 315kW P model : 93kW ~ 350kW	16	0.5	2

Relationship between model and carrier frequency:

This function is mainly used to improve the noise of motor operation and the interference of the inverter to the outside world.

Advantages of using high carrier frequency: ideal current waveform, less current harmonics, and low motor noise;

Disadvantages of using high carrier frequency: the switching loss increases, the temperature rise of the inverter increases, and the output capacity of the inverter is affected. Under high carrier frequency, the inverter needs to be derated; External electromagnetic interference increases.

Using a low carrier frequency is the opposite of the above situation. Too low carrier frequency will cause unstable operation at low frequencies, torque reduction and even oscillation.

When the inverter leaves the factory, the carrier frequency has been reasonably set. Under normal circumstances, users do not need to change this parameter.

Function code	Name	Description (setting range)	Factory Default	Change
F00.18	Carrier frequency adjustment with temperature	0: No 1: Yes	1	*

It is used to set whether the carrier frequency is adjusted based on the temperature. The AC drive automatically reduces the carrier frequency when detecting that the heatsink temperature is high. The AC drive resumes the carrier frequency to the set value when the heatsink temperature becomes normal. This function reduces the overheat alarms.

Function code	Name	Description (setting range)	Factory Default	Change
F00.19	Source of frequency upper limit	0: set by F00.04 1: analog Al1	0	•



Function code	Name	Description (setting range)	Factory Default	Change
		2:analog Al2		
F00.19	Source of frequency	3:analog Al3	0	
	upper limit	4:pulse (HDI)	0	•
		5:RS485 comminication		

It is used to set the source of the frequency upper limit, including digital setting (F00.04), AI,pulse setting or communication setting. If the frequency upper limit is set by means of AI1,AI2, AI3, DI5 or communication, the setting is similar to that of frequency A command. For details, see the description of F00.04.

For example, to avoid runaway in torque control mode in winding application, you can set the frequency upper limit by means of analog input. When the AC drive reaches the upper limit, it will continue to run at this speed.

Function code	Name	Description (setting range)	Factory Default	Change
F00.20	Frequency upper limit offset	0.00Hz ~ max.frequency (F00.03)	00.00Hz	*

If the source of the frequency upper limit is analog input or pulse setting, the final frequency upper limit is obtained by adding the offset in this parameter to the frequency upper limit set in F00.19.

Function code	Name	Description (setting range)	Factory Default	Change
F00.21	Base frequency for UP/DOWN modification during running	0: running frequency 1: set frequency	0	•

This parameter is valid only when the frequency source is digital setting.

It is used to set the base frequency to be modified by using keys A, v or the terminal UP/-DOWN function. If the running frequency and set frequency are different, there will be a large difference between the AC drive's performance during the acceleration/deceleration process.

Function code	Name	Description (setting range)	Factory Default	Change
F00.22	Binding command source to frequency source	Unit digit: (Binding keypad command to frequency source) 0: no binding 1: keypad setting	0000	*



Function code	Name	Description (setting range)	Factory Default	Change
F00.22	Binding command source to frequency source	2: analog Ai1 3: analog Ai2 4: analog Ai3 5:pulse setting (HDI) 6: multi- speed run setting 7: Simple PLC 8: PID control 9: RS485 communication Ten's digit (Binding terminal command to frequency source) Hundred's digit (Binding comm- unication command to frequency source) Thousands digit:(Binding autoop- eration command to frequency source)	0000	*

It is used to bind the three running command sources with the nine frequency sources, facilitating to implement synchronous switchover.

For details on the frequency sources, see the description of F00.06 (frequency A command selection).

Different running command sources can be bound to the same frequency source.

If a command source has a bound frequency source, the frequency source set in F00.06 to F00.09 no longer takes effect when the command source is effective.

Function code	Name	Description (setting range)	Factory Default	Change
F00.23	Range of frequency B source during superposition	0% ~ 150%	100%	*

If X and Y operation is used, F00.09 and F00.08 are used to set the adjustment range of the auxiliary frequency source.

You can set the auxiliary frequency to be relative to either maximum frequency or main frequency A. If relative to main frequency A, the setting range of the auxiliary frequency B varies according to the main frequency A.



Function code	Name	Description (setting range)	Factory Default	Change
F00.25	Frequency offset of frequency B source during superposition	0.00Hz ~ max.frequency F00.03	00.00Hz	•

If the frequency source involves A and B operation, you can set the frequency offset in F00.25 for superposition to the A and B operation result, flexibly satisfying various requirements.

Function code	Name	Description (setting range)	Factory Default	Change
F00.26	Retentive of keypad setting frequency upon power failure	0: no retentive 1: retentive	0	•

This parameter is valid only when the frequency source is keypad setting.

If F00.26 is set to 0, the keypad setting frequency value resumes to the value of F00.10 (Preset frequency) after the AC drive stops. The modification by using keys \land , \lor or the terminal UP/DOWN function is cleared.

If F00.26 is set to 1, the keypad setting frequency value is the set frequency at the moment when the AC drive stops. The modification by using keys \land , \lor or the terminal UP/DOWN function remains effective.

Function code	Name	Description (setting range)	Factory Default	Change
F00.27	Motor model selection	1: G type (constant torque load) 2: P type (variable torque load)	0	*

This parameter is used to display the delivered model and cannot be modified.

1: Applicable to constant torque load with rated parameters specified

2: Applicable to variable torque load (fan and pump) with rated parameters specified

Function code	Name	Description (setting range)	Factory Default	Change
F00.28	Function parameter restore	0:no operation 1: restore factory defaults,not include motor parameter 2: clear fault file	0	•



Group F01: Start-stop Control Parameters

Function code	Name	Description (setting range)	Factory Default	Change
F01.00	Start mode	0:direct start 1: rotational speed tracking restart 2: pre-excited start	0	*

0: Direct start

1: Rotational speed tracking restart

The AC drive judges the rotational speed and direction of the motor first and then starts at the tracked frequency. Such smooth start has no impact on the rotating motor. It is applicable to the restart upon instantaneous power failure of large-inertia load. To ensure the performance of rotational speed tracking restart, set the motor parameters in group F02 correctly.

2: Pre-excited start (asynchronous motor)

It is valid only for asynchronous motor and used for building the magnetic field before the motor runs. For pre-excited current and pre-excited time, see parameters of F01.03 and F01.04.

Function code	Name	Description (setting range)	Factory Default	Change
F01.01	Startup frequency	0.00Hz ~ 10.00Hz	0.00Hz	*
F01.02	Startup frequency holding time	0.0s ~ 100.0s	0.0s	•

To ensure the motor torque at AC drive startup, set a proper startup frequency. In addition, to build excitation when the motor starts up, the startup frequency must be held for a certain period.

The startup frequency (F01.02) is not restricted by the frequency lower limit. If the set target frequency is lower than the startup frequency, the AC drive will not start and stays in the standby state.

During switchover between forward rotation and reverse rotation, the startup frequency holding time is disabled.



Function Description Factory Name Change code (setting range) Default Startup DC braking F01 03 current/ Pre-excited $0\% \sim 100\%$ ٥% current Startup DC braking F01.04 0.0s~100.0s 0.0s time/ Pre-excited time

Startup DC braking is generally used during restart of the AC drive after the rotating motor stops. Pre-excitation is used to make the AC drive build magnetic field for the asynchronous motor before startup to improve the responsiveness.

Startup DC braking is valid only for direct start (F01.00=0). In this case, the AC drive performs DC braking at the set startup DC braking current. After the startup DC braking time, the AC drive starts to run. If the startup DC braking time is 0, the AC drive starts directly without DC braking. The larger the startup DC braking current is, the larger the braking force is.

If the startup mode is pre-excited start (F01.00 = 2), the AC drive builds magnetic field based on the set pre-excited current. After the pre-excited time, the AC drive starts to run. If the pre-excited time is 0, the AC drive starts directly without pre-excitation.

The startup DC braking current or pre-excited current is a percentage relative to the base value.

Function code	Name	Description (setting range)	Factory Default	Change
F01.05	Acceleration/ deceleration mode	0: line Acc/Dec time 1: S curve Acc/Dec A 2: S curve Acc/Dec B	0	•

It is used to set the frequency change mode during the AC drive start and stop process.

0: Linear acceleration/deceleration

The output frequency increases or decreases in linear mode. The provides fourgroup of acceleration/deceleration time, which can be selected by using F06.00 to F5.08.

1: S-curve acceleration/deceleration A

The output frequency increases or decreases along the S curve. This mode is generally used in the applications where start and stop processes are relatively smooth, such as elevator and conveyor belt. F01.06 and F01.07 respectively define the time proportions of the start segment and the end segment.

2: S-curve acceleration/deceleration B



In this curve, the rated motor frequency fb is always the inflexion point. This mode is usually used in applications where acceleration/deceleration is required at the speed higher than the rated frequency.

When the set frequency is higher than the rated frequency, the acceleration/deceleration time is:

In the formula, f is the set frequency, fb is the rated motor frequency and T is the acceleration time from 0Hz to fb.

Function code	Name	Description (setting range)	Factory Default	Change
F01.06	Time proportion of S- curve start segment	0.0%~ (100.0%-F01.07)	30.0%	•
F01.07	Time proportion of S- curve end segment	0.0%~ (100.0%- F01.06)	30.0%	*

These two parameters respectively define the time proportions of the start segment and the end segment of S-curve acceleration/deceleration. They must satisfy the requirement: $F01.06 + F01.07 \le 100.0\%$.

In Figure 6-2, t1 is the time defined in F6-08, within which the slope of the output frequency change increases gradually. t2 is the time defined in F01.07, within which the slope of the output frequency change gradually decreases to 0. Within the time between t1 and t2, the slope of the output frequency change remains unchanged, that is, linear acceleration/deceleration.





Function code	Name	Description (setting range)	Factory Default	Change
F01.08	Stop mode	0: deceleration to stop 1:stop freely	0	•

0: Decelerate to stop

After the stop command is enabled, the AC drive decreases the output frequency according to the deceleration time and stops when the frequency decreases to zero.

1: Coast to stop

After the stop command is enabled, the AC drive immediately stops the output. The motor will coast to stop based on the mechanical inertia.

Function code	Name	Description (setting range)	Factory Default	Change
F01.09	Initial frequency of stop DC braking	0.00Hz ~ F00.03(max. frequency)	0.00Hz	•
F01.10	Waiting time of stop DC braking	0.0s ~ 100.0s	0.0s	*
F01.11	Stop DC braking current	0%~100%	0.0%	•
F01.12	Stop DC braking time	0.0s~100.0s	0.0s	—

During the process of decelerating to stop, the AC drive starts DC braking when the running frequency is lower than the value.

When the running frequency decreases to the initial frequency of stop DC braking, the AC drive stops output for a certain period and then starts DC braking. This prevents faults such as overcurrent caused due to DC braking at high speed.

This parameter specifies the output current at DC braking and is a percentage relative to the base value. The larger current ,the effect of DC brake is higher, and heat of motor and Ac drive is higher.

This parameter specifies the holding time of DC braking. If it is set to 0, DC braking is cancelled.

The stop DC braking process is shown in the following figure 6-4.





Fig.6-4 Stop DC braking process

Function code	Name	Description (setting range)	Factory Default	Change
F01.13	Rotational speed tracking mode	0: start from frequency at stop1: start from zero speed2: start from max. frequency	0	_

To complete the rotational speed tracking process within the shortest time, select the proper mode in which the AC drive tracks the motor rotational speed.

0: From frequency at stop

It is the commonly selected mode.

1: From zero frequency

It is applicable to restart after a long time of power failure.

2: From the maximum frequency

It is applicable to the power-generating load.



Function code	Name	Description (setting range)	Factory Default	Change
F01.14	Rotational speed tracking speed	1~100	20	*

In the rotational speed tracking restart mode, select the rotational speed tracking speed. The larger the value is, the faster the tracking is. However, too large value may cause unreliable tracking.

Function code	Name	Description (setting range)	Factory Default	Change
F01.15	Brake usage rate	0% ~ 100%	100%	*

It is valid only for the AC drive with internal braking unit and used to adjust the duty ratio of the braking unit. The larger the value of this parameter is, the better the braking result will be. However, too larger value causes great fluctuation of the AC drive bus voltage during the braking process.



Group F02: Motor 1 Parameters

Function code	Name	Description (setting range)	Factory Default	Change
F02.00	Motor type selection	0:common asynchronous motor 1:variable frequency asynchro- nous motor	0	
F02.01	Rated power of asynchronous motor 1	0.1kW ~ 1000.0kW	Model dependent	•
F02.02	Rated frequency of asynchronous motor 1	0.01Hz ~ F00.03(max. frequency)	Model dependent	•
F02.03	Rated speed of asynchronous motor 1	1rpm ~ 65535rpm	Model dependent	•
F02.04	Rated voltage of asynchronous motor 1	1V~2000V	Model dependent	•
F02.05	Rated current of asynchronous motor 1	0.01A ~ 655.35A (AC drive power<= 55kW) 0.1A ~ 6553.5A (AC drive power> 55kW)	Model dependent	•

Set the parameters according to the motor nameplate no matter whether V/F control or vector control is adopted.

To achieve better V/F or vector control performance, motor auto-tuning is required. The motor auto-tuning accuracy depends on the correct setting of motor nameplate parameters.

Function code	Name	Description (setting range)	Factory Default	Change
F02.06	Stator resistance of asynchronous motor 1	0.001Ω ~ 65.535Ω (inverter power<= 55kW) 0.0001Ω ~ 6.5535Ω (AC drive power> 55kW)	Model dependent	•
F02.07	Rotor resistance of asynchronous motor 1	0.001Ω ~ 65.535Ω (AC drive power<= 55kW) 0.0001Ω ~ 6.5535Ω (AC drive power> 55kW)	Model dependent	•
F02.08	Leakage inductive reactance of asynchronous motor 1	0.01mH ~ 655.35mH (AC drive power<= 55kW) 0.001mH ~ 65.535mH (AC drive power> 55kW)	Model dependent	•



Function code	Name	Description (setting range)	Factory Default	Change
F02.09	Mutual inductive reactance of asynchronous motor 1	0.1mH ~ 6553.5mH (inverter power<= 55kW) 0.01mH ~ 655.35mH (AC drive power> 55kW)	Model dependent	•
F02.10	No-load current of asynchronous motor 1	0.01A ~ F02.05 (inverter power<= 55kW) 0.1A ~ F02.05 (AC drive power> 55kW)	Model dependent	•

The parameters in F02.06 to F02.10 are asynchronous motor parameters. These parameters are unavailable on the motor nameplate and are obtained by means of motor self-learning.

Only F02.06 to F02.08 can be obtained through static motor auto-tuning. Through complete motor auto-tuning, encoder phase sequence and current loop PI can be obtained besides the parameters in F02.06 to F02.10.

Each time "Rated motor power" (F02.01) or "Rated motor voltage" (F02.04) is changed, the AC drive automatically restores values of F02.06 to F02.10 to the parameter setting for the common standard asynchronous motor.

If it is impossible to perform motor auto-tuning onsite, manually input the values of these parameters according to data provided by the motor manufacturer.

Function code	Name	Description (setting range)	Factory Default	Change
F02.27	Encoder type	0:ABZ incremental encoder 1:UVW incremental encoder	0	•

The supports two types of encoder.

After installation of the PG card is complete, set this parameter properly based on the actual condition. Otherwise, the AC drive cannot run properly.

Function code	Name	Description (setting range)	Factory Default	Change
F02.29	Encoder pulses per revolution	1~65535	2500	•

This parameter is used to set the pulses per revolution (PPR) of ABZ or UVW incremental encoder. In CLVC mode, the motor cannot run properly if this parameter is set incorrectly.



Function code	Name	Description (setting range)	Factory Default	Change
F02.30	AB phase sequence of ABZ incremental encoder	0: forward 1: reverse	0	•

This parameter is valid only for ABZ incremental encoder (F02.27 = 0) and is used to set the A/B phase sequence of the ABZ incremental encoder.

It is valid for both asynchronous motor and synchronous motor. The A/B phase sequence can be obtained through "Asynchronous motor complete self-learning".

Function code	Name	Description (setting range)	Factory Default	Change
F02.31	Encoder installation angle	0.0 ~ 359.9°	0.0°	•
F02.32	UVW phase sequence of UVW encoder	0: forward 1: reverse	0	•
F02.33	UVW encoder angle offset	0.0~359.9°	0.0°	•
F02.36	Encoder wire-break fault detection time	0.0s: No action 0.1–10.0s	0.0	•

This parameter is used to set the time that a wire-break fault lasts. If it is set to 0.0s, the AC drive does not detect the encoder wire-break fault. If the duration of the encoder wire-break fault detected by the AC drive exceeds the time set in this parameter, the AC drive reports E026.

Function code	Name	Description (setting range)	Factory Default	Change
F02.37	Self-learning of motor parameter	0: no self-learning1: dynamic self- learning of asynchronous motor2: static self- learning of asynchronous motor	0	•

0: No self-learning

1: Static self-learning of asynchronous motor

It is applicable to scenarios where complete self-learning cannot be performed because the asynchronous motor cannot be disconnected from the load.



Before performing static self-learning, properly set the motor type and motor nameplate parameters of F02.00 to F02.05 first. The AC drive will obtain parameters of F02.06 to F02.08 by dynamic self-learning.

2: Complete self-learning of asynchronous motor

To perform this type of self-learning, ensure that the motor is disconnected from the load.

During the process of complete self-learning, the AC drive performs static self-learning first and then accelerates to 80% of the rated motor frequency within the acceleration time set in F00.12. The AC drive keeps running for a certain period and then decelerates to stop within deceleration time set in F00.13.

Before performing complete self-learning, properly set the motor type, motor nameplate parameters of F02.00 to F02.05, "Encoder type" (F02.27) and "Encoder pulses per revolution" (F02.28) first.

Set this parameter to 2, and press"RUN", the AC drive will obtain motor parameters of F02.06 to F02.10, "A/B phase sequence of ABZ incremental encoder" (F02.30) and vector control current loop PI parameters of F03.13 to F03.16 by complete self-learning. Press"STOP" to stop self-learning.

NOTE: Motor self-learning can be performed only in keypad mode.Function code will turn to 0 after finish self-learning.

-107-


Group F03: Vector Control Parameters

Group F03 is valid for vector control, and invalid for V/F control.

Function code	Name	Description (setting range)	Factory Default	Change
F03.00	Proportional gain 1 of speed loop	1~100	30	*
F03.01	Integral time 1 of speed loop	0.01s~10.00s	0.50s	*
F03.02	Switchover low point frequency	0.00Hz ~ F03.05	5.00Hz	*
F03.03	Proportional gain 2 of speed loop	1~100	20	*
F03.04	Integral time 2 of speed loop	0.01s~10.00s	1.00s	*
F03.05	Switchover high point frequency	F03.02 ~ F00.03(max. frequency)	10.00Hz	*

Speed loop PI parameters vary with running frequencies of the AC drive.

If the running frequency is less than or equal to "Switchover frequency 1" (F03.02), the speed loop PI parameters are F03.00 and F03.01.

If the running frequency is equal to or greater than "Switchover frequency 2" (F03.05), the speed loop PI parameters are F03.03 and F04.04.

If the running frequency is between F03.02 and F03.05, the speed loop PI parameters are obtained from the linear switchover between the two groups of PI parameters.



Fig.6-5 Relationship between running frequencies and PI parameters



The speed dynamic response characteristics in vector control can be adjusted by setting the proportional gain and integral time of the speed regulator.

To achieve a faster system response, increase the proportional gain and reduce the integral time. Be aware that this may lead to system oscillation.

The recommended adjustment method is as follows:

If the factory setting cannot meet the requirements, make proper adjustment. Increase the proportional gain first to ensure that the system does not oscillate, and then reduce the integral time to ensure that the system has quick response and smallovershoot.

Improper PI parameter setting may cause too large speed overshoot, and overvoltage fault may even occur when the overshoot drops.

Function code	Name	Description (setting range)	Factory Default	Change
F03.06	Vector control slip gain	50%~200%	100%	*

For SFVC, it is used to adjust speed stability accuracy of the motor. When the motor with load runs at a very low speed, increase the value of this parameter; when the motor with load runs at a very large speed, decrease the value of thisparameter.

For CLVC, it is used to adjust the output current of the AC drive with same load.

Function code	Name	Description (setting range)	Factory Default	Change
F03.07	Speed loop output filter	0.000s~0.100s	0.000s	*

In the vector control mode, the output of the speed loop regulator is torque current reference. This parameter is used to filter the torque references. It need not be adjusted generally and can be increased in the case of large speed fluctuation. In the case of motor oscillation,decrease the value of this parameter properly.

If the value of this parameter is small, the output torque of the AC drive may fluctuate greatly, but the response is quick.

Function code	Name	Description (setting range)	Factory Default	Change
F03.08	Vector control over excitation gain	0~200	64	*

During deceleration of the AC drive, over-excitation control can restrain rise of the bus volta ge to avoid the overvoltage fault. The larger the over-excitation gain is, the better the restraining effect is.



Increase the over-excitation gain if the AC drive is liable to overvoltage error during deceleration. Too large over-excitation gain, however, may lead to an increase in output current. Therefore, set this parameter to a proper value in actual applications.

Set the over-excitation gain to 0 in applications of small inertia (the bus voltage will not rise during deceleration) or where there is a braking resistor.

Function code	Name	Description (setting range)	Factory Default	Change
F03.09	Torque upper limit source in speed control mode	0:F03.10 1:analog Al1 2:analog Al2 3:analog Al3 4:Pulse (HDI) 5:RS485 Communication 6:MIN(Al1,Al2) 7:MAX(Al1,Al2) (corresponding to F03.10 digital setting)	0	*
F03.10	Digital setting of torque upper limit in speed control mode	0.0% ~ 200.0%	150.0%	*

In the speed control mode, the maximum output torque of the AC drive is restricted by F03.09. If the torque upper limit is analog, pulse or communication setting, 100% of the setting corre sponds to the value of F03.10, and 100% of the value of F03.10 corresponds to the AC drive rated torque.

Function code	Name	Description (setting range)	Factory Default	Change
F03.13	Excitation adjustment proportional gain	0~60000	2000	*
F03.14	Excitation adjustment integral gain	0~60000	1300	*
F03.15	Torque adjustment proportion gain	0~60000	2000	*
F03.16	Torque adjustment integral gain	0~60000	1300	*



These are current loop PI parameters for vector control. These parameters are automatically obtained through "Asynchronous motor complete self-learning" or "Synchronous motor noload self-learning", and need not be modified.

The dimension of the current loop integral regulator is integral gain rather than integral time. Note that too large current loop PI gain may lead to oscillation of the entire control loop.

Therefore, when current oscillation or torque fluctuation is great, manually decrease the proportional gain or integral gain here.

Function code	Name	Description (setting range)	Factory Default	Change
F03.17	Speed loop integral property	Units' digit: integral separation 0: invalid 1: valid	0	*
F03.18	Synchronous machine field weakening mode	0: Field weakening is invalid1: Direct calculation mode2: Automatic adjustment mode	0	*
F03.19	Synchronous machine field weakening depth	50% ~ 500%	100%	*
F03.20	Maximum field weakening current	1%~300%	50%	*
F03.21	Field weakening automatic adjustment gain	10% ~ 500%	100%	*
F03.22	Field weakening integral multiple	2~10	2	*

The provides two field weakening modes: direct calculation and automatic adjustment.

In direct calculation mode, directly calculate the demagnetized current and manually adjust the demagnetized current by means of F03.19. The smaller the demagnetized current is, the smaller the total output current is. However, the desired field weakening effect may not be achieved.

In automatic adjustment mode, the best demagnetized current is selected automatically. This may influence the system dynamic performance or cause instability.

The adjustment speed of the field weakening current can be changed by modifying the values of F03.21 and F03.22. A very quick adjustment may cause instability. Therefore, generally do not modify them manually.



Function code	Name	Description (setting range)	Factory Default	Change
F03.23	Speed/torque control mode selection	0: speed control 1: torque control	0	*
F03.24	Torque setting mode selection	0: digital setting (F03.26) 1:analog Al1 2:analog Al2 3:analog Al3 4:PULSE (HDI) 5:RS485 Communication 6:MIN(Al1,Al2) 7:MAX(Al1,Al2) (corresponding to F03.26 digital setting)	0	*
F03.26	Torque setting by keypad	-200.0% ~ 200.0%	105%	*

If the torque setting mode is 1~7, analog, pulse or communication setting are 100% of the setting corresponds to the value of F03.26.

Function code	Name	Description (setting range)	Factory Default	Change
F03.28	Upper frequency limit of forward when torque control	0.00Hz ~ F00. 03(max. frequency)	50.00Hz	*
F03.29	Upper frequency limit of reverse when torque control	0.00Hz ~ F00. 03(max. frequency)	50.00Hz	*

Please limit the max.speed of motor when torque control.

Function code	Name	Description (setting range)	Factory Default	Change
F03.30	Torque control acceleration time	0.00s~650.00s	0.00s	*
F03.31	Torque control deceleration time	0.00s~650.00s	0.00s	*



In the torque control mode, the difference between the motor output torque and the load torque determines the speed change rate of the motor and the load. Therefore, the motor speed may change rapidly, causing problems such as excessive noise or mechanical stress. By setting the torque control acceleration/deceleration time, the motor speed can be changed smoothly.

But for the occasions that require quick torque response, it is necessary to set the torque control acceleration and deceleration time to 0.00s.

For example, two motors are hard-connected to drive the same load. In order to ensure even distribution of the load, one inverter is set as the master and adopts the speed control method, and the other inverter is the slave and adopts torque control. The actual output of the master is The torque of the slave is used as the torque command of the slave. At this time, the torque of the slave needs to follow the master quickly, so the acceleration and deceleration time of the torque control of the slave is 0.00s.

-113.



Group F04: V/F Control Parameters

Group F04 is valid only for V/F control.

The V/F control mode is applicable to low load applications (fan or pump) or applications where one AC drive operates multiple motors or there is a large difference between the AC drive power and the motor power.

Function code	Name	Description (setting range)	Factory Default	Change
F04.00	Motor1 V/F curve setting	0: linear V/F 1: multi-point V/F 2: square V/F 3: V/F complete seperation 4: V/F half seperation 5:1.2 square V/F 6: 1.4 square V/F 7: 1.6 square V/F 8: 1.8 square V/F	0	*

0: Linear V/F

It is applicable to common constant torque load.

1: Multi-point V/F

It is applicable to special load such as dehydrator and centrifuge. Any such V/F curve can be obtained by setting parameters of F04.03 to F04.08.

2: Square V/F

It is applicable to centrifugal loads such as fan and pump.

3: V/F complete separation

In this mode, the output frequency and output voltage of the AC drive are independent. The output frequency is determined by the frequency source, and the output voltage is determined by "Voltage source for V/F separation" (F04.13).

It is applicable to induction heating, inverse power supply and torque motor control.

4: V/F half separation

In this mode, V and F are proportional and the proportional relationship can be set in F04.13. The relationship between V and F are also related to the rated motor voltage and rated motor frequency in Group F02.

Assume that the voltage source input is X (0 to 100%), the relationship between V and F is:

V/F = 2 * X *(Rated motor voltage)/(Rated motor frequency)



Function code	Name	Description (setting range)	Factory Default	Change
F04.01	Motor 1 torque boost	0.0%:(auto torque boost) 0.1% ~ 30.0%	Model dependent	•
F04.02	Cut-off frequency of motor 1 torque boost	0.00Hz ~ F00.03(max.frequency)	50.00Hz	

To compensate the low frequency torque characteristics of V/F control, you can boost the output voltage of the AC drive at low frequency by modifying F04.02.

If the torque boost is set to too large, the motor may overheat, and the AC drive may suffer overcurrent.

If the load is large and the motor startup torque is insufficient, increase the value of F04.01.

If the load is small, decrease the value of F04.01. If it is set to 0.0, the AC drive performs automatic torque boost. In this case, the AC drive automatically calculates the torque boost value based on motor parameters including the stator resistance.

F04.02 specifies the frequency under which torque boost is valid. Torque boost becomes invalid when this frequency is exceeded, as shown in the following figure.





-115-



Function code	Name	Description (setting range)	Factory Default	Change
F04.03	Motor1 V/F frequency point 1	0.00Hz ~ F04.05	0.00Hz	•
F04.04	Motor1 V/F voltage point 1	0.0% ~ 100.0%	0.0%	•
F04.05	Motor1 V/F frequency point 2	F04.03 ~ F04.07	0.00Hz	•
F04.06	Motor1 V/F voltage point 2	0.0% ~ 100.0%	0.0%	•
F04.07	Motor1 V/F frequency point 3	F04.05 ~ F02.02 (motor rated frequency	0.00Hz	•
F04.08	Motor1 V/F voltage point 3	0.0% ~ 100.0%	0.0%	•

These six parameters are used to define the multi-point V/F curve.

The multi-point V/F curve is set based on the motor's load characteristic. The relationship between voltages and frequencies is:

V1<V2<V3, f1<f2<f3

At low frequency, higher voltage may cause overheat or even burnt out of the motor and overcurrent stall or overcurrent protection of the AC drive.



 $V_{\scriptscriptstyle 1}\text{-}V_{\scriptscriptstyle 3}\text{:}$ The percentage of the voltage of the 1st-3rd stage of the multi-speed V/F

f₁-f₃: Frequency percentage of 1st-3rd stage of multi-speed V/F

V_b: Rated motor voltage

f_b: Rated motor running frequency

-116-



Function code	Name	Description (setting range)	Factory Default	Change
F04.09	Motor1 V/F slip compensation gain	0.0% ~ 200.0%	0.0%	*

This parameter is valid only for the asynchronous motor.

It can compensate the rotational speed slip of the asynchronous motor when the load of the motor increases, stabilizing the motor speed in case of load change. If this parameter is set to 100%, it indicates that the compensation when the motor bears rated load is the rated motor slip. The rated motor slip is automatically obtained by the AC drive through calculation based on the rated motor frequency and rated motor rotational speed in group F02.

Generally, if the motor rotational speed is different from the target speed, slightly adjust this parameter.

Function code	Name	Description (setting range)	Factory Default	Change
F04.10	V/F over-excitation gain	0~200	64	*

During deceleration of the AC drive, over-excitation can restrain rise of the bus voltage, preventing the overvoltage fault. The larger the over-excitation is, the better the restraining result is.

Increase the over-excitation gain if the AC drive is liable to overvoltage error during deceleration. However, too large over-excitation gain may lead to an increase in the output current.

Set the over-excitation gain to 0 in the applications where the inertia is small and the bus voltage will not rise during motor deceleration or where there is a braking resistor.

Function code	Name	Description (setting range)	Factory Default	Change
F04.11	V/F oscillation suppression gain	0~100	Model dependent	*

Set this parameter to a value as small as possible in the prerequisite of efficient oscillation suppression to avoid influence on V/F control.

Set this parameter to 0 if the motor has no oscillation. Increase the value properly only when the motor has obvious oscillation. The larger the value is, the better the oscillation suppression result will be.

When the oscillation suppression function is enabled, the rated motor current and noload current must be correct. Otherwise, the V/F oscillation suppression effect will not be satisfactory.

-117-

Function code	Name	Description (setting range)	Factory Default	Change
F04.13	Voltage source for V/F separation	0: digital setting (F04.14) 1: analog Al1 2: analog Al2 3: analog Al3 4: pulse (HDI) 5: multi-speed operation 6: simple PLC 7: PID control 8: RS485 Communication (corresponding F02.04 digital setting)	0	*
F04.14	Digital setting V/F separation of voltage	0V ~ F02.04(motor rated voltage)	0V	*

 ${\sf V}/{\sf F}$ separation is generally applicable to scenarios such as induction heating, inverse power supply and motor torque control.

If V/F separated control is enabled, the output voltage can be set in F04.14 or by means of analog, multi-reference, simple PLC, PID or communication. If you set the output voltage by means of non-digital setting, 100% of the setting corresponds to the rated motor voltage. If a negative percentage is set, its absolute value is used as the effectivevalue.

0: Digital setting (F04.14)

The output voltage is set directly in F04.14.

1: AI1;

2: AI2;

3: AI3;

The output voltage is set by Aiterminals.

4: Pulse setting (HDI)

The output voltage is set by pulses of the terminal. Pulse setting specification: voltage range 9-26V, frequency range 0-100 kHz.

5: Multi-speed operation

If the voltage source is multi-speed command, parameters in group F06 and F12 must be set to determine the corresponding relationship between setting signal and setting voltage. 100.0% of the multi-speed setting in group F12 corresponds to the rated motor voltage.



6: Simple PLC

If the voltage source is simple PLC mode, parameters in group F12 must be set to determine the setting output voltage.

7: PID control

The output voltage is generated based on PID closed loop. For details, see the description of PID in group F10.

8: Rs485 communication

The output voltage is set by the host computer by means of communication.

The voltage source for V/F separation is set in the same way as the frequency source. When the above voltage source is selected from 1 to 8, 0 to 100% corresponds to the output power 0V to the rated voltage of the motor.

Function code	Name	Description (setting range)	Factory Default	Change
F04.15	Voltage digital setting for V/F separation	0.0s ~ 1000.0s note: time from 0V to motor rated voltage (F02.04)	0.0s	*

The rise time of V/F separation refers to the time required for the output voltage to change from 0V to the rated voltage of the motor. As shown in Figure 6-8:



Fig.6-8 Voltage of V/F separation



Group F05: Fault and Protection

Function code	Name	Description (setting range)	Factory Default	Change
F05.00	Input phase loss protection	0: disabled 1: enabled	1	*

It is used to determine whether to perform input phase loss or contactor energizing protection.

≥ 18.5KW G type drive provide the function of input phase loss protection.

< 18.5KW P type drive do not provide the function of input phase loss protection no matter whether E05 00 is set to 0 or 1

Function code	Name	Description (setting range)	Factory Default	Change
F05.01	Output phase loss protectio	0: disabled 1: enabled	1	*

It is used to determine whether to perform output phase loss protection.

Function code	Name	Description (setting range)	Factory Default	Change
F05.02	Action selection at instantaneous power failure	0: Invalid 1: Decelerate 2: Decelerate to stop	0	*
F05.03	Voltage rally judging time a instantaneous power failure	0.00s~100.00s	0.50s	*
F05.04	Action judging voltage at instantaneous power failure	60.0% ~ 100.0%(standard bus voltage)	80.0%	*

Upon instantaneous power failure or sudden voltage dip, the DC bus voltage of the AC drive reduces. This function enables the AC drive to compensate the DC bus voltage reduction with the load feedback energy by reducing the output frequency so as to keep the AC drive running continuously.

If F05.02 = 1, upon instantaneous power failure or sudden voltage dip, the AC drive decelerates. Once the bus voltage resumes to normal, the AC drive accelerates to the set frequency. If the bus voltage remains normal for the time exceeding the value set in F05.03, it is considered that the bus voltage resumes to normal.

If F05.02 = 2, upon instantaneous power failure or sudden voltage dip, the AC drive decelerates to stop.

-120-





Fig.6-9 AC drive action diagram upon instantaneous power failure

Function code	Name	Description (setting range)	Factory Default	Change
F05.05	Overvoltage stall gain	0~100	0	*
F05.06	Overvoltage stall protective voltage	120% ~ 150%	130%	*

When the DC bus voltage exceeds the value of F05.06 (Overvoltage stall protective voltage) during deceleration of the AC drive, the AC drive stops deceleration and keeps the present running frequency. After the bus voltage declines, the AC drive continues to decelerate.

F05.05 (Overvoltage stall gain) is used to adjust the overvoltage suppression capacity of the AC drive. The larger the value is, the greater the overvoltage suppression capacity will be.

In the prerequisite of no overvoltage occurrence, set F05.05 to a small value.For small-inertia load, the value should be small. Otherwise, the system dynamic response will be slow. For large-inertia load, the value should be large. Otherwise, the suppression result will be poor and an overvoltage fault may occur.

When the overvoltage stall gain is set to 0, the overvoltage stall function is canceled.

-121-





Fig.6-10 Diagram of the overvoltage stall protection function

Function code	Name	Description (setting range)	Factory Default	Change
F05.07	Overcurrent stall gain	0~100	20	*
F05.08	Overcurrent stall protective current	100% ~ 200%	150%	*

When the output current exceeds the overcurrent stall protective current during acceleration/ deceleration of the AC drive, the AC drive stops acceleration/deceleration and keeps the present running frequency. After the output current declines, the AC drive continues toaccelerate/decelerate.

F05.07(Overcurrent stall gain) is used to adjust the overcurrent suppression capacity of the AC drive. The larger the value is, the greater the overcurrent suppression capacity will be. In the prerequisite of no overcurrent occurrence, set F05.08 to a small value.

For small-inertia load, the value should be small. Otherwise, the system dynamic response will be slow. For large-inertia load, the value should be large. Otherwise, the suppression result will be poor and overcurrent fault may occur.

If the overcurrent stall gain is set to 0, the overcurrent stall function is disabled.





Fig.6-11 Diagram of the overcurrent stall protection function

Function code	Name	Description (setting range)	Factory Default	Change
F05.09	Motor overload warning selection	0: disabled 1: enabled	1	*

F05.09=0: no motor overload protection, it will cause motor overheat and damaged, we suggest to use thermal relay.

F05.09=1: motor overload protection according to inverse time limit curve.

Function code	Name	Description (setting range)	Factory Default	Change
F05.10	Motor overload pre-alarm warning detection levels	0.20~10.00	1.00	*
F05.11	Motor overload pre-alarm warning detection time	50% ~ 100%	80%	*

This function is used to give an early warning signal to the control system through the multifunction output terminal before the motor overload fault protection. This warning factor is used to determine how much warning is given before motor overload protection. The larger the value is, the smaller the early warning is.

When the cumulative output current of the inverter is greater than the product of the overload inverse time limit curve and F05.11, the multi-function digital multi-function output terminal of the inverter outputs the ON signal of "motor overload pre-alarm".

-123-



Function code	Name	Description (setting range)	Factory Default	Change
F05.12	Protection upon load becoming 0	0: disabled 1: enabled	0	*
F05.13	Detection level of load becoming 0	0.0 ~ 100.0% (rated motor current)	10.0%	*
F05.14	Detection time of load becoming 0	0.0~60.0s	1.0s	*

If protection upon load becoming 0 is enabled, when the output current of the AC drive is lower than the detection level (F05.13) and the lasting time exceeds the detection time (F05.14), the output frequency of the AC drive automatically declines to 7% of the rated frequency. During the protection, the AC drive automatically accelerates to the set frequency if the load resumes to normal.

Function code	Name	Description (setting range)	Factory Default	Change
F05.15	Over-speed detection value	0.0% ~ 50.0%(F00.03(max. frequency))	20.0%	*
F05.16	Over-speed detection time	0.0~60.0s	1.0s	*

This function is valid only when the AC drive runs in the sensor vector control mode.

If the actual motor rotational speed detected by the AC drive exceeds the maximum frequency and the excessive value is greater than the value of F05.15 and the lasting time exceeds the value of F05.16, the AC drive reports E035 and acts according to the selected fault protection action.

Function code	Name	Description (setting range)	Factory Default	Change
F05.17	Detection value of too large speed deviation	0.0% ~ 50.0%(F00.03(max. frequency))	20.0%	*
F05.18	Detection time of too large speed deviation	0.0s~60.0s	5.0s	*

This function is valid only when the AC drive runs in the sensor vector control mode.

If the AC drive detects the deviation between the actual motor rotational speed detected by the AC drive and the set frequency is greater than the value of F05.17 and the lasting time exceeds the value of F05.18, the AC drive reports E034 and according to the selected fault protection action.



If F05.18 (Detection time of too large speed deviation) is 0.0s, this function is disabled.

Function code	Name	Description (setting range)	Factory Default	Change
F05.19	Fault auto reset times	0~20	0	*

It is used to set the times of fault auto resets if this function is used. After the value is excee ded, the AC drive will remain in the fault state.

Function code	Name	Description (setting range)	Factory Default	Change
F05.20	Time interval of fault auto reset	0.1s~100.0s	1.0s	*

It is used to set the waiting time from the alarm of the AC drive to fault auto reset.

Function code	Name	Description (setting range)	Factory Default	Change
F05.21	Fault protection action selection 1	Unit's digit:motor overload (E007) 0:coast to stop 1:stop according to the stop mode 2:continue to run Ten's digit :power input phase loss (E012) Hundred's digit:power output phase loss (E013) Thousand's digit:external equipment fault(E00d) Ten thousand's digit:communication fault(E018)	00000	*
F05.22	Fault protection action selection 2	Unit's digit:encoder/PG card fault(E026) 0:coast to stop Ten's digit:EEPROM read-write fault(E021) 0:coast to stop 1:stop according to the stop mode Hundred's digit: reserved Thousand's digit: motor overheat(E036)	00000	*



Function code	Name	Description (setting range)	Factory Default	Change
F05.22	Fault protection action selection 2	Ten thousand's digit (Accumulative running time reached)(E020)	00000	*
		Unit's digit: reserved Ten's digit: reserved Hundred's digit (Accumulative power-on time reached(E029)		
		0: coast to stop		
		1: stop according to the stop mode		
		2: continue to run		
	Fault	Thousand's digit: off load(E030)		
505.00	protection action selection 3	0: coast to stop	00000	~
F05.23		1: decelerate to stop	00000	*
		2: continue to run at 7% of rated motor		
		the load recovers		
		Ten thousand's digit :PID feedback lost during running (E02E)		
		0:coast to stop		
		1:stop according to the stop mode		
		2:continue to run		
		Unit's digit :too large speed deviation (E034)		
	Fault	0:coast to stop		
F05.24	protection	1:stop according to the stop mode	000	*
	selection 4	2:continue to run		
()	30160110114	Ten's digit:motor over-speed (E035)		
		Hundred's digit :initial position fault(E037)		

If "Coast to stop" is selected, the AC drive displays E0** and directly stops.

If "Stop according to the stop mode" is selected, the AC drive displays A^{**} and stops according to the stop mode. After stop, the AC drive displays $E0^{**}$.

If "Continue to run" is selected, the AC drive continues to run and displays A**. The running frequency is set in F05.26.



Function code	Name	Description (setting range)	Factory Default	Change
F05.26	Frequency selection for continuing to run upon fault	0:Current running frequency 1:Set frequency 2:Frequency upper limit 3:Frequency lower limit 4:Backup frequency upon abnormality	0	*

If a fault occurs during the running of the AC drive and the handling of fault is set to "Continue to run", the AC drive displays A** and continues to run at the frequency set in F05.26.

Function code	Name	Description (setting range)	Factory Default	Change
F05.27	Current fault type		_	•
F05.28	2nd fault type	0~32	_	•
F05.29	1st fault type		_	•

It is used to record the types of the most recent three faults of the AC drive. 0 indicates no fault. For possible causes and solution of each fault, refer to Chapter 8.

Function code	Name	Description (setting range)	Factory Default	Change
F05.30	Frequency upon current fault	It displays the frequency when the latest fault occurs		•
F05.31	Output current upon current fault	It displays the current when the latest fault occurs	_	•
F05.32	Bus voltage upon current fault	It displays the bus voltage when the latest fault occurs.		•
F05.33	Input terminal status upon current fault	It displays the status of all digital input terminals when the latest fault occurs. The sequence is as follows: BIT9BIT8BIT7BIT6BIT5BIT4BIT3BIT2BIT1BIT0 HDI S9 S8 S7 S6 S5 S4 S3 S2 S1		•

-127-



Function code	Name	Description (setting range)	Factory Default	Change
F05.33	Input terminal status upon current fault	If a input terminal is ON, the setting is 1. If the DI is OFF, the setting is 0. The value is the equivalent decimal number converted from the S status	-	
F05.34	Output terminal status upon current fault	It displays the status of all output terminals when the latest fault occurs. The sequence is as follows: BIT4 BIT3 BIT2 BIT1 BIT0 DO2 MO1 RA TA FMP If an output terminal is ON, the setting is 1, If the output terminal is OFF, the setting is 0. The value is the equivalent decimal number converted from the S statuses	2	•

Function code	Name	Description (setting range)	Factory Default	Change
F05.33	Input terminal status upon current fault	Reserved	—	•
F05.34	Output terminal status upon current fault	It displays the present power-on time when the latest fault occurs	—	•
F05.35	AC drive status upon current fault	It displays the present running time when the latest fault occurs	—	•
F05.36	Power-on time status upon current fault		—	•
F05.37	Running time status upon current fault		—	•
F05.38	Frequency upon 2nd fault	0	—	•
F05.39	Output current upon 2nd fault	Same as F05.30 ~ F05.37	—	•
F05.40	Bus voltage upon 2nd fault		_	•
F05.41	Input terminal status upon 2nd fault			•

-128-



Function code	Name	Description (setting range)	Factory Default	Change
F05.42	Output terminal status upon 2nd fault		_	•
F05.43	AC drive status upon 2nd fault		—	•
F05.44	Power-on time upon 2nd fault			•
F05.45	Running time upon 2nd fault		-	•
F05.46	Frequency upon 1st fault			•
F05.47	Output current upon 1st fault	Samo as E05 20 a	_	•
F05.48	Bus voltage upon 1st fault	F05.37		•
F05.49	Input terminal status upon 1st fault		_	•
F05.50	Output terminal status upon 1st fault		_	•
F05.51	AC drive status upon 1st fault		_	•
F05.52	Power-on time upon 1st fault		_	•
F05.53	Running time upon 1st fault			•

Function code	Name	Description (setting range)	Factory Default	Change
F05.54	Short-circuit to ground	0: Disabled	1	
	upon power-on	1: Enabled	1	•

It is used to determine whether to check the motor is short-circuited to ground at power-on of the AC drive. If this function is enabled, the AC drive's UVW will have voltage output a while after power-on.

Function code	Name	Description (setting range)	Factory Default	Change
F05.55	Output terminal action	0: Not act	0	
	during fault auto reset	1: Act	U	•

If the inverter is set with the function of automatic fault reset, during the period of automatic fault reset, whether the fault output terminal will act can be set through F05.55.

Function code	Name	Description (setting range)	Factory Default	Change
F05.56	Backup frequency upon abnormality	0.0% ~ 100.0% (100.0% corresponding to maximum frequency)F00.03)	100.0%	•

When the abnormal standby frequency is selected to run, the value set by F05.56 is a percentage relative to the maximum frequency.

Function code	Name	Description (setting range)	Factory Default	Change
F05.57	Type of motor temperature sensor	0: No temperature sensor 1: PT100 2: PT1000	0	•
F05.58	Motor overheat protection threshold	0°C ~ 200°C	100°C	•
F05.59	Motor overheat warning threshold	0°C ~ 200°C	90°C	•

The signal of the motor temperature sensor needs to be connected to the multi-function analog input terminal. Analog input AI3 can be used for the temperature signal input. The motor temperature sensor is connected to AI3 and ACM terminal. The AI3 terminal of the supports both PT100 and PT1000. Set the sensor type correctly during the use.

If the motor temperature exceeds the value set in F05.58, the AC drive reports an alarm and acts according to the selected fault protection action.

If the motor temperature exceeds the value set in F05.59, motor overheat warning becomes ON.

Function code	Name	Description (setting range)	Factory Default	Change
F05.60	Action pause judging voltage at instantaneous power failure	F05.04 ~ 100.0%	90.0%	•



Group F06: Input Terminals

The provides six multi-function digital input (DI) terminals and three analog input (AI) terminals. The optional extension card provides another four DI terminals (S7 to HDI), (HDI can be used for high-speed pulseinput).

Function code	Name	Description (setting range)	Factory Default	Change
F06.00	S1 terminal function selection		1	•
F06.01	S2 terminal function selection		2	•
F06.02	S3 terminal function selection		4	•
F06.03	S4 terminal function selection		6	•
F06.04	S5 terminal function selection	0.50	12	•
F06.05	S6 terminal function selection	0~50	13	•
F06.06	S7 terminal function selection		0	•
F06.07	S8 terminal function selection		0	•
F06.08	S9 terminal function selection		0	•
F06.09	HDI terminal function		0	•

The following table lists the functions available for the DI terminals.

Value	Function	Description	
0	No function	Set 0 for reserved terminals to avoid malfunction.	
1	Forward RUN (FWD)	The terminal is used to control forward or reverse RUN of	
2	Reverse RUN (REV)	the AC drive.	
3	3-wire operation control	The terminal determines three-line control of the AC drive. For details, see the description of F06.13.	
4	Forward jog	Forward jog indicates forward JOG running, while reverse jog indicates reverse JOG running. The JOG frequency,	
5	Reverse jog	acceleration time and deceleration time are described respectively in F09.06, F09.07 and F09.08.	
6	Coast to stop	The AC drive blocks its output, the motor coasts to rest and is not controlled by the AC drive. It is the same as coast to stop described in F02.10.	



Value	Function	Description	
7	Fault reset (RESET)	The terminal is used for fault reset function, the same as the function of RESET key on the operation panel. Remote fault reset is implemented by this function.	
8	Normally open (NO) input of external fault	If this terminal becomes ON, the AC drive reports E00d and performs the fault protection action.For more details, see the description of F05.21.	
9	Terminal UP	If the frequency is determined by external terminals,	
10	Terminal DOWN	the terminals with the two functions are used as	
11	Clear UP/ DOWN (terminal、keypad)	increment and decrement commands for frequency modification.	
12	Multi-speed terminal 1		
13	Multi-speed terminal 2	The setting of 16 speed or 16 other commands can	
14	Multi-speed terminal 3	these four terminals.	
15	Multi-speed terminal 4		
16	Pause operation	The AC drive decelerates to stop, but the running parameters are all memorized, such as PLC, swing frequency and PID parameters. After this function is disabled, the AC drive resumes its status before stop.	
17	Acc/ Dec time selection 1	Totally four groups of acceleration/deceleration time	
18	Acc/ Dec time selection 2	of these two terminals.	
19	Frequency source switchover	The terminal is used to perform switchover between two frequency sources according to the setting in F00.09.	
20	Run command switchover terminal	If the command source is set to terminal control $(F00.01=1)$, this terminal is used to perform switchover between terminal control and keypad control. If the command source is set to communication control $(F00.01=2)$, this terminal is used to perform switchover between communication control and keypad control.	



Value	Function	Description
21	Acceleration/Decelerati on prohibited	It enables the AC drive to maintain the current frequency output without being affected by external signals (except the STOP command).
22	PID pause	PID is invalid temporarily. The AC drive maintains the current frequency output without supporting PID adjustment of frequency source.
23	PLC status reset	The terminal is used to restore the original status of PLC control for the AC drive when PLC control is started again after a pause.
24	Swing pause	The AC drive outputs the central frequency, and the swing frequency function pauses.
25	Terminal count	Count once when terminal close once.
26	Counter reset	This terminal is used to clear the counter status.
27	Length count input	This terminal is used to count the length.
28	Length reset	This terminal is used to clear the length.
29	Torque control prohibited	The AC drive is prohibited from torque control and enters the speed control mode.
30	Pulse input (enabled only for HDI)	HDI is used for pulse input.
31	Reserved	reserved
32	Immediate DC braking	After this terminal becomes ON, the AC drive directly switches over to the DC braking state.
33	Normally closed (NC) input of external fault	After this terminal becomes ON, the AC drive reports E00d and stops.
34	Frequency modification forbidden	After this terminal becomes ON, the AC drive does not respond to any frequency modification.
35	Reverse PID action direction	After this terminal becomes ON, the PID action direction is reversed to the direction set in FA-03.
36	External STOP terminal 1	In operation panel mode, this terminal can be used to stop the AC drive, equivalent to the function of the STOP key on the operation panel.
37	Command source switchover terminal 2	It is used to perform switchover between terminal control and communication control. If the command source is terminal control, the system will switch over to communication control after this terminal becomes ON.



Value	Function	Description
38	PID integral pause	After this terminal becomes ON, the integral adjust- ment function pauses. However, the proportional and differentiation adjustment functions are still valid.
39	Reserved	reserved
40	Reserved	reserved
41	Motor selection terminal 1	Switchover among the two groups of motor parame- ters can be implemented through the two state combinations of these 2 two terminals.
42	Reserved	reserved
43	PID parameter switchover	If the PID parameters switchover performed by me- ans of DI terminal (F10.18 = 1), the PID parameters are F10.05 to F10.07 when the terminal becomes OFF; the PID parameters are F10.15 to F10.17 when this terminal becomes ON.
44	Reserved	reserved
45	Reserved	reserved
46	Speed control/Torque control switchover	This terminal enables the AC drive to switch over between speed control and torque control. When this terminal becomes OFF, the AC drive runs in the mode set in A03.23. When this terminal becomes ON, the AC drive switches over to the other control mode.
47	Emergency stop	When this terminal becomes ON, the AC drive stops within the shortest time. During the stop process, the current remains at the set current upper limit. This function is used to satisfy the requirement of stopping the AC drive in emergency state.
48	External STOP terminal 2	In any control mode (operation panel, terminal or communication), it can be used to make the AC drive decelerate to stop. In this case, the deceleration time is deceleration time 4.
49	Deceleration DC braking	When this terminal becomes ON, the AC drive decelerates to the initial frequency of stop DC braking and then switches over to DC braking state.



Value	Function	Description
50	Clear the current running time	When this terminal becomes ON, the AC drive's current running time is cleared. This function must be supported by F09.43 and F09.54.

The four multi-command terminals have 16 state combinations, corresponding to 16 reference values, as listed in the following table:

S1	S2	S3	S4	Multi-step speed setting	Corresponding Parameter
OFF	OFF	OFF	OFF	Multi-step speed 0	F12.02
OFF	OFF	OFF	ON	Multi-step speed 1	F12.03
OFF	OFF	ON	OFF	Multi-step speed 2	F12.04
OFF	OFF	ON	ON	Multi-step speed 3	F12.05
OFF	ON	OFF	OFF	Multi-step speed 4	F12.06
OFF	ON	OFF	ON	Multi-step speed 5	F12.07
OFF	ON	ON	OFF	Multi-step speed 6	F12.08
OFF	ON	ON	ON	Multi-step speed 7	F12.09
ON	OFF	OFF	OFF	Multi-step speed 8	F12.10
ON	OFF	OFF	ON	Multi-step speed 9	F12.11
ON	OFF	ON	OFF	Multi-step speed 10	F12.12
ON	OFF	ON	ON	Multi-step speed 11	F12.13
ON	ON	OFF	OFF	Multi-step speed 12	F12.14
ON	ON	OFF	ON	Multi-step speed 13	F12.15
ON	ON	ON	OFF	Multi-step speed 14	F12.16
ON	ON	ON	ON	Multi-step speed 15	F12.17

If the frequency source is multi-reference, the value 100% of F12.02 to F12.17 corresponds to the value of F00.03 (Maximum frequency).

Besides the multi-speed function, the multi-reference can be also used as the PID setting source or the voltage source for V/F separation, satisfying the requirement on switchover of different setting values.

Two terminals for acceleration/deceleration time selection have four state combinations, as listed in the following table.

-135-



State combinations of two terminals for acceleration/deceleration time selection as follow table:

Terminal 2	Terminal 1	Acceleration Time selection	Corresponding Parameters
OFF	OFF	Acceleration time 1	F00.12、F00.13
OFF	ON	Acceleration time 2	F09.00、F09.01
ON	OFF	Acceleration time 3	F09.02、F09.03
ON	ON	Acceleration time 4	F09.04、F09.05

State combinations of motor selection terminals as follow table:

Terminal	Selected Motor	Corresponding Parameters
OFF	Motor 1	Group F02
ON	Motor 2	Group F15

Function code	Name	Description (setting range)	Factory Default	Change
F06.10	Input terminal valid mode selection 1	0: valid on high level 1: valid on low level units' digit: S1 tens' digit: S2 hundreds' digit: S3 thousands' digit: S4 ten thousands' digit: S5	00000	•
F06.11	Input terminal polarity selection 2	0: valid on high level 1: valid on low level units' digit: S6 tens' digit: S7 hundreds' digit: S8 thousands' digit: S9 ten thousands' digit: HDI	00000	•

These parameters are used to set the valid mode of digital input DI terminals.

0: High level valid

The DI terminal (S) is valid when being connected with COM, and invalid when being disconnected from COM.



1: Low level valid

The DI terminal (S) is invalid when being connected with COM, and invalid when being disconnected from COM.

Function code	Name	Description (setting range)	Factory Default	Change
F06.12	Filtering time of switch	0.000s~1.000s	0.010s	*

It is used to set the software filter time of digital input (DI) terminal status. If DI terminals are liable to interference and may cause malfunction, increase the value of this parameter to enhance the anti-interference capability. However, increase of DI filter timewill reduce the response of DI terminals.

Function code	Name	Description (setting range)	Factory Default	Change
F06.13	Terminal control operation mode	0: 2-wire control 1 1: 2-wire control 2 2: 3-wire control 1 3: 3-wire control 2	0	•

This parameter is used to set the mode in which the AC drive is controlled by external terminals.

0:2-wire mode 1

It is the most commonly used two-line mode, in which the forward/reverse rotation of the motor is decided by K1 and K2.

1: 2-wire control 2

In this mode, K1 is RUN enabled terminal, and K2 determines the running direction.

K1	K2	RUN command
OFF	OFF	STOP
OFF	ON	Reverse RUN
ON	OFF	Forward RUN
ON	ON	STOP







K1	K2	RUN command
OFF	OFF	STOP
OFF	ON	STOP
ON	OFF	Forward RUN
ON	ON	Reverse RUN



Fig.6-13 Setting of 2-wire control 2

2: 3-wire control 1

In this mode, EN is RUN enabled terminal, and the direction is decided by Sw1 and SW3.STOP command is by normal close SW2.

SW1: forward run	<u>SW1 Ţ</u>	Sx(FWD)	
SW2: stop run SW3: reverse run	SW2	Sn(EN)	inve
EN is 3-wire run enabled terminal	<u>swa</u> Ţ	Sy(REV)	erter
		ОСМ	

Fig.6-14 Setting of 3-wire control 1

3: 3-wire control 2

In this mode, EN is RUN enabled terminal. The RUN command is given bySW1 and the direction is decided by K, EN is normal close input.

			SW1 Ţ	Sx(FWD)	
Sw1: forward run		1	SW1	Sn(EN)	inv
SW2: stop run	K	RUN command	K.Z.		ert
SW3: reverse run	OFF	Forward RUN	o	S SY(REV)	er.
EN is 3-wire run enabled terminal	ON	Reverse RUN	L	DCM	





Function code	Name	Description (setting range)	Factory Default	Change
F06.14	Terminal UP/DOWN rate	0.001Hz/s~65.535Hz/s	1.00Hz/s	*

It is used to adjust the rate of change of frequency when the frequency is adjusted by means of terminal UP/DOWN.

- If F00.11 (Frequency reference resolution) is 2, the setting range is 0.001–65.535Hz/s.
- If F00.11 (Frequency reference resolution) is 1, the setting range is 0.01–655.35Hz/s.

Function code	Name	Description (setting range)	Factory Default	Change
F06.15	S1 delay time	0.0s~3600.0s	0.0s	•
F06.16	S2 delay time	0.0s~3600.0s	0.0s	•
F06.17	S3 delay time	0.0s~3600.0s	0.0s	•

These parameters are used to set the delay time of the AC drive when the status of S termin als changes.

Currently, only S1, S2 and S3 support the delay time function

Function code	Name	Description (setting range)	Factory Default	Change
F06.18	Al1 lower limit	0.00V~F06.20	0.00V	*
F06.19	Corresponding setting of AI1 lower limit	-100.0% ~ +100.0%	0.0%	*
F06.20	AI1 upper limit	F06.18~+10.00V	10.00V	*
F06.21	Corresponding setting of AI1 upper limit	-100.0% ~ +100.0%	100.0%	*

These parameters are used to define the relationship between the analog input voltage and the corresponding setting. When the analog input voltage exceeds the maximum value (F06.20), the maximum value is used. When the analog input voltage is less than the minimum value (F06.08), the value set in F06.39 (Setting for AI less than minimum input) is used.

When the analog input is current input, 1 mA current corresponds to 0.5 V voltage.

F06.22 (Al1 filter time) is used to set the software filter time of Al1. If the analog input is liable to interference, increase the value of this parameter to stabilize the detected analog input.

-139-



However, increase of the AI filter time will slow the response of analog detection. Set this parameter properly based on actual conditions.



Fig.6-16 Corresponding relationship between analog input and setvalues

Function code	Name	Description (setting range)	Factory Default	Change
F06.21	Corresponding setting of AI1 upper limit	-100.0% ~ +100.0%	100.0%	*
F06.22	AI1 input filter time	0.00s~10.00s	0.10s	*
F06.23	AI2 low limit	0.00V~F06.25	0.00V	*
F06.24	Corresponding setting of Al2 lower limit	-100.0% ~ + 100.0%	0.0%	*
F06.25	Ai2 upper limit	F06.23~+10.00V	10.00V	*
F06.26	Corresponding setting of Al2 upper limit	-100.0% ~ +100.0%	100.0%	*
F06.27	Ai2 input filter time	0.00s~10.00s	0.10s	*

The method of setting Al2 functions is similar to that of setting Al1 function.

Function code	Name	Description (setting range)	Factory Default	Change
F06.28	Ai3 lower limit	-10.00V~F06.30	0.10V	*
F06.29	Corresponding setting of AI3 lower limit	-100.0% ~ +100.0%	0	*



Function code	Name	Description (setting range)	Factory Default	Change
F06.30	Ai3 upper limit	F06.28~+10.00V	4.00V	*
F06.31	Corresponding setting of AI3 upper limit	-100.0% ~ +100.0%	100.0%	*
F06.32	Ai3 input filter time	0.00s~10.00s	0.10s 🧹	*

The method of setting AI3 functions is similar to that of setting AI1 function.

Function code	Name	Description (setting range)	Factory Default	Change
F06.33	HDI lower limit	0.00kHz~F06.35	0.00kHz	*
F06.34	Corresponding setting of HDI lower limit	-100.0% ~ +100.0%	0.0%	*
F06.35	HDI upper limit	F06.33~+100.00kHz	50.00kHz	*
F06.36	Corresponding setting of HDI upper limit	-100.0% ~ +100.0%	100.0%	*
F06.37	HDI frequency input filter time	0.00s~10.00s	0.10s	*

These parameters are used to set the relationship between HDI pulse input and corresponding settings. The pulses can only be input by HDI. The method of setting this function is similar to that of setting Al1 function.

Function code	Name	Description (setting range)	Factory Default	Change
F06.38	AI curve selection	units'digit: Al curve selection 1: curve 1(2 point, see F06.18 ~ F06.21) 2: curve 2(2 point, see F06.23 ~ F06.26) 3: curve 3(2 point, see F06.28 ~ F06.31) 4: curve 4(4 point, see F06.40 ~ F06.47) 5: curve 5(4 point, see F06.48 ~ F06.55)	H.321	*



Function code	Name	Description (setting range)	Factory Default	Change
F06.38	AI curve selection	tens'digit: Al2 curve selection hundreds'digit: Al3 curve selection	H.321	*

The unit's digit, ten's digit and hundred's digit of this parameter are respectively used to select the corresponding curve of AI1, AI2 and AI3. Any of the five curves can be selected for AI1, AI2 and AI3.

Curve 1, curve 2 and curve 3 are all 2-point curves, set in group F4. Curve 4 and curve 5 are both 4-point curves.

Function code	Name	Description (setting range)	Factory Default	Change
F06.39	Setting for AI less than minimum input	units'digit:(setting for Al1 less than minimum input) 0: corresponding to the minimum input set 1: 0.0% tens'digit:(setting for Al2 less than minimum input) setting selection hundreds'digit:(setting for Al3 less than minimum input)	H.000	*

This parameter is used to determine the corresponding setting when the analog input voltage is less than the minimum value.

The unit's digit, ten's digit and hundred's digit of this parameter respectively correspond to the setting for Al2, Al2 and Al3.If the value of a certain digit is 0, when analog input voltage is less than the minimum input, the corresponding setting of the minimum input (F06.19, F06.24, F06.29) is used.If the value of a certain digit is 1, when analog input voltage is less than the minimum input, the corresponding value of this analog input is 0.0%.



Function code	Name	Description (setting range)	Factory Default	Change
F06.40	AI curve 4 lower limit	-10.00V~F06.42	0.00V	*
F06.41	AI curve 4 lower limit setting	-100.0% ~ +100.0%	0.0%	*
F06.42	Al curve 4 inflection point 1 input	F06.40 ~ F06.44	3.00V	*
F06.43	AI curve 4 inflection point 1 input setting	-100.0% ~ +100.0%	30.0%	*
F06.44	Al curve 4 inflection point 2 input	F06.42~F06.46	6.00V	*
F06.45	AI curve 4 inflection point 2 input setting	- 100.0% ~ +100.0%	60.0%	*
F06.46	AI curve 4 upper limit	F06.44 ~ + 10.00V	10.00V	*
F06.47	AI curve 4 upper limit setting	-100.0% ~ +100.0%	100.0%	*
F06.48	AI curve 5 lower limit	-10.00V ~ F06.50	- 10.00V	*
F06.49	AI curve 5 lower limit setting	-100.0% ~ +100.0%	- 100.0%	*
F06.50	Al curve 5 inflection point 1 input	F06.48 ~ F06.52	- 3.00V	*
F06.51	Al curve 5 inflection point 1 setting	-100.0% ~ +100.0%	- 30.0%	*
F06.52	Al curve 5 inflection point 2 input	F06.50 ~ F06.54	3.00V	*
F06.53	Al curve 5 inflection point 2 setting	-100.0% ~ +100.0%	30.0%	*
F06.54	Al curve 5 upper limit	F06.52 ~ +10.00V	10.00V	*
F06.55	AI curve 5 upper limit setting	-100.0% ~ +100.0%	100.0%	*




Fig.6-17 Curve 4 and curve 5

When setting curve 4 and curve 5, it should be noted that the minimum input voltage, inflection point 1 voltage, inflection point 2 voltage, and maximum voltage of the curve must increase sequentially.

Al curve selection F06.38 is used to determine how to select the analog input Al1~Al3 among 5 curves.

Function code	Name	Description (setting range)	Factory Default	Change
F06.64	AI1 jump point setting	-100.0% ~ 100.0%	0.0%	*
F06.65	AI1 jump point range setting	0.0% ~ 100.0%	0.5%	*
F06.66	AI2 jump point setting	-100.0% ~ 100.0%	0.0%	*
F06.67	Al2 jump point range setting	0.0% ~ 100.0%	0.5%	*
F06.68	AI3 jump point setting	-100.0% ~ 100.0%	0.0%	*
F06.69	AI3 jump point range setting	0.0% ~ 100.0%	0.5%	*

The analog input AI1~AI3 all have the function of setting value jumping.

The jump function means that when the corresponding setting of the analog quantity changes between the upper and lower intervals of the jump point, the corresponding setting value of the analog quantity is fixed to the value of the jump point.



For example:

the voltage of the analog input AI1 fluctuates around 5.00V, the fluctuation range is 4.90V~ 5.10V, the minimum input of AI1 is 0.00V corresponds to 0.0%, and the maximum input of 10.00V corresponds to 100.%, then the detected AI1 corresponds to the setting It fluctuates between 49.0% and 51.0%. Set AI1 to set jump point F06.64 to 50.0%, set AI1 to set jump amplitude F06.65 to 1.0%, then when the above AI1 input is processed by the jump function, the corresponding setting of AI1 input is fixed to 50.0%. AI1 is transformed into a stable input, eliminating fluctuations.

-145-



Group F07: Output Terminals

The provides 2 analog output (AO) terminal, 1 open-collector switch signal output, 2 relay terminal and a HDO terminal (used for high-speed pulse output or open-collector switch signal output) as standard. If these output terminals cannot satisfy requirements, use an optional I/O extension card that provides an AO terminal (AO2), a relay terminal(relay 2) and a DO terminal (Do2).

Function code	Name	Description (setting range)	Factory Default	Change
F07.00	HDO terminal output mode	0: Pulse output (HDOP) 1: Switch signal output(HDOR)	0	*
F07.01	HDOR output selection	0: no output 1: freuency reached	0	*
F07.02	Relay TA output selection (TA* TB* TC)	 2: frequency-level detection FDT1 output 3: fault output (stop) 4: motor overload pre- warning 5: AC drive overload pre- warning 	3	*
F07.03	Relay RA output selection(RA* RB* RC)		0	*
F07.04	Mo1 output selection		1	*

These five parameters are used to select the functions of the five digital output terminals. TA*TB*TC and RA*RB*RC are respectively the relays on the controlboard.

Value	Function	Description
0	no output	The terminal has no function.
1	freuency reached	Refer to the descriptions of F09.24.
2	frequency-level detection FDT1 output	Refer to the descriptions of F09.20 and F09.21
3	fault output (stop)	When the AC drive stops due to a fault, the terminal becomes ON.
4	motor overload pre-warning	The AC drive judges whether the motor load exceeds the overload pre-warning threshold before performing the protection action. If the pre-warning threshold is exceeded, the terminal becomes ON. For motor overload parameters, see the descriptions of F05.09 to F05.11.



Value	Function	Description
5	AC drive overload pre-warning	The terminal becomes ON 10s before the AC drive overload protection action is performed.
6	zero-speed running(no output at stop)	If the AC drive runs with the output frequency of 0, the terminal becomes ON. If the AC drive is in the stop state, the terminal becomes OFF.
7	zero-speed running 2 (no output at stop	If the output frequency of the AC drive is 0, the terminal becomes ON. In the state of stop, the signal is still ON.
8	frequency upper limit reached	If the running frequency reaches the upper limit, the terminal becomes ON.
9	frequency lower limit reached (no output at stop)	If the running frequency reaches the lower limit, the terminal becomes ON. In the stop state, the terminal becomes OFF.
10	set count value reached	The terminal becomes ON when the count value reaches the value set in F11.08.
11	designated count value reached	The terminal becomes ON when the count value reaches the value set in F11.09.
12	length reached	The terminal becomes ON when the detected actual length exceeds the value set in F11.05.
13	PLC cycle complete	When simple PLC completes one cycle, the terminal outputs a pulse signal with width of 250 ms.
14	accumulative running time reached	If the accumulative running time of the AC drive exceeds the time set in F09.16, the terminal becomes ON.
15	frequency limited	If the set frequency exceeds the frequency upper limit or lower limit and the output frequency of the AC drive reaches the upper limit or lower limit, the terminal becomes ON.
16	torque limited	In speed control mode, if the output torque reaches the torque limit, the AC drive enters the stall protection state and meanwhile the terminal becomes ON.
17	torque limited	If the AC drive main circuit and control circuit become stable, and the AC drive detects no fault and is ready for RUN, the terminal becomes ON.
18	AC drive running	When the AC drive is running and has output frequency (can be zero), the terminal becomes ON



Value	Function	Description
19	Ai1> Ai2	When the input of AI1 is larger than the input of AI2, the terminal becomes ON.
20	undervoltage state output	If the AC drive is in undervoltage state, the terminal becomes ON.
21	reserved	reserved
22	reserved	reserved
23	reserved	reserved
24	accumulative power-on time reached	If the AC drive accumulative power-on time (F08.13) exceeds the value set in F09.15, the terminal becomes ON.
25	frequency level detection FDT2 output	Refer to the descriptions of F09.22 and F09.23.
26	frequency 1 reached	Refer to the descriptions of F09.31 and F09.32.
27	frequency 2 reached	Refer to the descriptions of F09.33 and F09.34.
28	current 1 reached	Refer to the descriptions of F09.39 and F09.40.
29	current 2 reached	Refer to the descriptions of F09.41 and F09.42.
30	timing reached	If the timing function (F09.43) is valid, the terminal becomes ON after the current running time of the AC drive reaches the set time.
31	Ai1 input limit exceeded	If Al1 input is larger than the value of F09.47 (Al1 input voltage upper limit) or lower than the value of F09.46 (Al1 input voltage lower limit), the terminal becomes ON.
32	load becoming 0	If the load becomes 0, the terminal becomes ON.
33	reverse running	If the AC drive is in the reverse running state, the terminal becomes ON.
34	zero current state	Refer to the descriptions of F09.22 and F09.23.
35	module temperature reached	If the heatsink temperature of the inverter module (F08.08) reaches the set module temperature threshold (F09.48), the terminal becomes ON.
36	output current limit exceeded	Refer to the descriptions of F09.37 and F09.38.

Value	Function	Description
37	frequency lower limit reached(having output at stop)	If the running frequency reaches the lower limit, the terminal becomes ON. In the stop state, the signal is still ON.
38	alarm output(keep running)	If a fault occurs on the AC drive and the AC drive continues to run, the terminal outputs the alarm signal.
39	motor overheat warning	If the motor temperature reaches the temperature set in F05.59 (motor overheat warning threshold), the terminal becomes ON.
40	current running time reached	If the current running time of AC drive exceeds the value of F09.54, the terminal becomes ON.

Function code	Name	Description (setting range)	Factory Default	Change
F07.06	Output terminal valid mode selection	0: Positive logic 1: Negative logic Unit's digit: HDO Ten's digit:TA Hundred's digit: RA Thousand's digit: MO1	0000	*

It is used to set the logic of output terminals HDO, relay 1, relay 2, Mo1.

0: Positive logic

The output terminal is valid when being connected with COM, and invalid when being disconnected from COM.

1: Positive logic

The output terminal is invalid when being connected with COM, and valid when being disconnected from COM.

Function code	Name	Description (setting range)	Factory Default	Change
F07.07	HDO delay time	0.0s~3600.0s	0.0s	*
F07.08	TA delay time	0.0s~3600.0s	0.0s	*
F07.09	RA delay time	0.0s~3600.0s	0.0s	*
F07.10	Mo1 output delay time	0.0s~3600.0s	0.0s	*



These parameters are used to set the delay time of output terminals HDO, relay 1, relay 2, MO1 from status change to actual output.

Function code	Name	Description (setting range)	Factory Default	Change
F07.12	HDOP output selection		0	*
F07.13	Ao1 output selection	0~15	0	*
F07.14	Ao2 output selection		1	*

The output pulse frequency of the HDOP terminal ranges from 0.01 kHz to "HDO output max.frequency" (F07.22). The value of F07.22 is between 0.01 kHz and 100.00kHz.

The output range of AO1 and AO2 is 0-10V or 0-20mA. The relationship between pulse and analog output ranges and corresponding functions is listed in the following table:

Value	Function	Description
0	setting frequency	0 to maximum output frequency
1	running frequency	0 to maximum output frequency
2	output current	0 to 2 times of rated motor current
3	output voltage	0 to 1.2 times of rated AC drive voltage
4	output speed	0 to rotational speed corresponding to maximum output frequency
5	output torque	0 to 2 times of rated motor torque
6	output power	0 to 2 times of rated power
7	pulse input	0.01kHz ~ 100.00kHz
8	Al1	0V ~ 10V
9	AI2	0V ~ 10V (or 0 ~ 20mA)
10	AI3	0V ~ 10V
11	lenth	0 to maximum set length
12	count value	0 to maximum count value
13	Rs485 communication	0.0% ~ 100.0%
14	output current 100% corresponding to 1000.0A	0.0A ~ 1000.0A



Value	Function	Description
0	setting frequency	0 to maximum output frequency
15	output voltage 100% corresponding to 1000.0V	0.0V~1000.0V

Function code	Name	Description (setting range)	Factory Default	Change
F07.15	AO1 offset coefficient	-100.0% ~ 100.0%	0.0%	*
F07.16	AO1 gain	-10.00~+10.00	1.00	*
F07.17	AO2 offset coefficient	-100.0% ~ 100.0%	0.0%	*
F07.18	AO2 gain	-10.00 ~ +10.00	1.00	*

These parameters are used to correct the zero drift of analog output and the output amplitude deviation. They can also be used to define the desired AO curve.

If "b" represents zero offset, "k" represents gain, "Y" represents actual output, and "X" represents standard output, the actual output is: Y= kX+b.

The zero offset coefficient 100% of AO1 and AO2 corresponds to 10V (or 20 mA). The standard output refers to the value corresponding to the analog output of 0 to 10V (or 0 to 20 mA) with no zero offset or gain adjustment.

For example, if the analog output is used as the running frequency, and it is expected that the output is 8V when the frequency is 0 and 3V at the maximum frequency, the gain shall be set to -0.50, and the zero offset shall be set to 80%.

Function code	Name	Description (setting range)	Factory Default	Change
F07.19	AO1 output filter time	0~10.00	0	*
F07.20	AO2 output filter time	0~10.00	0	*
F07.21	HDO output filter time	0~10.00	0	*
F07.22	HDO output max.frequency	0.01kHz~100.00kHz	50.00kHz	*

This function code is used to select max.frequency of output pulse when HDO ternimal as \ensuremath{p} ulse output.

-151-



Group F08: Keypad And Display

Function code	Name	Description (setting range)	Factory Default	Change
F08.00	User password	0~65535	0	*

Press FUNC/DATA key to confirm password.

Don't press again within 1 minute, password will saved.

If no need password, setting to 00000.

Function code	Name	Description (setting range)	Factory Default	Change
F08.02	STOP key function selection	0: STOP/RST key enabled only in keypad control 1: STOP/RST key enabled in any operation mode	1	*
F08.03	LED display running parameters 1	0000-FFFF	H.008F	*



If a parameter needs to be displayed during the running, set the corresponding bit to 1, and set F08.03 to the hexadecimal equivalent of this binary number.





If a parameter needs to be displayed during the running, set the corresponding bit to 1, and set F08.04 to the hexadecimal equivalent of this binary number.

These two parameters are used to set the parameters that can be viewed when the AC drive is in the running state. You can view a maximum of 32 running state parameters that are displayed from the lowest bit of F08.03.

Function code	Name	Description (setting range)	Factory Default	Change
F08.05	LED display stop parameters	0000-FFFF	H.0063	*





If a parameter needs to be displayed during the running, set the corresponding bit to 1, and set F08.05 to the hexadecimal equivalent of this binary number.

Function code	Name	Description (setting range)	Factory Default	Change
F08.06	Load speed display coefficient	0.0001 ~ 6.5000	- 1.0000	*

This parameter is used to adjust the relationship between the output frequency of the AC drive and the load speed. For details, see the description of F08.12.

Function code	Name	Description (setting range)	Factory Default	Change
F08.07	Auxiliary LED display selection	0~16	2	*
F08.08	Heatsink temperature of inverter module	0.0°C ~ 100.0°C	_	**
F08.09	Software version		—	**



Function code	Name	Description (setting range)	Factory Default	Change
F08.10	Accumulative running time	0h ~ 65535h	—	**
F08.11	Product number	—	—	**

These function code can not be modify.

Heatsink temperature of inverter module is used to display the insulated gate bipolar transistor (IGBT) temperature of the inverter module, and the IGBT overheat protection value of the inverter module depends on themodel.

Function code	Name	Description (setting range)	Factory Default	Change
F08.12	Number of decimal places for load speed display	0: 0 decimal place 1: 1 decimal place 2: 2 decimal places 3: 3 decimal places	1	*

F08.12 is used to set the number of decimal places for load speed display. The following gives an example to explain how to calculate the load speed:

Assume that F08.06 (Load speed display coefficient) is 2.000 and F08.12 is 2 (2 decimal places). When the running frequency of the AC drive is 40.00 Hz, the load speed is

40.00x2.000=80.00 (display of 2 decimal places).

If the AC drive is in the stop state, the load speed is the speed corresponding to the set frequency, namely, "set load speed". If the set frequency is 50.00 Hz, the load speed in the stop state is $50.00 \times 2.000 = 100.00$ (display of 2 decimal places).

Function code	Name	Description (setting range)	Factory Default	Change
F08.13	Accumulative power-on time	0h ~ 65535h	_	**

It is used to display the accumulative power-on time of the AC drive since the delivery. If the time reaches the set power-on time (F09.16), the terminal with the digital output function 24 becomes ON.

-155-



Function code	Name	Description (setting range)	Factory Default	Change
F08.14	Accumulative power consumption	0–65535 kWh	_	**

It is used to display the accumulative power consumption of the AC drive until now.



Group F09: Auxiliary Functions

Function code	Name	Description (setting range)	Factory Default	Change
F09.00	Acceleration time 2	0.0s~6500.0s	Model dependent	*
F09.01	Deceleration time 2	0.0s~6500.0s	Model dependent	*
F09.02	Acceleration time 3	0.0s~6500.0s	Model dependent	*
F09.03	Deceleration time 3	0.0s~6500.0s	Model dependent	*
F09.04	Acceleration time 4	0.0s~6500.0s	Model dependent	*
F09.05	Deceleration time 4	0.0s~6500.0s	Model dependent	*

The provides a total of four groups of acceleration/deceleration time, that is, the preceding three groups and the group defined by F00.12 and F00.13. Definitions of four groups are completely the same. You can switch over between the four groups of acceleration/deceleration time through different state combinations of digital input(S) terminals. For more details, see the descriptions of F06.01 to F06.05.

Function code	Name	Description (setting range)	Factory Default	Change
F09.06	JOG running frequency	0.00Hz ~ F00.03(max. frequency)	2.00Hz	*
F09.07	JOG acceleration time	0.0s~6500.0s	20.0s	*
F09.08	JOG deceleration time	0.0s~6500.0s	20.0s	*

These parameters are used to define the set frequency and acceleration/deceleration time of the AC drive when jogging. The startup mode is "Direct start" (F01.00=0) and the stop mode is "Decelerate to stop" (F01.08=0) during jogging.

Function code	Name	Description (setting range)	Factory Default	Change
F09.09	Jump frequency 1	0.00Hz ~ F00.03(max. frequency)	0.00Hz	*
F09.10	Jump frequency 2	0.00Hz ~ F00.03(max. frequency)	0.00Hz	*
F09.11	Frequency jump amplitude	0.00Hz ~ F00.03(max. frequency)	0.00Hz	*



If the set frequency is within the frequency jump range, the actual running frequency is the jump frequency close to the set frequency. Setting the jump frequency helps to avoid the mechanical resonance point of the load.

The supports two jump frequencies. If both are set to 0, the frequency jump function is disabled. The principle of the jump frequencies and jump amplitude is shown in the following figure 6-15.





Function code	Name	Description (setting range)	Factory Default	Change
F09.12	Forward/Reverse rotation dead-zone time	0.0s~3000.0s	0.0s	*

It is used to set the time when the output is 0 Hz at transition of the AC drive forward rotation and reverse rotation, as shown in the following figure.



Fig.6-19 Forward/Reverse rotation dead-zone time



Function code	Name	Description (setting range)	Factory Default	Change
F09.13	Reverse control	0: enabled 1: disabled	0	*

It is used to set whether the AC drive allows reverse rotation. In the applications where reverse rotation is prohibited, set this parameter to 1.

Function code	Name	Description (setting range)	Factory Default	Change
F09.14	Running mode when set frequency lower than frequency lower limit	0:run at frequency lower limit 1: stop 2: run at zero speed	0	*

It is used to set the AC drive running mode when the set frequency is lower than the frequency lower limit. The provides three running modes to satisfy requirements of various applications.

Function code	Name	Description (setting range)	Factory Default	Change
F09.15	Accumulative power-on time threshold	0.0s~6500.0s	0h	*

If the accumulative power-on time (F7-13) reaches the value set in this parameter, the corresponding DO terminal becomes ON.

Function code	Name	Description (setting range)	Factory Default	Change
F09.16	Accumulative running time threshold	0.0s~6500.0s	0h	*

It is used to set the accumulative running time threshold of the AC drive. If the accumulative running time (F08.10) reaches the value set in this parameter, the corresponding DO terminal becomes ON.

Function code	Name	Description (setting range)	Factory Default	Change
F09.17	Startup protection	0: No 1: Yes	0	*



This parameter is used to set whether to enable the safety protection. If it is set to 1, the AC drive does not respond to the run command valid upon AC drive power-on (for example, an input terminal is ON before power-on). The AC drive responds only after the run command is cancelled and becomes valid again.

In addition, the AC drive does not respond to the run command valid upon fault reset of the AC drive. The run protection can be disabled only after the run command is cancelled. In this way, the motor can be protected from responding to run commands upon power-onor fault reset in unexpected conditions.

Function code	Name	Description (setting range)	Factory Default	Change
F09.18	Droop control	0.00Hz ~ 10.00Hz	0.00Hz	*

This function is used for balancing the workload allocation when multiple motors are used to drive the same load. The output frequency of the AC drives decreases as the load increases. You can reduce the workload of the motor under load by decreasing the output frequency for this motor, implementing workload balancing between multiple motors.

Function code	Name	Description (setting range)	Factory Default	Change
F09.19	Motor switchover	0: Motor 1 1: Motor 2	0	•
F09.20	Frequency detection value(FDT1)	0.00Hz ~ F00.03(max. frequency)	50.00Hz	*
F09.21	Frequency detection hysteresis (FDT hysteresis 1)	0.0% ~ 100.0% (FDT1 level)	5.0%	*
F09.22	Frequency detection value(FDT2)	0.00Hz ~ F00.03(max. frequency)	50.00Hz	*
F09.23	Frequency detection hysteresis (FDT hysteresis 2)	0.0% ~ 100.0%(FDT2 level)	5.0%	*

If the running frequency is higher than the value of F09.20, thecorresponding multi-function output terminal becomes ON. If the running frequency is lower than value of F09.20, multi-function output terminal goes OFF.

These two parameters are respectively used to set the detection value of output frequency and hysteresis value upon cancellation of the output. The value of F09.21 is a percentage of the hysteresis frequency to the frequency detection value (F09.20).





Fig.6-20 The FDTfunction

Function code	Name	Description (setting range)	Factory Default	Change
F09.24	Detection range of	0.0% ~ 100.0%(F00.03(0.0%	*
	frequency reached	max. frequency))	0.0%	

If the AC drive running frequency is within the certain range of the set frequency, the corresponding multi-function output terminal becomes ON.

This parameter is used to set the range within which the output frequency is detected to reach the set frequency. The value of this parameter is a percentage relative to the maximum frequency. The detection range of frequency reached is shown in the following figure.



Fig.6-21 Detection range of frequency reached

-161-



Function code	Name	Description (setting range)	Factory Default	Change
F09.25	Jump frequency during acceleration/deceleration/	0: disabled 1: enabled	0	*

It is used to set whether the jump frequencies are valid during acceleration/deceleration.

When the jump frequencies are valid during acceleration/deceleration, and the running frequency is within the frequency jump range, the actual running frequency will jump over the set frequency jump amplitude (rise directly from the lowest jump frequency to the highest jump frequency). The following figure shows the diagram when the jump frequencies are valid during acceleration/deceleration.



Fig.6-22 Diagram when the jump frequencies are valid during acceleration/deceleration

Function code	Name	Description (setting range)	Factory Default	Change
F09.28	Frequency switchover point between acceleration time 1 and acceleration time 2	0.00Hz ~ F00.03(max. frequency)	0.00Hz	*
F09.29	Frequency switchover point between deceleration time 1 and deceleration time 2	0.00Hz~F00.03(max. frequency)	0.00Hz	*

This function is valid when motor 1 is selected and acceleration/deceleration time switchover is not performed by means of S terminal. It is used to select different groups of acceleration/deceleration time based on the running frequency range rather than S terminal during the running process of the AC drive.





Fig.6-23 Acceleration/deceleration times witchover

During acceleration, if the running frequency is smaller than the value of F09.28, acceleration time 2 is selected. If the running frequency is larger than the value of F09.28, acceleration time 1 is selected.

During deceleration, if the running frequency is larger than the value of F09.29, deceleration time 1 is selected. If the running frequency is smaller than the value of F09.29, deceleration time 2 is selected.

Function code	Name	Description (setting range)	Factory Default	Change
F09.30	Terminal JOG preferred	0: disabled 1: enabled	0	*

It is used to set whether terminal JOG is preferred.

If terminal JOG is preferred, the AC drive switches to terminal JOG running state when there is a terminal JOG command during the running process of the AC drive.

Function code	Name	Description (setting range)	Factory Default	Change
F09.31	Any frequency reaching detection value 1	0.00Hz~F00.03(max. frequency)	50.00Hz	*
F09.32	Any frequency reaching detection amplitude 1	0.0% ~ 100.0%(F00.03(max. frequency)	0.0%	*
F09.33	Any frequency reaching detection value 2	0.00Hz ~ F00.03(max. frequency)	50.00Hz	*
F09.34	Any frequency reaching detection amplitude 2	0.0% ~ 100.0%(F00.03(max. frequency)	0.0%	*



If the output frequency of the AC drive is within the positive and negative amplitudes of the any frequency reaching detection value, the corresponding multi-function output becomes ON.The provides two groups of any frequency reaching detection parameters, inclu-ding frequency detection value and detection amplitude, as shown in the following figure.



Fig.6-24 Any frequency reaching detection

Function code	Name	Description (setting range)	Factory Default	Change
F09.35	Zero current detection level	0.0% ~ 300.0%(rated motor current)	5.0%	*
F09.36	Zero current detection delay time	0.01s~600.00s	0.10s	*

If the output current of the AC drive is equal to or less than the zero current detection level and the duration exceeds the zero current detection delay time, the corresponding multifunction output terminal becomes ON.

The zero current detection is shown in the following figure:







Function code	Name	Description (setting range)	Factory Default	Change
F09.37	Output overcurrent threshold	1.1% (no detection) 1.2%–300.0% (rated motor current)	200.0%	*
F09.38	Output overcurrent detectio delay time	0.00s~600.00s	0.00s	*

If the output current of the AC drive is equal to or higher than the overcurrent threshold and the duration exceeds the detection delay time, the corresponding multi-function output terminal becomes ON. The output overcurrent detection function is shown in the following figure.



Fig.6-26 Output overcurrent detection

Function code	Name	Description (setting range)	Factory Default	Change
F09.39	Any current reaching 1	0.0% ~ 300.0% ((rated motor current)	100.0%	*
F09.40	Any current reaching 1 amplitude	0.0% ~ 300.0% (rated motor current)	0.0%	*
F09.41	Any current reaching 2	0.0% ~ 300.0% (rated motor current)	100.0%	*
F09.42	Any current reaching 2 amplitude	0.0% ~ 300.0% (rated motor current)	0.0%	*

If the output current of the AC drive is within the positive and negative amplitudes of any current reaching detection value, the corresponding multi-function output terminal becomes ON.

The provides two groups of any current reaching detection parameters, including current detection value and detection amplitudes, as shown in the following figure.





Fig.6-27 Any current reaching detection

Function code	Name	Description (setting range)	Factory Default	Change
F09.43	Timing function	0: Disabled 1: Enabled	0	*
F09.44	Timing duration source	0: F09.45 1: analog Al1 2: analog Al2 3: analog Al3 (Analog input range corresponds to F09.45)	0	*
F09.45	Timing duration	0.0Min ~ 6500.0Min	0.0Min	*

These parameters are used to implement the AC drive timing function.

If F09.43 is set to 1, the AC drive starts to time at startup. When the set timing duration is reached, the AC drive stops automatically and meanwhile the corresponding multi-function terminal output becomes ON.

The AC drive starts timing from 0 each time it starts up and the remaining timing duration. The timing duration is set in F09.44 and F09.45, in unit of minute.

Function code	Name	Description (setting range)	Factory Default	Change
F09.46	Al1 input voltage lower limit	0.00V~F09.47	3.10V	*
F09.47	Al1 input voltage upper limit	F09.46~10.00V	6.80V	*



These two parameters are used to set the limits of the input voltage to provide protection on the AC drive. When the Al1 input is larger than the value of F09.47 or smaller than the value of F09.46, the corresponding multi-function output terminal becomes ON, indicating that Al1 input exceeds the limit.

Function code	Name	Description (setting range)	Factory Default	Change
F09.48	Module temperature threshold	0°C ~ 100°C	75°C	*

When the heatsink temperature of the AC drive reaches the value of this parameter, the corresponding multi-function output terminal becomes ON, indicating that the module temperature reaches the threshold.

Function code	Name	Description (setting range)	Factory Default	Change
F09.49	Cooling fan control	0: Fan working during running1: Fan working continuously	0	*

It is used to set the working mode of the cooling fan. If this parameter is set to 0, the fan works when the AC drive is in running state. When the AC drive stops, the cooling fan works if the heatsink temperature is higher than 40°C, and stops working if the heatsink temperature is lower than 40°C.

If this parameter is set to 1, the cooling fan keeps working after power-on.

Function code	Name	Description (setting range)	Factory Default	Change
F09.50	Wake up pressure	0.0~F10.04 (PID given feedback range)	0.0	*
F09.51	Wake up delay time	0.0s~6500.0s	0.0s	*
F09.52	Dormant frequency	0.0Hz~F00.3 (maximum frequency)	0.00Hz	*
F09.53	Dormant delay time	0.0s~6500.0s	0.0s	*

These parameters are used to implement the dormant and wakeup functions in the water supply application.

When the AC drive is in running state, the AC drive enters the dormant state and stops automatically after the dormant delay time (F09.53) if the set frequency is lower than or equal to the dormant frequency (F09.52). Chapter 6

-167-



When the AC drive is in dormant state and the current running command is effective, the AC drives starts up after the wakeup delay time (F09.51) if the set frequency is higher than or equal to the wakeup frequency (F09.50).

Generally, set the wakeup frequency equal to or higher than the dormant frequency. If the wakeup frequency and dormant frequency are set to 0, the dormant and wakeup functions are disabled.

When the dormant function is enabled, if the frequency source is PID, whether PID operation is performed in the dormant state is determined by F10-28. In this case, select PID operation enabled in the stop state (F10.28 = 1).

Function code	Name	Description (setting range)	Factory Default	Change
F09.54	Current running time reached	0.0Min ~ 6500.0Min	0.0Min	*

If the current running time reaches the value set in this parameter, the corresponding multifunction output terminal becomes ON, indicating that the current running time is reached.

Function code	Name	Description (setting range)	Factory Default	Change
F09.55	DPWM switchover running frequency upper limit	0.00Hz ~ 15.00Hz	12.00Hz	*

Only valid for V/F control. The wave generation mode of the asynchronous motor V/F operation is determined. If the value is lower than this value, it is a 7-segment continuous modulation mode. On the contrary, it is a 5-segment discontinuous modulation mode.

When it is 7-stage continuous modulation, the switching loss of the inverter is large, but the current ripple is small; in the 5-stage intermittent debugging mode, the switching loss is small and the current ripple is large; but at high frequency, it may cause The instability of the motor operation generally does not need to be modified.

For V/F running instability, please refer to function code F04.11, and for inverter loss and temperature rise, please refer to function code F00.17.

Function code	Name	Description (setting range)	Factory Default	Change
F09.56	PWM modulation system	0: asynchronous modulation 1: synchronous modulation	0	*



Only valid for V/F control. Synchronous modulation means that the carrier frequency changes linearly with the output frequency, ensuring that the ratio of the two (carrier ratio) remains unchanged. Generally, it is used when the output frequency is high, which is beneficial to the output voltage quality.

When the output frequency is lower (below 100Hz), synchronous modulation is generally not required, because the ratio of the carrier frequency to the output frequency is relatively high at this time, and the advantages of asynchronous modulation are more obvious.

Synchronous modulation takes effect only when the operating frequency is higher than 85Hz, and asynchronous modulation is fixed below this frequency.

Function code	Name	Description (setting range)	Factory Default	Change
F09.57	Dead zone compensation mode selection	0: no compensation 1: compensation mode 1 2: compensation mode 2	1	*

This parameter is no need to modify normally, only if special request of output voltage wave, or motor oscillation.

High power suggest compensation modes 2.

Function code	Name	Description (setting range)	Factory Default	Change
F09.58	Depth of PWM random	0: PWM random disabled 1 ~ 10: PWM carrier frequen- cy random depth	0	*

Setting random PWM can soften the monotonous and harsh motor sound and help reduce external electromagnetic interference. When the random PWM depth is set to 0, the random PWM is invalid. Adjusting random PWM with different depths will get different effects.

Function code	Name	Description (setting range)	Factory Default	Change
F09.59	Rapid current limit	0: Disabled 1: Enabled	1	*

This parameter can be used in overcurrent protection.

If repid current limit long time, AC drive will overheat and cause drivedamaged.

-169



Function code	Name	Description (setting range)	Factory Default	Change
F09.60	Current detection compensation	0~100	5	*

It is used to set the current detection compensation of the inverter. If the setting is too large, the control performance may be degraded. Usually no modification is required.

Function code	unction Name	Description (setting range)	Factory Default	Change
F09.61	Under-voltage point	60.0% ~ 140.0%	100.0%	*

It is used to set the voltage value of inverter undervoltage fault E001. 100.0% of inverters with different voltage levels correspond to different voltage points, which are:

Voltage class	Under-voltage point base value
Single phase 220V	200V
Three phase 220V	200V
Three phase 380V	350V
Three phase 480V	350V
Three phase 690V	650V
Three phase 1140V	1350V

Function code	Name	Description (setting range)	Factory Default	Change
	SVC optimize mode	0: no optimize		
F09.62		1: optimize mode 1	1	*
	selection	2: optimize mode 2		

Optimize mode 1: can be used in application need high torque control.

Optimize mode 2: can be used in application need high speed control.

Function code	Name	Description (setting range)	Factory Default	Change
F09.63	Dead-zone time adjustment	100% ~ 200%	150%	*



Set for 1140V voltage level. Adjusting this value can improve the effective utilization rate of the voltage, and if the adjustment is too small, it will easily lead to unstable system operation. User modification is not recommended

Function code	Name	Description (setting range)	Factory Default	Change
F09.64	Over-voltage point	200.0V~2500.0V	Model dependent	*

It is used to set the voltage value of the inverter overvoltage fault. The factory value of different voltage levels is:

Voltage class	Under-voltage point base value
Single phase 220V	400.0V
Three phase 220V	400.0V
Three phase 380V	810.0V
Three phase 480V	890.0V
Three phase 690V	1300.0V
Three phase 1140V	2000.0V



Group F10: Process Control PID Function

PID control is a general process control method. By performing proportional, integral and differential operations on the difference between the feedback signal and the target signal, it adjusts the output frequency and constitutes a feedback system to stabilize the controlled counter around the target value.

It is applied to process control such as flow control, pressure control and temperature control. The following figure shows the principle block diagram of PID control.



Fig.6-28 Principle block diagram of PID control

Function code	Name	Description (setting range)	Factory Default	Change
F10.00	PID setting source	0: Keypad (F10.01) 1: Analog Al1 2: Analog Al2 3: Analog Al3 4: Pulse setting (HDI) 5: Rs485 communication setting 6: Multi-speed command 7:Panel potentiometer setting	0	*
F10.01	Keyboard preset PID given	0.0~F10.04 (PID given feedback range)	5.0	*

F00.06 is used to select the channel of target process PID setting. The PID setting is a relative value and ranges from 0.0% to 100.0%. The PID feedback is also a relative value. The purpose of PID control is to make the PID setting and PID feedback equal.



Function code	Name	Description (setting range)	Factory Default	Change
F10.02	PID feedback source	0: Al1 1: Al2 2: Al3 3: Al1–Al2 4: Pulse setting(HDI) 5: Rs485 communication setting 6: Al1 + Al2 7: MAX (Al1 , Al2) 8: MIN (Al1 , Al2)	0	*

This parameter is used to select the feedback signal channel of process PID. The PID feedback is a relative value and ranges from 0.0% to 100.0%.

Function code	Name	Description (setting range)	Factory Default	Change
F10.03	PID output characteristic selection	0: PID output is positive characteristic1: PID output is negative characteristic	0	*

0: Forward action

When the feedback value is smaller than the PID setting, the AC drive's output frequency rises.For example, the winding tension control requires forward PID action.

1: Reverse action

When the feedback value is smaller than the PID setting, the AC drive's output frequency reduces. For example, the unwinding tension control requires reverse PID action.

Function code	Name	Description (setting range)	Factory Default	Change
F10.04	PID setting feedback range	0.0 ~ 1000.0	10.0	*

This parameter is a non-dimensional unit. It is used for PID setting display and PID feedback display.

Relative value 100% of PID setting feedback corresponds to the value of F10.04.



Function code	Name	Description (setting range)	Factory Default	Change
F10.05	Proportional gain Kp1	0.0~100.0	20.0	*
F10.06	Integral time Ti1	0.01s~10.00s	2.00s	*
F10.07	Differential time Td1	0.000s~10.000s	0.000s	*

F10.05 (Proportional gain Kp1)

It decides the regulating intensity of the PID regulator. The higher the Kp1 is, the larger the regulating intensity is. The value 100.0 indicates when the deviation between PID feedback and PID setting is 100.0%, the adjustment amplitude of the PID regulator on the output frequency reference is the maximum frequency.

F10.06 (Integral time Ti1)

It decides the integral regulating intensity. The shorter the integral time is, the larger the regulating intensity is. When the deviation between PID feedback and PID setting is 100.0%, the integral regulator performs continuous adjustment for the time set in F10.06. Then the adjustment amplitude reaches the maximum frequency.

F10.07 (Differential time Td1)

It decides the regulating intensity of the PID regulator on the deviation change. The longer the differential time is, the larger the regulating intensity is. Differential time is the time within which the feedback value change reaches 100.0%, and then the adjustment amplitude reaches the maximum frequency.

Function code	Name	Description (setting range)	Factory Default	Change
F10.08	Cut-off frequency of PID reverse rotation	0.00 ~ F00.03(maximum frequency)	0.00Hz	*

In some situations, only when the PID output frequency is a negative value (AC drive reverse rotation), PID setting and PID feedback can be equal. However, too high reverse rotation frequency is prohibited in some applications, and F10.08 is used to determine the reverse rotation frequency upper limit.

Function code	Name	Description (setting range)	Factory Default	Change
F10.09	PID deviation limit	0.0% ~ 100.0%	0.0%	*

If the deviation between PID feedback and PID setting is smaller than the value of F10.09, PID control stops. The small deviation between PID feedback and PID setting will make the output frequency stabilize, effective for some closed-loop control applications.





Fig.6-29 Relation between deviation limit and output frequency

Function code	Name	Description (setting range)	Factory Default	Change
F10.10	PID differential limit	0.00% ~ 100.00%	0.10%	*

It is used to set the PID differential output range. In PID control, the differential operation may easily cause system oscillation. Thus, the PID differential regulation is restricted to a small range.

Function code	Name	Description (setting range)	Factory Default	Change
F10.11	PID setting change time	0.00~650.00s	0.00s	*

The PID setting change time indicates the time required for PID setting changing from 1.1% to 100.0%. The PID setting changes linearly according to the change time, reducing the impact caused by sudden setting change on the system.

Function code	Name	Description (setting range)	Factory Default	Change
F10.12	PID feedback filter time	0.00~60.00s	0.00s	*
F10.13	PID output filter time	0.00~60.00s	0.00s	*

-175-



F10.12 is used to filter the PID feedback, helping to reduce interference on the feedback but slowing the response of the process closed-loop system.

F10.13 is used to filter the PID output frequency, helping to weaken sudden change of the AC drive output frequency but slowing the response of the process closed-loop system.

Function code	Name	Description (setting range)	Factory Default	Change
F10.15	Proportional gain Kp2	0.0~100.0	20.0	*
F10.16	Integral time Ti2	0.01s~10.00s	2.00s	*
F10.17	Differential time Td2	0.000s~10.000s	0.000s	*
F10.18	PID parameter switchover condition	0: No switchover 1: Switchover via input terminal 2: Automatic switchover based on deviation	0	*
F10.19	PID parameter switchover deviation 1	0.0%~F10.20	20.0%	*
F10.20	PID parameter switchover deviation 2	F10.19~100.0%	80.0%	*

In some applications, PID parameters switchover is required when one group of PID parameters cannot satisfy the requirement of the whole running process.

These parameters are used for switchover between two groups of PID parameters. Regulator parameters F10.15 to F10.17 are set in the same way as F10.05 to F10.07.

The switchover can be implemented either via a S terminal or automatically implemented based on the deviation.

If you select switchover via a S terminal, the multi-function terminal must be allocated with function 43 "PID parameter switchover". If the multi-function terminal is OFF, group 1 (F10.05 to F10.07) is selected. If the multi-function terminal is ON, group 2 (F10.15 to F10.17) is selected.

If you select automatic switchover, when the absolute value of the deviation between PID feedback and PID setting is smaller than the value of F10.19, group 1 is selected. When the absolute value of the deviation between PID feedback and PID setting is higher than the value of F10.20, group 2 is selected. When the deviation is between F10.19 and F10.20, the PID parameters are the linear interpolated value of the two groups of parameter values.





Fig.6-30 PID parameters switchover

Function code	Name	Description (setting range)	Factory Default	Change
F10.21	PID initial value	0.0% ~ 100.0%	0.0%	*
F10.22	PID initial value holding time	0.00~650.00s	0.00s	*

When the AC drive starts up, the PID starts closed-loop algorithm only after the PID output is fixed to the PID initial value (F10.21) and lasts the time set in F10.22.



Fig.6-31 PID initial value function



Function code	Name	Description (setting range)	Factory Default	Change
F10.23	Maximum deviation between two PID outputs in forward direction	0.00% ~ 100.00%	1.00%	*
F10.24	Maximum deviation between two PID outputs in reverse direction	0.00% ~ 100.00%	1.00%	*

F10.23 and F10.24 respectively correspond to the maximum absolute value of the output deviation in forward direction and in reverse direction.

Function code	Name	Description (setting range)	Factory Default	Change
F10.25	PID integral property	Unit's digit :Integral separated 0: Invalid 1: Valid Ten's digit :Whether to stop integral operation when the output reaches the limit 0: Continue integral operation 1: Stop integral operation	00	*

Integral separated: If it is set to valid, , the PID integral operation stops when the multifunction digital S allocated with function 22 "PID integral pause" is ON In this case, only proportional and differential operations take effect.

If it is set to invalid, integral separated remains invalid no matter whether the S allocated with function 22 "PID integral pause" is ON or not.

Whether to stop integral operation when the output reaches the limit. If "Stop integral operation" is selected, the PID integral operation stops, which may help to reduce the PIDovershoot.



Function code	Name	Description (setting range)	Factory Default	Change
F10.26	Detection value of PID feedback loss	0.0%: Not judging feedback loss 0.1%–100.0%	0.0%	*
F10.27	Detection time of PID feedback loss	0.0s~20.0s	0.0s	*

These parameters are used to judge whether PID feedback is lost.

If the PID feedback is smaller than the value of F10.26 and the lasting time exceeds the value of F10.27, the AC drive reports E02E and acts according to the selected fault protection action.

Function code	Name	Description (setting range)	Factory Default	Change
F10.28	PID operation at stop	0: No PID operation at stop 1: PID operation at stop	0	*

It is used to select whether the PID continues to operate in the PID stop state. In general applications, the PID should stop computing in the stop state.


Group F11: Swing Frequency, Fixed Length and Count

The swing frequency function is applied to the textile and chemical fiber fields and the applications where traversing and winding functions are required.

The swing frequency function indicates that the output frequency of the AC drive swings up and down with the set frequency as the center. The trace of running frequency at the time axis is shown in the following figure.

The swing amplitude is set in F11.00 and F11.01. When F11.01 is set to 0, the swing amplitude is 0 and the swing frequency does not take effect.



Fig.6-32 Swing frequency control

Function code	Name	Description (setting range)	Factory Default	Change
F11.00	Swing frequency setting mode	0: Relative to the central frequency 1: Relative to the maximum frequency	0	*

This parameter is used to select the base value of the swing amplitude.

0: Relative to the central frequency (F00.09 frequency source selection)

It is variable swing amplitude system. The swing amplitude varies with the central frequency (set frequency).

1: Relative to the maximum frequency (F00.03 maximum output frequency)

It is fixed swing amplitude system. The swing amplitude is fixed.



Function code	Name	Description (setting range)	Factory Default	Change
F11.01	Swing frequency amplitude	0.0% ~ 100.0%	0.0%	*
F11.02	Jump frequency amplitude	0.0% ~ 50.0%	0.0%	*

Use this parameter to determine the value of swing amplitude and kick frequency.

When setting the swing amplitude relative to the center frequency (F11.00=0), the swing amplitude AW=frequency source F00.09 × swing frequency amplitude F11.01. When setting the swing amplitude relative to the maximum frequency (F11.00=1), the swing amplitude AW = the maximum frequency F00.03 × the swing amplitude F11.01.

The kick frequency amplitude is the percentage of the kick frequency relative to the swing amplitude when the swing frequency is running, namely: kick frequency=swing amplitude AW × kick frequency amplitude F11.02. If the swing is selected relative to the center frequency (F11.00=0), the kick frequency is the change value. If the swing is selected relative to the maximum frequency (F11.00=1), the sudden frequency is a fixed value. The wobble operating frequency is constrained by the upper limit and lower limit of the operating frequency.

Function code	Name	Description (setting range)	Factory Default	Change
F11.03	Swing frequency cycle	0.1s~3000.0s	10.0s	*
F11.04	Triangular wave rising time coefficient	0.1%~100.0%	50.0%	*

F11.03 specifies the time of a complete swing frequency cycle.

F11.04 specifies the time percentage of triangular wave rising time to F11.03 (Swing frequency cycle).

Triangular wave rising time =F11.03 (Swing frequency cycle) x F11.04 (Triangular wave rising time coefficient, unit: s)

Triangular wave falling time =F11.03 (Swing frequency cycle) x (1–F11.04 Triangular wave rising time coefficient ,unit: s)

Function code	Name	Description (setting range)	Factory Default	Change
F11.05	Set length	0m ~ 65535m	1000m	*
F11.06	Actual length	0m ~ 65535m	0m	*



Function code	Name	Description (setting range)	Factory Default	Change
F11.07	Number of pulses per meter	0.1~6553.5	100.0	*

The preceding parameters are used for fixed length control.

The length information is collected by multi-function digital input(DI) terminals. F11.06 (Actual length) is calculated by dividing the number of pulses collected by the DI terminal by F11.07 (Number of pulses each meter).

When the actual length F11.06 exceeds the set length in F11.05, the multi-function digital output terminal allocated becomes ON.

During the fixed length control, the length reset operation can be performed via the multifunction S terminal allocated with function 28. For details, see the descriptions of F06.00 to F06.09.

Allocate corresponding input terminal with function 27 (Length count input) in applications. If the pulse frequency is high, HDI must be used.

Function code	Name	Description (setting range)	Factory Default	Change
F11.08	Set count value	1~65535	1000	*
F11.09	Designated count value	1 ~ 65535	1000	*

The count value needs to be collected by input terminal. Allocate the corresponding input terminal with function 25 (Counter input) in applications. If the pulse frequency is high, HDI must be used.

When the count value reaches the set count value (F11.08), multi-function digital output terminal allocated with function 8 (Set count value reached) becomes ON. Then the counter stops counting.

When the counting value reaches the designated counting value (F11.09), multi-function digital output terminal allocated with function 9 (Designated count value reached) becomes ON. Then the counter continues to count until the set count value is reached.

F11.09 should be equal to or smaller than F11.08.



Fig.6-33 Reaching the set count value and designated count value



Group F12: Simple PLC Function And Multi-speed control

The multi-command has many functions. Besides multi-speed, it can be used asthe setting source of the V/F separated voltage source and setting source of process PID. In addition, the multi-command is relative value.

The simple PLC function is different from the user programmable function. Simple PLC can only complete simple combination of multi-command, while the user programmable function is more practical.

Function code	Name	Description (setting range)	Factory Default	Change
F12.00	Simple PLC running mode	0: Stop after the AC drive runs one cycle1: Keep final values after the AC drive runs one cycle2: Repeat after the AC drive runs one cycle	0	*

Simple PLC can be either the frequency source or V/F separated voltage source.

When simple PLC is used as the frequency source, whether parameter values of F12.02 to F12.17 are positive or negative determines the running direction. If the parameter values are negative, it indicates that the AC drive runs in reverse direction.





0: Stop after the AC drive runs one cycle

The AC drive stops after running one cycle, and will not start up until receiving another command.

-183-



1: Keep final values after the AC drive runs one cycle

The AC drive keeps the final running frequency and direction after running one cycle.

2: Repeat after the AC drive runs one cycle

The AC drive automatically starts another cycle after running one cycle, and will not stop until receiving the stop command.

Function code	Name	Description (setting range)	Factory Default	Change
F12.01	Simple PLC retentive selection	Unit's digit: Retentive upon power failure 0: No 1: Yes Ten's digit: Retentive upon stop 0: No 1: Yes	00	*

PLC retentive upon power failure indicates that the AC drive memorizes the PLC running moment and running frequency before power failure and will continue to run from the memorized moment after it is powered on again. If the unit's digit is set to 0, the AC drive restarts the PLC process after it is powered on again.

PLC retentive upon stop indicates that the AC drive records the PLC running moment and running frequency upon stop and will continue to run from the recorded moment after it starts up again. If the ten's digit is set to 0, the AC drive restarts the PLC process after it starts up again.

Function code	Name	Description (setting range)	Factory Default	Change
F12.02	Multi-speed 0	-100.0% ~ 100.0%	0.0%	*
F12.03	Multi-speed 1	-100.0% ~ 100.0%	0.0%	*
F12.04	Multi-speed 2	-100.0% ~ 100.0%	0.0%	*
F12.05	Multi-speed 3	-100.0% ~ 100.0%	0.0%	*
F12.06	Multi-speed 4	-100.0% ~ 100.0%	0.0%	*
F12.07	Multi-speed 5	-100.0% ~ 100.0%	0.0%	*
F12.08	Multi-speed 6	-100.0% ~ 100.0%	0.0%	*



Function code	Name	Description (setting range)	Factory Default	Change
F12.09	Multi-speed 7	-100.0% ~ 100.0%	0.0%	*
F12.10	Multi-speed 8	-100.0% ~ 100.0%	0.0%	*
F12.11	Multi-speed 9	-100.0% ~ 100.0%	0.0%	*
F12.12	Multi-speed 10	-100.0% ~ 100.0%	0.0%	*
F12.13	Multi-speed 11	-100.0% ~ 100.0%	0.0%	*
F12.14	Multi-speed 12	-100.0% ~ 100.0%	0.0%	*
F12.15	Multi-speed 13	-100.0% ~ 100.0%	0.0%	*
F12.16	Multi-speed 14	-100.0% ~ 100.0%	0.0%	*
F12.17	Multi-speed 15	-100.0% ~ 100.0%	0.0%	*

Multi-command can be the setting source of frequency, V/F separated voltage and process PID. The multi-command is relative value and ranges from -100.0% to 100.0%.

As frequency source, it is a percentage relative to the maximum frequency. As V/F separated voltage source, it is a percentage relative to the rated motor voltage. As process PID setting source, it does not require conversion.

Multi-command can be switched over based on different states of multi-function digital S terminals. For details, see the descriptions of group F06.

Function code	Name	Description (setting range)	Factory Default	Change
F12.18	Running time of simple PLC multi-speed 0	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.19	Acceleration/deceleration time of simple PLC multi- speed 0	0~3	0	*
F12.20	Running time of simple PLC multi-speed 1	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.21	Acceleration/deceleration time of simple PLC multi- speed 1	0~3	0	*
F12.22	Running time of simple PLC multi-speed 2	0.0s(h) ~ 6500.0s(h)	0.0s(h)	*



Function code	Name	Description (setting range)	Factory Default	Change
F12.23	Acceleration/deceleration time of simple PLC multi-speed 2	0~3	0	*
F12.24	Running time of simple PLC multi-speed 3	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.25	Acceleration/deceleration time of simple PLC multi-speed 3	0~3	0	*
F12.26	Running time of simple PLC multi-speed 4	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.27	Acceleration/deceleration time of simple PLC multi-speed 4	0~3	0	*
F12.28	Running time of simple PLC multi-speed 5	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.29	Acceleration/deceleration time of simple PLC multi-speed 5	0~3	0	*
F12.30	Running time of simple PLC multi-speed 6	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.31	Acceleration/deceleration time of simple PLC multi-speed 6	0~3	0	*
F12.32	Running time of simple PLC multi-speed 7	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.33	Acceleration/deceleration time of simple PLC multi-speed 7	0~3	0	*
F12.34	Running time of simple PLC multi-speed 8	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.35	Acceleration/deceleration time of simple PLC multi-speed 8	0~3	0	*
F12.36	Running time of simple PLC multi-speed 9	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.37	Acceleration/deceleration time of simple PLC multi-speed 9	0~3	0	*
F12.38	Running time of simple PLC multi-speed 10	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.39	Acceleration/deceleration time of simple PLC multi-speed 10	0~3	0	*

-186-



Function code	Name	Description (setting range)	Factory Default	Change
F12.40	Running time of simple PLC multi-speed 11	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.41	Acceleration/deceleration time of simple PLC multi-speed 11	0~3	0	*
F12.42	Running time of simple PLC multi-speed 12	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.43	Acceleration/deceleration time of simple PLC multi-speed 12	0~3	0	*
F12.44	Running time of simple PLC multi-speed 13	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.45	45 Acceleration/deceleration time of simple PLC multi-speed 13 0~3		0	*
F12.46	46 Running time of simple PLC multi-speed 14 0.0s(h) ~ 6500.0s(h)		0.0s(h)	*
F12.47	Acceleration/deceleration time of simple PLC multi-speed 14		0	*
F12.48	Running time of simple PLC multi-speed 15	0.0s(h)~6500.0s(h)	0.0s(h)	*
F12.49	Acceleration/deceleration time of simple PLC multi-speed 15	0~3	0	*
F12.50	Time unit of multi-speed	0: s (second) 1:h (hour)	0	*
F12.51	Multi-speed 0 source	0: Set by F12.02 1: Al1 2: Al2 3: Al3 4: Pulse setting 5: PID 6: Set frequency via keypad(F00.10),modifi ed UP/DOWN 7: Panel potentiometer setting	0	*

It determines the setting channel of reference 0. You can perform convenient switchover between the setting channels. When multi-command or simple PLC is used as frequency source, the switchover between two frequency sources can be realized easily.

-187-



Group F13: Communication Parameters

Function code	Name	Description (setting range)	Factory Default	Change
F13.00	Local communication address	1~247,0-bit broadcast address	1	*

When the local address is set to 0, it is the broadcast address, which realizes the broadcast function of the upper computer.

The local address is unique (except the broadcast address), which is the basis for the pointto-point communication between the host computer and the inverter.

Function code	Name	Description (setting range)	Factory Default	Change
F13.01	Data format	0: 300BPS 1: 600BPS 2: 1200BPS 3: 2400BPS 4: 4800BPS 5: 9600BPS 6: 19200BPS 7: 38400BPS 8: 57600BPS 9: 115200BPS	5	*

This parameter is used on set data transfer rate between host computer and AC drive.

Note: Baud rate of host computer and AC drive must be same, or communication is failed. The higher baud rate, the faster communication speed.

Function code	Name	Description (setting range)	Factory Default	Change
F13.02	Data format	0: No check, data format <8,N,2> 1: Even parity check, data format <8,E,1 2: Odd Parity check, data format <8,O,1> 3: Data format <8,N,1>	0	*

Note: Data format of host computer and AC drive must be same, or communication is failed.



Function code	Name	Description (setting range)	Factory Default	Change
F13.03	Response delay	0ms ~ 20ms	20	*

Communication response delay: It refers to the interval time from the end of the inverter's data reception to the time when the data is sent to the upper computer. If the response delay is less than the system processing time, the response delay is subject to the system processing time. If the response delay is longer than the system processing time, after the system has processed the data, it will wait for a delay until the response delay time expires before sending to the host computer. send data.

Function code	Name	Description (setting range)	Factory Default	Change
F13.04	Communication timeout	0.0(invalid), 0.1s~60.0s	0.0	*

When the function code is set to 0.0s, the communication timeout fault time parameter is invalid.

When the function code is set to a valid value, if the interval between one communication and the next communication exceeds the communication timeout time, the system will report a communication failure error (E018).

Normally, it is set to invalid. If this parameter is set in a continuous communication system, the communication status can be monitored.

Function code	Name	Description (setting range)	Factory Default	Change
F13.05	Modbus protocol	0: Non-standard Modbus protocol	0	*
	Selection	1: Standard Modbus protocol		

F13.05= 1: Select standard Modbus protocol.

F13.05= 0: When reading the command, the number of bytes returned by the slave is one byte more than the standard Modbus protocol.

Fur c	nction ode	Name	Description (setting range)	Factory Default	Change
F1	13.06	Communication reading current resolution	0: 0.01A 1: 0.1A	0	*



Group F15: Motor 2 Parameters

The series products can be switched between 2 motors, the motor nameplate parameters can be set separately for the 2 motors, the motor parameter self-learning can be performed separately, the V/F control or vector control can be selected separately, the encoder-related parameters can be set separately, and the parameters can be set separately. Set parameters related to V/F control or vector control performance.

All parameters of group F15, the content definition and usage method are consistent with the relevant parameters of the first motor, and the description will not be repeated here. Users can refer to the description of the relevant parameters of the first motor.



Peaco Support FC280 Series VFD User Manual



Fault Diagnosis and Trouble Shooting

7.1	Faults and Solutions	
7.2	Common Faults and Solutions	198



7.1 Faults and Solutions

The inverter has a total of 34 warning information and protection functions. Once a fault occ-urs, the protection function will act, the inverter will stop output, the inverter fault relay contact will act, and the fault code will be displayed on the inverter display panel. user before seeking service, you can conduct selfexamination according to the prompts in this section, analyze the cause of the fault, and find out the solution. If it belongs to the reasons stated in the dot-ted box, please seek service, contact the agent of the inverter you purchased or directly con-tact our company.

Among the 21 warning messages, E033 is a hardware overcurrent or overvoltage signal. Under normal circumstances, a hardware overvoltage fault causes E033 to alarm.

Display	Fault name	Possible Causes	Solutions
E001	Bus under- voltage	 instantaneous power failure; input voltage of the inverter is not within the specified requirements; bus voltage is abnormal; rectifier bridge and buffer resistance is abnormal; drive board is abnormal; main control board is abnormal. 	 fault reset adjust to normal voltage seek technical support seek technical support seek technical support seek technical support
E002	Over-voltage during acceleration	 input voltage is too high ; external force dragging motor running in the process of acceleration ; acceleration time is too short ; have no install brake unit or brake resistance. 	 adjust to normal voltage; cancel external force or add a brake resistance; increase acceleration time; install brake unit or brake resistance.
E003	Over-voltage at constant speed running	 input voltage is too high ; external force dragging motor running in the process of running. 	 adjust to normal voltage cancel external force or add a brake resistance.



Display	Fault name	Possible Causes	Solutions
E004	Over-current during acceleration	 AC drive output circuit is ground or short circuit; no self-learning of motor parameter; acceleration time is too short; manual torque boost or V/F curve is not suitable; voltage is too low; start rotating motor ; additional load when acceleration; AC drive type is too small. 	 eliminate external faults; self-learning of motor parameter; increase acceleration time; adjust manual torque boost or V/F curve; adjust to normal voltage; speed tracking restart or start after motor stop; cancel additional load; select an AC drive of higher power class.
E005	Over-current during deceleration	 AC drive output circuit is ground or short circuit; no self-learning of motor parameter; deceleration time is too short; voltage is too low; additional load when deceleration; have no install brake unit or brake resistance. 	 eliminate external faults; self-learning of motor parameter; increase deceleration time; adjust to normal voltage; cancel additional load; install brake unit or brake resistance.
E006	Over-current at constant speed running	 AC drive output circuit is ground or short circuit; no self-learning of motor parameter; voltage is too low; additional load when running; AC drive type is too small. 	 eliminate external faults; self-learning of motor parameter; adjust to normal voltage; cancel additional load; select an AC drive of higher power class.



Display	Fault name	Possible Causes	Solutions
E007	Motor overload	 Whether protection parameter F05.10 is suitable; Whether load is too heavy or motor lock-rotor; AC drive type is too small. 	 setting parameter correctly; reduce the load and check the motor and mechanical condition; select an AC drive of higher power class.
E008	AC drive overload	 The load is too heavy or lockedrotor occurs on the motor. The AC drive model is of too small power class. 	 reduce the load and check the motor and mechanical condition. select an AC drive of higher power class.
E00A	Overvoltage during deceleration	 The input voltage is too high. An external force drives the motor during acceleration. The acceleration time is too short. The braking unit and braking resistor are not installed. 	 1.adjust the voltage to normal range. cancel the external force or install a braking resistor. increase the acceleration time. install the braking unit and braking resistor.
E00d	External equipment fault	 external fault signal is input via S. external fault signal is input via virtual I/O. 	reset the operation.reset the operation.
E00E	Module overheat	 the ambient temperature is too high. the air filter is blocked. the fan is damaged. the thermally sensitive resistor of the module is damaged. the inverter module is damaged. 	 lower the ambient temperature. clean the air filter. replace the damaged fan. replace the damaged thermally sensitive resistor. replace the inverter module.



Display Fault name Possible Causes Solutions FFPROM The EEPROM chip is Replace the main control F00F readwrite damaged. board fault the three-phase power input is abnormal. eliminate external faults. the drive board is faulty. seek technical support Power input F012 the lightening board is phase loss seek technical support faultv. seek technical support the main control board is faultv the cable connecting the AC drive and the motor eliminate external faults. is faulty. check whether the motor. the AC drive's threethree-phase winding is Power output phase outputs are F013 normal phase loss unbalanced when the seek technical support motor is running. seek technical support the drive board is faulty. the module is faulty. replace the faulty HALL the HALL device is Current device E015 faulty. detection fault replace the faulty drive the drive board is faulty. board the motor parameters set the motor parameters are not set according to according to the nameplate Motor self-E016 the name-plate. properly. learning fault the motor self-learning check the cable connecting times out the AC drive and the motor replace the faulty drive the drive board and Contactor board or power supply F017 power supply are faulty. board. fault the contactor is faulty. replace the faulty contactor.



Display	Fault name	Possible Causes	Solutions
E018	Communicati on fault	 the host computer is in abnormal state. the communication cable is faulty. F00.02 is set improperly. the communication parameters in group F13 are set improperly. 	 check the cabling of host computer. check the communication cabling. set F00.02 correctly. set the communication parameters properly.
E020	Accumulative running time reached	 The accumulative running time reaches the setting value. 	 Clear the record through the parameter initialization function.
E023	Short circuit to ground	 The motor is short circuited to the ground. 	• Replace the cable or motor.
E026	Encoder fault	 the encoder type is incorrect. the cable connection of the encoder is incorrect. the encoder is damaged. the PG card is faulty. 	 set the encoder type correctly based on the actual situation. eliminate external faults. replace the damaged encoder. replace the faulty PG card.
E029	Accumulative power-on time reached	 The accumulative power- on time reaches the setting value. 	 Clear the record through the parameter initialization function.
E02E	PID feedback lost during running	 The PID feedback is lower than the setting of F10.26. 	 Check the PID feedback signal or set F10.26 to a proper value.
E030	Load becoming 0	 The AC drive running current is lower than F05.13. 	 Check that the load is disconnected or the setting of F05.13 and F05.14 is correct.
E032	Pulse-by- pulse current limit fault	 the load is too heavy or lockedrotor occurs on the motor. the AC drive model is too small power class. 	 reduce the load and check the motor and mechanical condition. select an AC drive of higher power class.



Display	Fault name	Possible Causes	Solutions
E033	AC drive hardware fault	overvoltage exists.overcurrent exists.	handle based on overvoltage.handle based on overcurrent.
E034	Too large speed deviation	 the encoder parameters are set incorrectly. the motor self-learning is not performed. F05.17 and F05.60 are set incorrectly. 	 set the encoder parameters properly. perform the motor self- learning. set F05.17 and F05.60 correctly based on the actual situation.
E035	Motor over- spee	 the encoder parameters are set incorrectly. the motor self-learning is not performed. F05.17 and F05.60 are set incorrectly. 	 set the encoder parameters properly. perform the motor self- learning. set F05.17 and F05.60 correctly based on the actual situation
E036	Motor overheat	 the cabling of the temperature sensor becomes loose. the motor temperature is too high. 	 check the temperature sensor cabling and eliminate the cabling fault. lower the carrier frequency or adopt other heat radiation measures.
E037	Initial position fault	• The motor parameters are not set based on the actual situation.	 Check that the motor parameters are set correctly and whether the setting of rated current is too small.
E038	Motor switchover fault during running	 Change the selection of the motor via terminal during running of the AC drive. 	 Perform motor switchover after the AC drive stops.



7.2 Common Faults and Solutions

You may come across the following faults during the use of the AC drive. Refer to the following table for simple fault analysis.

SN	Fault name	Possible Causes	Solutions
1	There is no display at power-on.	 there is no power supply to the AC drive or the power input to the AC drive is too low. the power supply of the switch on the drive board of the AC drive is faulty. the rectifier bridge is damaged. the control board or the operation panel is faulty. the cable connecting the control board and the drive board and the drive board and the operation panel breaks. 	 check the power supply. check the bus voltage. re-connect the 34-core cables. seek technical support
2	displayed at power-on.	 the cable between the drive board and the control board is in poor contact. related components on the control board are damaged. the motor or the motor cable is short circuited to the ground. the HALL device is faulty. the power input to the AC drive is too low. 	 re-connect the 34-core cables. seek technical support.
3	Display "E023" alarm when power on	 The motor or output line is short- circuited to ground; The inverter is damaged; 	 Use a shaker to measure the insulation of the motor and output wire; Seek manufacturer service;



SN	Fault name	Possible Causes	Solutions
4	Power on the inverter shows normal, after running, it will show and stop immediately	 the cabling of the temperature sensor becomes loose. the motor temperature is too high. 	 replace the damaged fan. eliminate external fault.
5	E00E (module overheat) fault is reported frequently.	 The carrier frequency setting is too high; The fan is damaged or the air duct is blocked; Damage to the internal components of the inverter (thermocouple or other) 	 reduce the carrier frequency(F00.17). seplace the fan and clean the air filter. seek technical support
6	The motor does not rotate after the AC drive runs	 check the motor and the motor cables. the AC drive parameters are set improperly (motor parameters). the cable between the drive board and the control board is in poor contact. the drive board is faulty. 	 ensure the cable between the AC drive and the motor is normal. replace the motor or clear mechanical faults. check and re-set motor parameters.
7	The S terminals are disabled	 the parameters are set incorrectly. the external signal is incorrect. the jumper bar across DCM and +24 V becomes loose. the control board is faulty. 	 check and reset the parameters in group F06. re-connect the external signal cables. re-confirm the jumper bar across DCM and +24 V. seek technical support.



SN	Fault name	Possible Causes	Solutions
8	The motor speed is always low in close loop vector control mode	 1.the encoder is faulty. 2.the encoder cable is connected incorrectly or in poor contact. 3.the PG card is faulty. 4.the drive board is faulty. 	 1.replace the encoder and ensure the cabling is proper. 2.replace the PG card. 3.seek technical support
9	The AC drive reports overcurrent and overvoltage frequently	 1.the motor parameters are set improperly. 2.the acceleration/deceleration time is improper. 3.the load fluctuates. 	 1.re-set motor parameters or re-perform the motor self-learning. 2.set proper acceleration/ deceleration time. 3.seek technical support
10	E017 is reported upon power-on or running.	 The soft startup contactor is not picked up. 	 1.check whether the contactor cable is loose. 2.check whether the contactor is faulty. 3.heck whether 24 V power supply of the contactor is faulty. 4.seek technical support.
11	88888 is displayed upon power-on.	 Related component on the control nboard is damaged. 	 Replace the control board.

-200-



Peaco Support FC280 Series VFD User Manual



Appendix

Appendix A: Serial Communications	202
Appendix B: Accessories Selection	212



Appendix A: Serial Communications

AC drive, provide the RS485 communication interface, and adopt the ModBus communication n protocol of international standard to make master- slave communication. Users can realize centralized control by PC/ PLC, upper computer controlling and so on(set the controlling command, operation frequency, correlation function code parameters change, inverter working state and fault information monitoring, etc.), so as to adapt to specific application requirements.

1.Protocol content

The Modbus serial communication protocol defines the frame content and using form of asynchronous transmission in serial communication, including: host polling and broadcast frame, slave response frame format; frame content of host organization includes: slave address (or the broadcast address), performing commands, data and error checking, etc.; slave response is also using the same structure, content including: action confirmation, data returning and error checking, etc. if error happens when slave is receiving frame, or cannot achieve the requirements of the host, it will organize a fault frame as a response feedback to the host.

2.Application way

AC drive access the controlling network of "single master multiple slave" with Rs232/RS485 bus.

3.Bus structure

(1) The interface way RS485 hardware interface

(2) Transmission mode

Asynchronous serial and half- duplex transmission mode. At the same time only one between the host and the slave can send data and the other receives data. In the process of serial asynchronous communication, data is sending in the form of message, and frame by frame.

(3) Topological structure

Single master multiple slave system. Slave address set range from $1 \sim 247$, 0 as the broadcast address, and each slave address in the network has uniqueness. This is the foundation of guaranteeing Modbus serial communication.

4. Protocol specification

The communication protocol of AC drive is a kind of master-slave Modbus co-mmunication protocol with asynchronous serial, and in the network only one device (host) can establish-protocol(called "query/ command"). Other device (slave) can only respond to "query/ command" of the host with the provided data, or make corresponding action according to the



"query/ command" of the host. Host here refers to the personal computer (PC) , industrial control equipment or programmable logic controller (PLC) , etc. , and slave refers to BD330 series inverter or other controlling equipment of the same communication protocol. Host can not only separately communicate with a certain slave, but also can release broadcast information to all slaves. For the separately "query/ command" of the host, slave should return a information (called response) , and for broadcast information of the host, the slave does not have to feedback information to the host.

5.Communication frame structure

The Modbus protocol communication data format of AC drive as following :

In RTU mode, new information always becomes silent for at least 3. 5 bytes of transmission time as a start. In the network that calculates transmission rate by baud rate, transmission time of 3. 5 bytes can be easily grasped. And then the transmitted data fields are, in order: slave address, operation command code, data and CRC check words,transmitted bytes of each domain are hexadecimal 0...9, A... F. network device always monitors the activities of the communication bus, even in the silent intervals. When receiving the first field (address information), each network device will conform the byte. With the last byte transmission completion, a similar 3. 5 bytes of transmission time interval is used to show the end of the frame. After this, the transmission of a new frame will start.

Information of a frame must be transmitted in a continuous flow of data. If the interval is more than 1. 5 bytes before the end of the whole frame transmission, the receiving device will remove the incomplete information, and mistakenly consider the following byte to be part of a new frame address. In the same way, if the interval between the start of a new frame and previous frame is less than 3. 5 bytes, receiving device will consider it to be a continuation of the previous frame. Because of the frame disorder, the final CRC check value is not correct, which will lead to communication fault.



The standard structure of RTU frame:

START	T1- T2-T3-T4(3. 5 bytes of transmission time)
SLAVE ADDR	Communication address : 1 ~ 247
CMD	03H : read slave parameters; 06H : write slave parameters



Chapter 8 Appendix

DATA (n - 1)		
DATA (n - 2)	Data: function code parameter address, number of function	
	code parameter ,value of function code parameter	
DATA 0		
CRC CHK high- order	- Check value: CRC T1- T2-T3-T4(3. 5 bytes of transmission time)	
CRC CHK low- order		
END		

Command code (CMD): 03H , read N words (at most continuously read 12 words) . For example, the inverter of which slave address is 01, memory starting address is F02, when continuously reading two words, and then the host command information as below:

ADR	01H	
CMD	03H	
Starting address high- order	F0H	
Starting address low- order	02H	
Number of data high- orde	00H	
Number of data low- order	02H	
CRC CHK low- order	Need to approve CPC CHK	
CRC CHK high- order		

Slave response information

When F13.05 set to 0:

ADR	01H
CMD	03H
Number of bytes high-order	00H
Number of bytes low-order	04H
Data address F002H high- order	00H
Data address F002H low- order	00H
Data address F003H high- order	00H
Data address F003H low- order	01H
CRC CHK low- order	Need to calculate CRC,CHK
CRC CHK high- order	



hen F13.05 set to 1:

ADR	01H
CMD	03H
Number of bytes	04H
Data address F002H high- order	00H
Data address F002H low- order	00H
Data address F003H high- order	00H
Data address F003H low- order	01H
CRC CHK low- order	Need to calculate CRC,CHK
CRC CHK high- order	

Command code: 06H, write a word

For example: write 5000(1388H) in F00AH address of inverter that the slave ad-dress is 02H.

Host command information :

ADR	02H
CMD	06H
Data address high-order	F0H
Data address low-order	0AH
Data content high- order	13H
Data content low- order	88H
CRC CHK low- order	Need to calculate CRC,CHK
CRC CHK high- order	

Slave response information :

ADR	02H
CMD	06H
Data address high-order	F0H
Data address low-order	0AH
Data content high- order	13H
Data content low- order	88H
CRC CHK low- order	Need to coloulate CBC CHK
CRC CHK high- order	Need to calculate CRC,CHK



CRC checking methods- - - CRC(Cyclical Redundancy Check) :

Use the RTU frame format, and frame contains frame error detection domain based on CRC calculation. CRC domain detects the content of the entire frame. CRC domain is two bytes, containing 16 bit binary value. It joins the frame after calculated by the transmission equipment, and the receiving device recalculates CRC of the received frame, and compared with the received value of CRC domain, if the two CRC value is not equal, then there is an error in transmission.

CRC is deposited in the OxFFFF first, and then process more than six consecutive bytes of the frame with the value of current register. Only 8 bit data of each character is valid for CRC, and the start bit and stop bit and parity bit are all invalid.

In the process of CRC, each 8- bit character is separately XOR with register content, and as a result, moves to the lowest effective direction, and the highest effective bit fills with 0. LSB is extracted to detect, if the LSB is 1, register is separately XOR with preset value, if the LSB is 0, then give up. The whole process will repeat 8 times. After the completion of the final bit (eighth bit), next 8- bit bytes will separately XOR with the current value of register. The value in the register finally is the CRC value after all bytes in the frame perform.

This calculation method of CRC adopts the CRC check rule of international standards. When users edit CRC algorithm, they can refer to relevant standard of the CRC algorithm, and write CRC calculation program that really meets the requirements.

Now offer a simple function of CRC calculation for user reference (programming with C language) :

unsigned int crc_cal_value(unsigned char*data_value,unsigned char dta_length)

```
(
int i
unsigned int crc_value=0xFFFF
while(data_length--)
crc_value^=*data_value++
for(i=0;i<8,i++)
(
if(crc_value&0x0001) crc_value=(crc_value>>1)^0xa001
        else crc_value=crc_value>>1
)
)
return(crc_value)
)
```

hapter 8



The definition of communication data address: :

This part is the address definition of communication data, and used to control the operation of the inverter, obtain inverter state information and related function parameters settings, etc.

6.Function code parameter address rules

High and low byte range respectively: high byte $F0^{-}FE(F \text{ group}), A0 \sim A2(F15 \sim F17 \text{ group})$; low byte $00 \sim FF$. For example, if visit F04.02, so the function code address is 0xF40C.

Note: F14 group: manufactures setting parameters, neither can read this group of parameter, nor change this group of parameters; F17 group: can read this group of parameter,but can not change parameter.When inverter is in operation, some parameters cannot be changed; some parameters cannot be changed no matter what state the inverter is; when changing the function code parameters, you also should note the parameter setting range, units, and related instructions.

Function code group	Communication visit address	Function code address of communication change RAM
F00~F14	0xF000~0xFEFF	0x0000~0x0EFF
F15~F17	0xA000~0xA2FF	0x4000~0x42FF

Because the EEPROM is frequently stored, it will reduce the service life of EEPROM. As for users, some function code does not need to be stored under the mode of communication, and only need to change the value of RAM to satisfy the usage requirements. This function can be achieved only by changing the high-order of the corresponding code address from F to 0.

High and low byte range respectively: high byte $00^{\sim}0F(F~group);$ low byte $00^{\sim}FF.$

For example:

Function code F04.12 is not stored in the EEPROM, and set the address to 040C. Function code F15.51 is not stored in the EEPROM, and set the address to 4033.

This address can only be used for chip RAM, and cannot used as a function of reading, if doing so, then invalid address. For all parameter, it can realize this function by command code 07H.

Chapter 8 Appendix

Control command input to AC drive: (only write)

Command Address	Command Function
1000H	0001H : forward running
	0002H : reverse running
	0003H : forward jog
	0004H : reverse jog
	0005H : free stop
	0006H : decelerate to stop
	0007H : fault resetting

Digital output to terminal control: (only write)

Command Address	Command Function
1001H	BIT0: MO1 output control
	BIT1: retain
	BIT2: RA output control
	BIT3: TA output control
	BIT4: HDO output control
	BIT5: retain
	BIT6: retain
	BIT7: retain
	BIT8: retain

Analog output AO1 control: (only write)

Command Address	Command Function
1002H	0~7FFF means 0%~100%

Analog outputAO2 control: (only write)

Command Address	Command Function
1003H	0~7FFF means 0%~100%



Pulse output control: (only write)

Command Address	Command Function
1004H	0~7FFF means 0%~100%

Read AC drive status: (only write)

Status address	Status Command Function	
	0001: forward running	
2000H	0002: reverse running	
	0003: stop	

Stop/run parameter address:

Address	Data meaning	Addres	Data meaning
3000H	*communication setting range (- 10000 ~ 10000) (decimalism)	3001H	frequency running
3002H	bus voltage	3003H	output voltage
3004H	output current	3005H	output
3006H	output torque	3007H	speed
3008H	terminal input symbol	3009H	terminal output symbol
300AH	Ai1 voltage	300BH	Ai2 voltage
300CH	Ai3 voltage	300DH	count value input
300EH	length valuse input	300FH	load speed
3010H	PID setting	3011H	PID feedback value
3012H	PLC steps	3013H	input pulse frequency , unit is 0.01kHz
3014H	feedback speed, unit is 0.1Hz	3015H	residue running time
3016H	Ai1 voltage before correcting	3017H	Ai2 voltage before correcting
3018H	Ai3 voltage before correcting	3019H	line speed
301AH	current power on time	301BH	current run time
301CH	input pulse frequency, unit is 1Hz	301DH	communication setting time
301EH	actual feedback speed		A frequency display
3020H	B frequency display		



Note: 4communication setting value is relative percentage(-100. 00% \sim 100. 00%), and can make communication write operations. When setting as frequency source, relative is the largest frequency(F00.03); When setting as torque source, relative is F03.10,F15.48 (motor1,motor2.)

Parameter lock password calibration: (if back to 8888H, is means password calibration passed)

Address	Data meaning
1F00H	*****

Parameter initializing address is 1F01H:

Status address	Command Function
1F01H	0001H: factory reset, not include motor parameter
	0002H: clear fault file

Parameter initializing address is 1F01H:

AC Drive fault address	AC Drive fault information
8000H	0000H: no fault 0001H: acceleration overcurrent(E004) 0002H: deceleration overcurrent(E005) 0003H: constant speed overcurrent(E006) 0004H: acceleration overvoltage (E002) 0005H: deceleration overvoltage (E00A) 0006H: constant speed overvoltage (E003) 0007H: undervoltage falut(E001) 0008H: motor overload (E007) 0009H: AC drive overload(E008) 000AH: input phase loss (E012) 000BH: output phase loss (E013) 000CH: module overheat (E00E) 000DH: buffer resistance overload(E014) 000EH: contactor fault(E017) 000FH: external fault(E018) 0010H: communication fault (E015) 0012H: motor self- learning fault (E016)



Chapter 8 Appendix

AC Drive fault address	AC Drive fault information
8000H	0013H: accumulative running time reached (E020) 0014H: EEPROM readwrite fault (E00F) 0015H: Short circuit to ground (E023) 0016H: PID feedback lost during running (E02E) 0017H: encoder fault (E026) 0018H: AC drive hardware fault (E033) 0019H: accumulative power-on time reached(E029) 001AH: load becoming 0(E030) 001BH: rapid current limit timeout (E032) 001CH: too large speed deviation (E034) 001DH: motor switchover fault during running(E038) 001EH: motor over-speed (E035) 001FH: motor overheat (E036) 0020H: initial position fault (E037)

Communication fault description: (fault code)

Communication fault address	Communication fault information		
8000H	0000H : no fault 0001H : wrong password 0002H : wrong command code 0003H : wrong CRC check 0004H : invalid address 0005H : invalid parameter 0006H : invalid parameter change 0007H : system is locked 0008H : inverter busy(EEPR0M in storage)		



Appendix B: Accessories Selection

1.Beake unit and brake resistance

AC drive	Brake unit		Brake resistance					
Power	Model	Quantity (piece)	^y Power(W)/Resistance value(Ω)		Quantity (piece)			
220V								
0.55KW	- Built-in		80	120	1			
0.75KW			80	120	1			
1.5KW			150	100	1			
2.2KW			300	68	1			
3.7KW]		300	68	1			
5.5KW			400	30	1			
7.5KW			400	30	1			
380V								
0.75KW			150	300	1			
1.5KW			200	300	1			
2.2KW	-			200	200	1		
3.7KW			400	150	1			
5.5KW	Duille in		400	100	1			
7.5KW	Built-In		750	75	1			
11KW			1000	60	1			
15KW			1500	40	1			
18.5KW			2500	30	1			
22KW			3000	30	1			
30KW	DBU-4030	1	5000	25	1			
37KW		1	7500	20	1			
45KW	080-4045	1	10000	13.6	1			
55KW	DBU-4030	2	5000*2	25	1			
75KW		2	7500*2	15	1			
93KW	080-4045	2	10000*2	13.6	1			
110KW		1	20000	8	1			
132KW	000-4100	1	25000	6	1			

-212-



AC drive	Brake unit		Brake resistance				
Power	Model	Quantity (piece)	Power(W)/Resistar	Quantity (piece)			
380V							
160KW		1	30000	30	1		
200KW	DB0-4100	1	35000	25	1		
220KW	DBU-4280	1	40000	20	1		
250KW		1	44000	13.6	1		
280KW		1	50000	25	1		
315KW		1	55000	15	1		
350KW		1	60000	13.6	1		
400KW		1	60000	8	1		
500KW		1	80000	6	1		

Note:

- Please select the power and the resistance value recommended by our company.
- The power and the resistance value that recommended above can be calculated by 100% braking torque and 10% frequency of utilization. The power and the resistance value can be appropriately reduced as long as it meets the load demand and the system is reliable: The power and the resistance value of the braking resistor should be appropriately changed if the braking torque and frequency of utilization need to be increased, or users can contact the company.
- When installing a braking resistor, please consider the safety and the inflammability of the surrounding environment.

The frequency of use of Braking:

UD= t1/ t2*100%

- tl: the braking time in a working period;
- t2: a working period;

If the braking efficiency is double, the power of the corresponding braking unit and braking resistor also need to be double.

-213-



(b) The resistance of the resistor that over 2500W and the power are the total amount of resistance and power. The power of the resistor is get from parallel connection based on 2500W. For example, to get a 25000W 6Ω IS, ten 2500W 60Ω resistors are needed to be connected in parallel.

The calculation of braking resistor: When the braking current IB flowing through the energy consumption circuit is equal to half of the rated current of the motor, the braking torque of the motor is approximately equal to its rated torque:

IB=IMN/2 TB≈TMN or IB=2UB/ IMN

Notes :

IB—braking current, A; IMN—the motor rated current, A;

Tb-braking torque, N•m; TMN-rated load torque of motor, N•m.

As a general rule, the range of choice of braking torque is :

```
TMN < TB < 2TMN IMN < IB < 21MN
```

According to specific situation, users can decide the braking current according to the formula(3-12) and (3-13).

After that , it is easy to calculate the braking resistance :

RB= UB/ IB RBmin= UB/ IMN

Notes :

UB is the braking threshold voltage; RB is braking resistor value.

UB is 1. 1 times as that of the rated voltage of bus. RBmin is the minimum braking resistance the common braking threshold voltage :

AC220V: DC380V AC380V: DC680V AC660V: DC1140V When get IB and RB, the power of resistance will be known.

RB=680V/9A=75Ω RBmin=680/18=38Ω

Empirically, the value is 75Ω

The power of braking resistor=1*6802/75*0.1=616W The power can be appropriately enlarged in actual use.



2. Mounting dimension of brake resistance



Rated power	L1(±2)	L2(±5)	L3(±3)	D(±2)	в	B1	H1(±3)
80	152	174	196	28	6.5	28	61
150	195	217	239	40	8	41	81
200	195	217	239	40	8	41	81
300	282	304	326	40	8	41	81
400	282	304	326	40	8	41	81
750	316	338	360	50	8	45	101
1000	300	325	350	60	8.5	60	119
1500	415	440	465	60	8.5	60	119
2000	510	535	560	60	8.5	60	119
2500	600	625	650	60	8.5	60	119

3. Display panel



Hole diameter of the panel installation box (height* width) : 122* 86mm

Size of outline box : 135*92


Appendix C: Mini Series introduction

1. Specification model

Models	Rated power (KW)	Rated input current (A)	Rated output current(A)	Adaptive motor (KW)				
	Single- phase 220V±15%, 47/63Hz							
2S-0.7G	0.75	8.2	4.1	0.75				
2S-1.5G	1.5	14.0	7.0	1.5				
2S-2.2G	2.2	23.0	10.0	2.2				
2S-3.7G	3.7	30.0	15.0	3.7				
2S-5.5G	5.5	48.0	23.0	5.5				
	Three - phas	se 220V±15%, 47	/63Hz					
2T-0.75G	0.75	4.9	4.1	0.75				
2T-1.5G	1.5	8.4	7.0	1.5				
2T-2.2G	2.2	11.5	10.0	2.2				
2T-3.7G	3.7	18.0	15.0	3.7				
2T-5.5G	5.5	24.0	23.0	5.5				
	Three-phas	e 380V±15%, 47	/63Hz					
4T-0.75G	0.75	3.4	2.5	0.75				
4T-1.5G	1.5	5.0	3.7	1.5				
4T-2.2G	2.2	5.8	5.0	2.2				
4T-3.7G	3.7	10.5	8.5	3.7				
4T-5.5G	5.5	14.6	13.0	5.5				
4T-7.5G	7.5	20.5	18.0	7.5				

2. Appearance dimension







Power (KW)	Housing No	A (mm)	H (mm)	D (mm)	W (mm)	B (mm)	d (mm)
220V : 0.75-2.2 380V : 0.75-3.7	B18	105	162	154	94	150	4.5
220V : 3.7-5.5 380V : 5.5-7.5	B19	115	220	154	104	209	5.5

3. Control Circuit and Main Circuit Wirin

- O Main circuit terminal
- O Cotrol circuit terminal





4. Display panel

The Apparatus Size of the Digital Hand-Held Programming Panel.



5. Functional group

Except for the following parameters, other parameters are the same as those in Chapter 5.

Function code	Name	Description (setting range)	Factory Default	Change
F08.07	Rectifier Bridge Module Temperature	0.0°C ~ 100.0°C	_	**



Appendix D: Single Phase Output Series

1. Specification model

Models	Input voltage	output voltage	Rated power (KW)	Rated input current (A)	Rated output current(A)
2SS-0.5G			0.55	5.4	3.8
2SS-0.7G		104 000	0.75	8.2	5.2
2SS-1.5G		161 220	1.5	14.0	10.0
2SS-2.2G		-	2.2	18.0	13.8

2. Appearance dimension



Power(KW)	Housing No	A (mm)	H (mm)	D (mm)	W (mm)	B (mm)	d (mm)
0.75-1.5	B18	105	162	150	94	150	5
2.2	B19	115	220	150	104	219	5



3. Wiring diagram



380V Single Phase Output Series



-220-



Appendix E: 220V Input, 380V Output Series

1. Specification model

Models	Input voltage	Output voltage	Rated power (KW)	Rated input current (A)	Rated output current(A)
FC280-2S/4T-0.75G			0.75	7.5	2.5
FC280-2S/4T-1.5G			1.5	11	3.7
FC280-2S/4T-2.2G			2.2	15	5
FC280-2S/4T-3.7G			3.7	26	8.5
FC280-2S/4T-5.5G			5.5	39	13
FC280-2S/4T-7.5G	1PH 220	3PH 380	7.5	54	18
FC280-2S/4T-11G	1		11	72	24
FC280-2S/4T-15G	1		15	90	30
FC280-2S/4T-18.5G			18.5	112	37
FC280-2S/4T-22G			22	138	46
FC280-2S/4T-30G			30	174	58

2. Appearance dimension





Power(KW)	A (mm)	H (mm)	D (mm)	W (mm)	B (mm)	d (mm)
0.75-1.5	118	185	157	106	175	4.5
2.2-7.5	160	247	177	148	235	5.5
11-18.5	220	321	198	205	305	5.5



3. Wiring diagram





Appendix F: Elevator & Lift Series

1. Wiring diagram

Analog speed given

Supports two kinds of speed given: Analog speed given and multi-stage speed given; Life controller sends out speed command curve, inverter get speed given command through the analog signal.



Multi-stage speed given

Elevator controller provide speed command, after receiving the command, inverter will automaticlly calculate S curve accelera-tion and deceleration speed.





Built-in Emergency leveling mode

In the using of eleva tor, if the power is cut suddenly, passengers may be kept in the cage. Inverters can support emergency UPS power running, Both the main circuit and the working are powered by 220V UPS.



2. Functional group

Function code	Name	Description (setting range)	Factory Default	Change
		F0 Group		
F00.00	Speed control mode	0: No-PG vector control (SVC) 1: PG vector control (FVC) 2: V/F control	2	•
F00.01	Running command channel	0:keypad control 1:terminal control 2:RS485 communication control	0	*
F00.06	Frequency instruction selection	0: The keyboard is set, and the power failure of the inverter is not memorized; 1: The keyboard is set, and the inverter is powered off; 2: The analog Al setting; 3: The analog Al setting; 4: The analog Al setting ; 5: PULSE pulse setting (HDI); 6: Multi-speed operation setting; 7: Simple PLC setting; 8: PID control setting; 9:485 communication setting; 10: Panel potentiometer given.	8	•

Chapter 8



Function code	Name	Description (setting range)	Factory Default	Change				
	F6 Group							
F06.00	S1 terminal function selection	0: No function	1	•				
F06.01	S2 terminal function selection	2: Reverse running	2	•				
F06.02	S3 terminal function selection	6: Free stop 12: Multi-speed terminal 1	12	•				
F06.03	S4 terminal function selection	13: Multi-speed terminal 2 14: Multi-speed terminal 3	13	•				
F06.04	S5 terminal function selection	51: Elevator overhaul signal 52 : Elevator emergency	14	•				
F06.05	S6 terminal function selection	signal 53: Short floor signal input	8	•				
Group F07								
F07.02	Relay TA output selection(TA* TB* TC)	3: Fault output; 42: Elevator brake output;	7	*				
F07.03	Relay RA output selection(RA* RB* RC)	43: Operating contactor output;	3	*				
F07.04	Mo1 output selection	44: Emergency signal time arrives (red font is new)	1	*				
	Group 26 E	levator special group						
F26.00	Elevator-specific function enable	0: invalid 1: valid	1	•				
F26.01	Brake open delay	0.00 ~10.00s	0.00s	•				
F26.02	Starting frequency	0.00 ∽10.00Hz	5.00Hz	•				
F26.03	Start frequency hold time	0.00 ~10.00s	0.00s	•				
F26.04	brake closing frequency delay	0.00 ~10.00s	0.30s	•				
F26.05	Brake open frequency (rising)	0.00 ~10.00Hz	1.00Hz	•				
F26.06	Brake close frequency (rising)	0.00 ~10.00Hz	0.20Hz	•				



Function code	Name	Description (setting range)	Factory Default	Change
F26.07	Brake open frequency (down)	0.00 ~10.00Hz	1.00Hz	•
F26.08	Brake close frequency (down)	0.00 ~10.00Hz	0.20Hz	•
F26.09	Brake open current	0.0~100.0%	40.00%	•
F26.10	Brake open frequency hold time	0.00~10.00s	0.30s	•
F26.11	Brake open type	0: open according to frequency; 1:opene according to frequency and current	0	•
F26.12	Emergency operation frequency	0.00~50.00Hz	8.00Hz	•
F26.13	Overhaul running frequency	0.00~50.00Hz	8.00Hz	•
F26.14	Emergency signal processing	0: Elevator does not run; 1: UPS power supply operation	0	•
F26.15	Running contactor closing delay	0.00~10.00s	0.20s	•
F26.16	Running contactor opening delay	0.00~10.00s	0.10s	•
F26.17	Brake closed frequency hold time	0.00~10.00s	0.50s	•
F26.18	Short floor function mode	0: invalid 1: valid	0	
F26.19	Short floor function setting speed	0.00Hz~F00.03 (maximum frequency)	30.00Hz	•
F26.20	Increasing frequency of electric mode	0.00~3.00Hz	0.00Hz	•
F26.21	Decreasing frequency of power generation mode	0.00~3.00Hz	0.00Hz	•
F26.22	Emergency signal effective time	0.0~500.0s	10.0s	•
F26.23	Emergency signal invalid time	0.0〜1000.0s	180.0s	•



The detailed Solution steps for setting inverter used on Elevator

Step 1:

F00.28 set to "T to confirm, restore the factory value.

Step 2:

F00.01 is Tto confirm, and then press PRG to exit, and then close the UP Down terminals. See whether the inverter has forward and reverse running.

Step 3:

Set: F00.06 into 6, multi-step speed is valid.

Step 4:

set F09.30 into 1 and respectively set F06.02 to 4, F06.03 to 8 and F06.04 to 7.

Close the low-speed switch (the default is S3) and you can see that the frequency converter runs at 6Hz forward rotation.

Close the high-speed switch (default is S4 terminal) and you can see that the inverter displays E008 fault.

Close the maintenance speed switch (default is S5 terminal) and you can see that the inverter E008 fault disappears.

Step 5:

Set F06.02 (S3) to "12" Corresponding to low speed switch Default 10Hz.

F06.03 (S4) is "13" Corresponding to high speed switching 40/50Hz.

F06.04 (S5) is "14" Corresponding maintenance speed switch Speed is set by parameter F12.06.

Step 6: Set the Speed

F12.03=20 (corresponding to low speed of 10HZ).

F12.04=80 or 100 (corresponding to high speed of 40/50HZ).

F12.06=? We don't know the exact speed you need for this one (corresponding to maintenance speed).

Step 7:

set the acceleration and deceleration should be F05.05=0 F00.12/F0-13/

F09.00 / F09.01 /F09.02 /F09.03 / F09.04/F09.05 all set 2.5.



Step 7:

set the acceleration and deceleration should be F05.05=0 F00.12/F0-13/

F09.00 / F09.01 /F09.02 /F09.03 / F09.04/F09.05 all set2.5.

Step 8:

F07.02= 7 when the inverter is stopped or 0Hz is running TA-TB, normally open change into normally closed

- F00.01 = 1 Terminal control
- F00.06 = 6 Multi Step Speed
- F00.12 = 2.5 Acceleration time
- F00.13 = 2.5 Deceleration time
- F05.05 = 0 overvoltage Stall gain
- F06.02 = 12 multi function terminal 1
- F06.03 = 13 multi function terminal 2
- F06.04 = 14 multi function terminal 3
- F07.02 = 7 Zero -speed ruining 2 (having output at stop)
- F09.00/01/02/03/04/05 = 2.5
- F12.03 = 20 % Slow Speed
- F12.04= 80% /100% high speed
- F12.06 =? Maintenance Speed



Appendix G: Off Grid Solar Series

1. Wiring diagram



SI200 Series Solar VFD Wiring Method(For mini power 0.4-7.5kw)



Method 1:

RST can choose two to connect, this kind of wiring does not distinguish between positive and negative ;

Method 2:

Connect the positive pole to DC+, then short-circuit RST to the negative pole of the photovoltaic panel.



PORT

Three phase 380 VAC Alternate AC power supply, for example, wiring diagram such as following:



2. Basic Technical Specification

Items	Specifications
Recommended MPPT voltage range	3 AC 220V / 130~380V DC (Recommend 330V DC) 3 AC 380V / 330~780V DC (Recommend 560V DC)
MPPT efficiency	99.9%
Rated output voltage	3AC 220V/ 380V
Output frequency range	0~60Hz
Cooling method	Air cooling
Protection degree	IP20/54

Model (380V)	Max DC input current (A)	Rated output current (A)	Applicable water pump (KW)
4T0007G/0015P	4.2	2.5	0.75
4T0015G/0022P	6.1	4.0	1.5
4T0022G/0037P	7.1	6.0	2.2
4T0037G/0055P	16.5	9.6	3.7



Model (380V)	Max DC input current (A)	Rated output current (A)	Applicable water pump (KW)
4T0055G/0075P	23.9	14.0	5.5
4T0075G/0110P	30.6	17.0	7.5
4T0110G/0150P	39.2	25	11
4T0150G/0185P	49	32	15

3. Installation and Commissioning Instructions for Photovoltaic Water Pumps

3.1 Wiring:

1st type:

the positive pole of the solar photovoltaic panel output is connected to the inverter "+" terminal, and the negative pole of the solar photovoltaic panel output is connected to the inverter "-" terminal.

2nd type:

solar photovoltaic The positive and negative poles of the board output are respectively connected to the "R" and "T" terminals of the inverter. This method does not distinguish between positive and negative. The water pump is connected to the "U" "V" "W" terminals of the inverter.

-231-



3.2 Set the working mode of the photovoltaic water pump:

There are two working modes for the photovoltaic water pump.

The first one is CVT mode. In this working mode, only two parameters need to be set (F16.00 is set to 1, which is used to select CVT working mode; F16) .01 Set the worki-ng voltage point of CVT mode. Generally, the inverter with voltage level of 380VAC can set this parameter between 450 and 540, and the inverter with voltage level of 220VAC can set this parameter between 250 and 310). In CVT mode, when the light intensity state, that is, the inverter bus voltage exceeds the voltage value set by F16.01, the inverter will speed up the pump running speed, otherwise the inverter will reduce the pump running speed.

The second working mode is MPPT working mode. In this working mode, the following parameters need to be set: F16.00 is set to 2, and the working mode is selected as MPPT working mode. F16.05 and F16.06 respectively set the upper and lower limits of MPPT mode voltage search (the two parameters generally use the factory values). When running in MPPT mode, the inverter will automatically search for the maximum power output point according to the sunlight intensity to ensure the maximum output power. (Because the sunlight intensity changes in real time, the process of searching for the maximum power point in this mode is a relatively slow process. And the maximum output power is not equivalent to the maximum pump operating frequency.) ** CVT working mode is relatively simple and easy to understand . It is recommended that customers use the CVT mode for testing.

3.3 Start the inverter:

The startup mode of the inverter is determined by the parameter F00.01, and the default is to start the inverter with the panel keys (ie, manually press the RUN key on the inverter panel to start the inverter). When the site is in the situation that no one needs to run automatically for a long time, it is recommended that the customer set F00.01 to 1, and use a wire to connect the S1 terminal and the DCM terminal together. This setting mode will run automatically as soon as the inverter is powered on.

3.4 Check the running direction of the water pump:

run with the pump. The running direction of the pump is related to the wiring sequence of the three motor wires "U", "V" and "W", so after starting the inverter, you need to check the pump manually Whether the running direction is correct, if the running direction is wrong, you need to choose two of the three motor wires "U", "V" and "W" to change the wire sequence.



3.5 Introduction to related faults of photovoltaic water pump:

- Sleep display U-L1 When the inverter panel displays this code, it means that the inverter enters sleep mode (not a fault). It will enter sleep mode only when the inverter is running at low speed for a long time. When the sun is strong enough, The inverter will automatically exit the sleep state and restart. For details, please refer to the detailed introduction of parameters F08.50 and F08.52.
- FULL is displayed when the water is full. When the inverter panel displays this code, it means that the inverter has detected a water full signal (need to connect a pressure sensor and other equipment). Refer to parameters F16.08, F16.09, F16.10 for specific introduction.
- Ounderload display E-PT. When the inverter panel displays this code, it means that the inverter has detected an underload. The underload detection is determined by parameters F16.12 and F16.13. The underload automatic reset time is determined by F16.14. When the inverter output current is less than the current value set by F16.12 and continues to run for a period of time (running time is greater than the time set by F16.13), the inverter will display the underload interface. **If the inverter falsely reports underload, you can set the underload current (F16.12) parameter to a smaller value. Generally, the no-load current of a three-phase asynchronous motor is about 30% of the rated motor current.

Steps	Parameter	Parameter meaning	Setting value	Remarks
1	F00.28	Function parameter recovery	1	Restore factory settings
2	F16.00	Vmpp voltage setting selection	1	CVT mode
3	F16.01	Given voltage of CVT mode	450	•
4	F16.12	Under load detection current	30.0	Underload detection current
5	F00.01	Run command channel	1	Terminal start

4. Recommended parameter settings, take SP200-4T-2.2G as an example :



5. Photovoltaic Pump Special Function Parameter Table

Function code	Name	Description (setting range)	Factory Default
		Group F0	
F0.00	Speed Control Mode	0: No PG vector control (SVC); 1: PG vector control (FVC); 2: V/F control	2
F0.04	Upper limit of operating frequency	F0.05~100% F0.04 is used to limit the maximum value of the target frequency. The final target frequency after PI adjustment cannot exceed the set upper limit value.	50.00Hz
F0.05	Operating frequency lower limit	The 0.0%~F0.04 F0.05 is used to limit the minimum value of the target frequency, and the final target frequency can not be lower than the set limit after the PI adjustment.	10.00Hz
F0.06	Frequency instruction selection	 0: The keyboard is set, and the power failure of the inverter is not memorized; 1: The keyboard is set, and the inverter is powered off; 2: The analog Al1 setting; 3: The analog Al2 setting; 4: The analog Al3 setting ; 5: PULSE pulse setting (HDI); 6: Multi-speed operation setting; 7: Simple PLC setting; 8: PID control setting; 9:485 communication setting; 10: Panel potentiometer given. 	8
Group F9			
F9.50	Awakening frequency	Sleep frequency (F08.52) ~ maximum frequency (F00.03); In sleep state, and the current running command is valid, when the PID calculation target frequency is greater than F8.50 wake-up frequency, after F8.51 delay time, Inverter wake up start	20Hz



Function code	Name	Description (setting range)	Factory Default
F9.51	Wake up delay time	0.0s~6500.0s	300.0s
F9.52	Sleep frequency	0.00Hz~ Awakening frequency (F08.52) Sets the sleep frequency higher than the lower limit of the operating frequency; When the operating frequency is lower than the lower limit of the output frequen- cy, the delay starts timing. After this status reaches the sleep delay time, the inverter Sleep, show (U-L1).	11Hz
F9.53	Sleep delay time	0.0s~6500.0s	100.0s
F9.61	Undervoltage setting	When the bus voltage is lower than (undervoltage point +50V), it immediately sleeps, and the display (U-L1) factory value is 70.0%, corresponding to 245V.	
Group F10			
F10.00	PID given source selection	The PID reference source is the bus volta- ge, which is dedicated to the PV pump.	7
F10.02	PID feedback source value selection	The PID feedback source is the bus voltage.	9
F10.03	PID output characteristics selection	0: PID output is positive characteristic; 1: PID output is negative characteristic.	1
F10.05	Proportional gain KP1	0.00~100.00 (Scale factor of the target frequency1) The larger the value, the greater the effect and the faster the adjustment.	20.0
F10.06	Integral time Ti1	0.00~100.00 (Integral coefficient of the target frequency1) The smaller the value, the greater the effect and the faster the adjustment.	2.00s
F10.07	Differential time Td1	0.000s~10.000s	0.005
F10.09	PID control deviation limit	Deviation is not calculated within 3V	0.50%

Chapter 8



Function code	Name	Description (setting range)	Factory Default
F10.15	Proportional gain Kp2	0.00~100.00 (Scale factor 2 of the target frequency) The larger the value, the greater the effect and the faster the adjustment.	70.0
F10.16	Integral time Ti2	0.00~100.00 (Integral coefficient of the target frequency 2) The smaller the value, the greater the effect and the faster the adjustment.	2.00s
F10.17	Differential time Td2	0.000s~10.000s	0.005
F10.19	PID parameter switching deviation 1	The factory value of 1.0% corresponds to a deviation of 10V	1.0%
F10.20	PID parameter switching deviation 2	The factory value of 3.0% corresponds to a deviation of 30V	3.0%
		Group F16	
F16.00	Vmpp voltage given selection	Set to 1, bus voltage is given as CVT mode; set to 2 as MPPT mode. A value of 1 indicates that a voltage reference method is used, the reference voltage is a fixed reference value given by F16.01, and 2 means that the reference voltage is tracked using the maximum power and the reference voltage will continue to change until the system is stable. Regardless of which reference voltage method is used, when the bus voltage is higher than the reference voltage, the target frequency will change to the upper output frequency limit; when the bus voltage is lower than the reference voltage, the target frequency will change to the lower limit of the output	2
F16.01	Set voltage for CVT mode	0.0~1000.0Vdc When F16.00 is 1, the reference voltage is given by this function code.	580.0V



Function code	Name	Description (setting range)	Factory Default
F16.02	MPPT voltage search interval	The unit is second	10.0s
F16.03	MPPT search voltage step 1	Coarse adjustment	5.0V
F16.04	MPPT search voltage step 2	Fine-tuning	1.0V
F16.05	MPPT search voltage limit	16.06~1000.0vdc is valid at MPPT maximum power tracking voltage and is the maximum voltage for tracking.	580.0V
F16.06	MPPT search voltage lower limit	0~F16.05 is valid at MPPT maximum power tracking voltage and is the minimum voltage for tracking. The maximum power tracking voltage will be tracked in the range of F16.06~F16.05. F16.05 must be greater than F16.06. The smaller the difference between them, the narrower the tracking range and the faster the tracking. However, it is important to ensure that the normal maximum power voltage falls within this range. F16.05 and F16.06 must be properly adjusted according to site conditions.	480V
F16.07	MPPT search voltage shutdown reset	Set to 0, MPPT search voltage shutdown reset; set to 1, stop does not reset.	0
F16.08	Water level detection selection	0: invalid; 1: Al1; 2: Al2; 3: Al3. When 0 is selected, the water level control is invalid. 1~3 are given for the water level control analog signal source. As long as the analog source is selected, the function codes F16.09, F16.10, and F16.11 will be valid.	0



Function code	Name	Description (setting range)	Factory Default
F16.09	Water level threshold	The unit is percentage, 0.0~100.0% When the detected water level control analog signal is greater than the water level threshold, and continues this state after the delay time of F16.10, it reports full water early warning (FULL) and sleeps. If it is non-continuous, that is, when the delay time does not arrive, the given analog signal is greater than the water level threshold, and the delay time is automatically cleared. Then, when the measured water level control analog signal is less than the water level threshold, the delay time is restarted.	70.00%
F16.10	Full water level delay	0~60000s Full water delay time setting.	60s
F16.11	Empty water level delay	0~60000s Empty water delay time setting. In the state of full water warning, when the detected water level control analog signal is less than the F16.09 water level threshold, the delay time is started. After this delay time of F16.11 continues, the full water warning is cleared and the system returns to normal In non-continuous situations, the delay timer is automatically cleared.	600s
F16.12	Underload detection current	0.0%: Underload not detected When not 0.0%, it is determined by the parameter setting value of F16.12. 100.0% corresponds to the rated current of the motor. If the current value continues to be less than the set value of F16.12, after the F16.13 pump underload running time, underload warning will be reported, otherwise it will work normally. In non- continuous situations, the delay timer is automatically cleared.	50%



Function code	Name	Description (setting range)	Factory Default
F16.13	Underload running time	0~60000s Pump under load Operation time setting. Under the condition of continuous under- load, when the running time arrives, an under-load warning (E-Pt) will be reported.	30s
F16.14	Underload reset time	0~60000s Underload reset delay setting. Under the state of under-load alarm, after the time of F16.14, reset to normal state.	3600s
	Sleep display U-L1; fu	Ill water display FULL; underload display E-Pt	

Peaco Support FC280 Series VFD User Manual





WARRANTY

The company solemnly promises that users will enjoy the following warranty services from the date of purchase of products from our company (hereinafter referred to as the manufacturer).

Since the product was purchased by the user from the manufacturer, enjoy the following three guarantee services:

- ¤ Return, replacement and repair within 30 days of delivery:
- x Replacement and repair within 90 days of delivery:
- x Repair within 18 months of delivery:
- $\exists Except when exporting abroad.$
- This product enjoys lifetime paid service from the date of purchase by the user from the manufacturer.
- Obsclaimer: Product failure caused by the following reasons is not covered by the manufacturer's free warranty service:

 - $\varkappa\,$ Failure caused by the user to repair or modify the product without communicating with the manufacturer:
 - x Failure caused by abnormal aging of the product due to poor user environment:
 - Failures caused by natural disasters such as earthquakes, fires, floods or abnormal voltages:
 - Damage to the product during transportation (the transportation method is specified by the customer, and the company assists in handling the cargo consignment procedures)
- Under the following conditions, manufacturers have the right not to provide warranty services:
 - When the manufacturer's product logo, trademark, nameplate, etc. are damaged or unrecognizable:
 - in When the user fails to pay the purchase price in accordance with the signed contract:
- For the service of return, replacement and repair, the company must return or return to the company, and it can only be returned or repaired after confirming the responsibility vested.



WARRANTY CARD

User information			
User name			
User address	\sim		
Postal code	Contact person		
Tel	Fax		
Machine type	Machine code		
Agent / Reseller Information			
Supplier			
Contact			
Tel	Delivery date		

CERTIFICATE OF QUALITY

QC test:

This product has been tested by our company's quality department, and its performance meets the standards, passes the inspection, and is approved to leave the factory.



Feedback Note

www.peacosupport.com sales@peacosupport.com Free Shipping Worldwide Reliable Supplier